

70x100MM 铜版纸正反印刷折页

XiQeer 希奇尔



BT2676

使用说明书

使用产品前请仔细阅读本使用说明，并请妥善保管

一.产品参数

产品型号:BT2676	充电时间:约4H
配对名称:BT2676	待机时间:约75H(开机连接状态下关闭灯光)
蓝牙芯片:蓝牙5.3	电池容量:4000mAh±5%
工作频率:2.4GHz-2.48GHz	电池规格:锂电池/3.7V
蓝牙格式:A2DP/AVRCP/HFP/HSP	播放音乐时长:约8小时 (70%音量,播放时长会随音乐类型和音量大小而改变)
传送距离:室内无障碍≥10米	防水防尘等级:IPX7
通话时长:约7小时	功能:蓝牙音乐播放/通话/TF卡播放/幻彩闪灯

*以上数据来源希奇尔实验室测定值,但因客观环境改变数据会有所不同或误差


二.连接与配对

- 长按“”键2秒
当音箱在关机状态下,长按“”键2秒,同时有开机提示音自动进入配对搜索模式,此时音箱可被其它设备发现
- 打开手机蓝牙进行搜索配对
配对名:



*蓝牙配对成功或开机自动回连:蓝牙配对成功,或开机后回连成功,有提示音

三.蓝牙使用

- 开机/关机**
开机:长按“”键2秒;
当音箱在关机状态下,长按“”键2秒,同时有开机提示音自动进入配对搜索模式,此时音箱可被其它设备发现
关机:长按“”键3秒
当音箱在开机状态下,长按“”键3秒,并有提示音
- 蓝牙控制**

 - : 音量减
 - M : 模式键
 - : 开机键
 - + : 音量加
 - * : 灯光键

 单击“  ”键接听;长按“  ”1秒拒接 /双击“  ”键回拨	 长按音量“+”键切换下一曲
 单击M键切换音源模式(蓝牙/TF卡模式) 有“断开蓝牙”的提示音 同时进入搜索配对模式	 单击“  ”键,暂停音乐; 再单击“  ”键,播放音乐
 单击音量“+”键实现加音量	 单击音量“-”键实现减音量
- 3.TWS配对**
两台音箱开机后无任何连接状态,长按其中一台“M”键2秒发出开始对箱TWS配对的提示音“嘟嘟”,等待几秒后对箱成功配对,伴随提示音“嘟”。
若要解除对箱配对,再长按2秒“M”键解除,有解除对箱提示音。
- 4.效果灯**
充电状态中红灯长亮;充满电后红灯灭
单击“*”键切换RGB灯,5色循环(渐变/蓝渐粉/随音乐节奏跳变/红渐橙/粉渐紫跳变)
长按2S“*”键关闭灯光


注意事项

- 切勿使用具有磨蚀性的清洁剂清理本产品。
- 切勿让本产品加热或靠近火源,如煮食炉。
- 切勿让本产品长时间受阳光直接照射。
- 切勿将本产品弃置于火中,避免发生爆炸。
- 切勿在雨中使用本产品。
- 切勿尝试拆开本产品作出任何修改,因为它并不包含任何维修组件。
- 如果长时间内不打算使用本产品,请你把它储存在干燥的环境中,避免极端的温度和灰尘!


Made in China

Warning Please follow the above safety instructions otherwise it will cause fire, electric shock, damage or other damage.

XiQeer



BT2676

INSTRUCTION MANUAL

Please read these instructions carefully before using the product and keep them in a safe place

1.Product parameters

Product Model: BT2676	Charging time: about 4H
Pairing name: BT2676	Standby time: about 75H (turn off the light when the device is turned on)
Bluetooth chip: Bluetooth 5.3	Battery capacity: 4000mAh±5%
Working frequency: 100Hz-20KHz	Battery specification: Lithium battery/3.7V
Bluetooth format: A2DP/AVRCP/HFP/HSP	Music playback duration: about 8 hours
Transmission distance: Indoor barrier-free≥10 meters	Dustproof and waterproof rating: IPX7
Talk duration: about 7 hours	Function: Bluetooth music playback/call/TF card/ FM playback/flashling lights

* The above data comes from HEPU laboratory measurements, but the data may vary or error due to changes in the objective environment


2.Connect & Pair

- Long press the “” button for 2 seconds
When the speaker is powered off, press and hold the “” button for 2 seconds, and at the same time, there is a boot prompt to automatically enter the pairing search mode, and the speaker can be discovered by other devices at this time.
- Turn on the Bluetooth of the mobile phone to search for the pairing name:



*Bluetooth pairing is successful or automatic reconnection after power-on: Bluetooth pairing is successful, or the reconnection is successful after power-on, and there is a prompt tone

3.Bluetooth use

- 1 Power on/off**
Power on: Press and hold the “” button for 2 seconds;
When the speaker is turned off,Press and hold “” button 2 seconds,At the same time,there is a boot prompt sound to automatically enter the pairing search mode,At this time, the speaker can be found by other devices.
Power off: Press and hold the “” button for 3 seconds
When the speaker is powered on, press and hold the “” button for 3 seconds, and there will be a prompt sound.
- 2 Bluetooth control**

 - : Volume down
 - M : Mode key
 - : Power button
 - + : Volume up
 - * : Light keys

 Click the “  ” key to answer; Long press “  ” 1 second reject, / double click the “  ” key to call back	 Long press the volume “+” button to switch to the previous track
 Click the M button to switch the audio source mode (Bluetooth/TF card/ FM mode) There is a prompt sound of “disconnect Bluetooth” Enter the search pairing mode at the same time	 Click the “  ” key to pause the music; Then click the “  ” button to play the music
 Click the volume “+” key to increase the volume	 Click the volume “-” key to reduce the volume
- 3.TWS pairing**
There is no connection status after the two speakers are turned on,Press and hold one of the “M” buttons for 2 seconds to send out a prompt sound to start pairing with the box TWS“Doodoo”,Wait for a few seconds to successfully pair the box,Accompanied by the prompt sound“Toot”To unpair the box,Press and hold for 2 seconds“M” The key is released,There is a prompt sound to lift the box.
- 4 Effect lights**
The red light is always on in the charging state;
The red light turns off when fully charged.
Click the “*” key to switch RGB lights,5 color cycles (gradient/blue fade/jump to the rhythm of the music, red fade to orange/pink fade to purple jump).
Long press the 2S“*” button to turn off the light.

Precautions

- Never use abrasive detergents to clean this product.
- Never allow this product to be heated or near a fire source, such as a cooking stove.
- Do not expose this product to direct sunlight for a long time.
- Do not dispose of this product in fire to avoid explosion.
- Never use this product in the rain.
- Do not attempt to disassemble this product to make any modifications, as it does not contain any repair components.
- If you do not plan to use this product for a long time, please store it in a dry environment away from extreme temperatures and dust!


Made in China

Warning Please follow the above safety instructions otherwise it will cause fire, electric shock, damage or other damage.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.