

# USE MANUAL

## SMART WATCH

### Charging and Activation

Before using the watch for the first time, please ensure it is fully charged. If the charging icon does not appear, please keep charging for 10 minutes.

1. Use the included magnetic charging cable to attach it to the metal contact points on the back of the watch, then charge it.
2. This product does not come with a power adapter. To ensure safety, you can use a computer USB interface or a power adapter with an output not exceeding 5V = 1A when charging. Please purchase a power adapter through legitimate channels and avoid using low-quality or counterfeit adapters to prevent damage to the watch, explosions, or fires.
3. Do not charge in a humid environment. Regularly clean the watch body with a dry cloth to ensure the cleanliness of the magnetic charging port and the magnetic charging cable for normal charging.




### Buttons and Touch

1. Long press to turn on the watch when off state.
2. In the power-on state, Long press to display the shutdown page, and click to shut down.
3. Press once on the watch dial to enter the menu, and press the button twice in quick succession to switch the menu styles.


4. When on the other interfaces, press the button to return to the watch dial interface.

Swipe Up: Message Notifications



Swipe Down: Control Center

### App Download and Connection



1. Download and install the 'FitCloudPro' app. You can scan the QR code in this manual, scan the QR code on the watch, or directly search for 'FitCloudPro' in the app store to download.
2. Connect the smartwatch. 1) Scan the QR code to connect: After the mobile phone turns on the Wireless, enter the APP (Note: If the APP cannot be opened, please turn on the positioning of your phone and then open the APP) Click on the device -> Click on 'Add Device' -> Click on 'Scan QR Code Binding' (scan the QR code on the watch). 2) Manual connection: Click 'Device' -> Click 'Add Device' -> Click 'Search Device' (Find the corresponding item in "Settings" -> "System" -> "System Information" in the watch sliding control center Wireless name and MAC address of the device) -> Click 'Connect'. 3) Connect to Wireless call: Slide down to open the 'Control Center', click the 'Telephone' icon, turn on the audio mode, and then turn on the Wireless call in the mobile phone system (when the mobile phone's Wireless is turned on/off), find the corresponding Wireless name, and click 'Connect'. After the connection is successful, the call and music functions can be used normally.

### FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.