










How to Wear A Microphone	
1.Keep the wired microphone in front of the voice source and speak (as shown in the picture).	
	Aim at this side when speaking.
2. When speaking, please refer to the correct wearing instruction and keep it right at the front of the voice source (as shown in the picture)	
	This picture shows the correct way to wear it.
3. Wrong wearing (as shown in the picture) will cause problems such as howling and low voice.	
	This picture shows the wrong way to wear it.
Tip: The black cotton can filter the sound of interfering airflow.	
	■ [19] ■



Warning	
Operating Environment	
01. This product should not be placed in an unbalanced, humid place or near other fire or heat sources (such as stoves).	
02. Do not place the product near devices that are susceptible to interference.	
03. Please do not use power chargers and batteries that are not equipped with this machine.	
Cleaning and maintenance	
01. This product must not be immersed in water or splashed with water.	
02. Do not use hard objects to wipe the surface to avoid scratches.	
03. Please use a soft cloth to wipe.	
Power Warning	
01. Please do not use power adapters and charging cable not provided with this machine.	
02. If the power adapter and charging cable are damaged, must be replaced with the original matching to avoid insufficient power supply or damage to the PCBA.	
	■ [20] ■
Cautions	
01. Please do not drop this product or hit it with hard objects to avoid injury or malfunction.	
02. Please do not use it when the structure is damaged, so as not to cause injury or other accidents.	
03. Do not remodel. Non-maintenance technicians are not allowed to disassemble and repair it to avoid fire, electric shock and injury.	
04. When abnormality or malfunction occurs, stop using it immediately to avoid fire, electric shock and injury..	
	■ [21] ■



Warranty & Repair Policy	
1. Please keep this warranty service card properly. If the warranty service card is lost, it will not be replaced. Please be sure to keep the invoice (or photocopy) or relevant vouchers (valid vouchers must be affixed with the dealer's store stamp), and present them together when the device is faulty and sent for repair. If you can not provide the invoice or relevant valid purchase vouchers, the product warranty The starting date of the period will be based on the date of manufacture corresponding to the serial number.	
2. Within one month from the date of sale of this product, if the voice amplifier has a failure under normal use conditions, you can receive free-of-charge services or replacement services; within two years, if the voice amplifier has a failure under normal use conditions, you can receive free after-sales repair warranty service. For product warranty service needs, please contact local purchasing dealer or agent for assistance.	
3. The accompanying consumables (product lanyards, charging cables, etc.) are not covered by the warranty.	
4. If the damage is caused by the following factors, the company will have the right to charge maintenance service fees as appropriate.	
Certificate	
Product name	High-Power Professional Voice Amplifier
Model	M12
QC	
Date of manufacture	
	■ [22] ■



FCC Caution
 (1) § 1.19 Labeling requirements.
 This device complies with part 1 of the FCC Rules* operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation*
 § 1.21 Changes or modification warning
 Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment*
 § 1.10. Information to the user*
 Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules* These limits are designed to provide reasonable protection against harmful interference in a residential installation* This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications* However, there is no guarantee that interference will not occur in a particular installation* If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 -Reorient or relocate the receiving antenna*
 -Increase the separation between the equipment and receiver*
 -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected*
 -Consult the dealer or an experienced radio/TV technician for help*