

「影寂天下人」

Reign of Serenity



雷电将军充能套装礼盒

Raiden Shogun Charging Bundle Gift Box


说明书

User's Manual

使用产品前请仔细阅读本说明书，并妥善保管
Read this manual carefully prior to use, and preserve it carefully.

礼盒示意图


礼盒底盒：



礼盒套盒：



移动电源说明书



- ① USB-C 口, 支持输入和输出
- ② 神变 · 恶曜开眼——电源按键
- ③ 诸愿百眼之轮——LED电源指示灯环
- ④ 雷罚恶曜之眼——LED电源指示灯

性能参数

产品名称: 「影寂天下人」雷电将军充能套装 - 移动电源

产品型号: SHJC20240522 产品尺寸: 97x65.5x20mm

电池容量: 5000mAh 电池额定能量: 19.3Wh

额定容量: 2800mAh 数量: 1 (个)

输入(USB-C): 5V=2.6A, 9V=2A

输出(USB-C): 5V=2.4A, 9V=2.22A, 12V=1.67A

无线充输出: 5W/7.5W/10W(MAX)

总输出 (USB-C+无线): 5V= 2.4A(Max)

FCC ID: 2BFZT-SHJC20240522

电池类型: 聚合物锂离子电池 生产日期: 2024 / 06 / 30

执行标准: GB 31241-2022, GB 4943.1-2022

产地: 广东省深圳市 生产商: 深圳市一讯达科技有限公司

地址: 深圳市光明区玉塘街道田寮社区同观路十九号路

10号九洲工业园厂房1栋701



⚠ 警告: 请勿拆解, 防止电击!
浸水后禁止使用!

雷罚恶曜之眼——LED电源指示灯的定义：

雷罚恶曜之眼



无工作状态

电量低于3%



一档状态

电量4%~75%



二档状态

电量76%~100%时

电量显示定义：



0%~3%



4%~10%

诸愿百眼之轮——LED电源指示灯环显示移动电源的剩余电量。

电量显示定义：



11%~25%



26%~50%

诸愿百眼之轮——LED电源指示灯环显示移动电源的剩余电量。

电量显示定义：




51%~75%



76%~100%

诸愿百眼之轮——LED电源指示灯环 显示移动电源的剩余电量。


产品使用方法——充电形式



形式一 无线充形式充电（手机需要支持无线充功能）：

- (1) 将移动电源轻放至手机背面，与手机接触后诸愿百眼之轮③经过一个完整的旋转动画后，显示当前电量。(当电量 $> 75\%$ 时，雷罚恶曜之眼④二档亮起)
- (2) 约15s后诸愿百眼之轮③将全部熄灭，只保留雷罚恶曜之眼④一档持续亮。


产品使用方法——充电形式



形式二 有线充形式充电：


- (1) 将USB-C接口数据线插入移动电源底端接口，另一端和手机相连，连接后诸愿百眼之轮③经过一个完整的旋转动画后，显示至当前电量。(当电量 > 75% 时，雷罚恶瞳之眼④二档亮起)
- (2) 约15s后诸愿百眼之轮③将全部熄灭，只保留雷罚恶瞳之眼④一档持续常亮。

电量查看——步骤一




(1) 未使用前, 诸愿百眼之轮③处于全部熄灭状态。

电量查看——步骤二




(2) 单击神变·恶瞳开眼②，诸愿百眼之轮③将以旋转动画的形式停止到当前电量。（当前电量示意：51%-75%）

电量查看——步骤三



(3) 约15s后诸愿百眼之轮③将全部熄灭。

电量查看——步骤四



(4) 若想关闭电源，也可通过双击神变·恶曜开眼②。

使用方法：

电源按键：

单击按键产品将开机，灯光以旋转动画形式即时点亮，15秒后熄灭，这表示该设备处于待机模式，可以正常使用。连续按开关两次，产品将关机，设备停止工作。

自动识别及唤醒功能：

产品设有自动检测识别功能，当识别到手机接入时（有线 / 无线）自动开启工作。

无线充电小贴士：

iPhone 12 及以上机型可直接使用无线充电，更早机型或安卓机型需要搭配磁吸片或支持磁吸的手机壳一同使用。

若所用手机型号不支持无线充，可选择有线充电的方式。

安全警示说明

- 1、本产品不是玩具,请放置于儿童无法触及的位置,禁止给儿童使用或玩耍,以免发生意外。
- 2、请务必选用符合当地安全标准(如中国3C认证标准)的充电器为本产品充电,以防触电或导致电池损坏。
- 3、请勿重压、敲击本产品并避免使本产品发生严重跌落或强烈震动,如发生这些情况,或有液体渗入/灌入本产品内部,可能导致电池、电路损坏或短路,请立即停止使用并妥善处置。
- 4、本产品发生鼓胀、变形、漏液、容量明显下降等情形,请立即停止使用并妥善处置。
- 5、请勿将本产品放置在衣裤口袋、密闭的包内、床上、沙发上等可能影响其散热的地方对其充电或对外放电。并确认使用中本产品不被衣物、枕头、被褥或其他杂物等覆盖,在长时间给手机等其他设备进行充电时,不要将本产品和手机等其他设备叠放在一起,确保手机和其他设备的良好散热。
- 6、严禁拆解、挤压、穿刺、短路本产品或投入水、火中(包括靠近炉灶、暖气等热源)或暴露于温度高于40°C的环境中。
- 7、天气炎热时,请勿将本产品放在室外无人的车内或其他阳光暴晒的场所。
- 8、本产品中包含锂离子聚合物电池,严禁私自拆开产品外壳,避免造成电池破损或其他危险。

电池使用注意事项

- 1、本产品不含任何可由用户自行维修的部件,充电电池不可更换。
- 2、将电池组投入火中或加热炉中,或对电池组进行机械挤压或切割的处理可能导致爆炸。
- 3、将电池组放置在极高温度环境中,可能导致爆炸或泄漏可燃液体或气体。
- 4、电池组承受极低气压,可能导致爆炸或泄漏可燃液体或气体。

注意事项

- 1、首次使用,请将本产品充满电。
- 2、移动电源存在转化效率,故移动电源电池容量不等同于可充电容量。
- 3、在为本产品充电或使用本产品为其他设备充电时,请自行选择适配的充电器和数据线。
- 4、对本产品充电过程中,应确保有人在场,外出或长时间离开时请拔除电源。
- 5、本产品充满电,或本产品对其他设备充满电后,请及时将连接线拔除,避免长时间处于连接状态产生损耗。
- 6、如本产品按键后无电量指示,可能处于保护状态,可连接到外部充电器尝试恢复。
- 7、若较长时间不使用本产品,为保证电池使用寿命,请每2个月至少给产品进行一次完全的充放电。
- 8、如因消费者违反产品使用说明书的警示,不恰当使用本产品所造成的人身及财产损害将自行承担一切后果,本公司将不承担任何法律责任。

无线充警告说明

本产品是利用磁耦合以及电容耦合等机理实现电源到负荷的非波束式近场电力传输。设备符合国家《无线充电(电力传输)设备无线电管理暂行规定》以及产品质量、电磁辐射和电气安全等法律法规、国家标准等有关规定。

不得擅自改变使用场景或使用条件、扩大工作频率范围、加大传输功率(包括额外加装功率放大器)。

不得对其他合法的无线电业务及台(站)产生有害干扰,也不得提出免受无线电干扰和辐射无线电波干扰的保护要求。如对其他合法的无线电业务及台(站)产生有害干扰时,应立即停止使用,并在采取措施消除有害干扰后方可继续使用。

无线充电设备禁用区域,禁止使用无线充电功能。

使用无线充电设备如对广播业务的接收造成影响,应立即停止使用无线充电设备。在船舶、航空器和铁路机车(含动车组列车)内使用无线充电设备应当遵守本规定及相关行业主管部门的规定。

有毒有害物质说明

有害物质	零部件	
	电路板组件	塑料/其他部件
铅(Pb)	×	●
汞(Hg)	●	●
镉(Cd)	●	●
六价铬(Cr,VI)	●	●
多溴联苯(PBB)	●	●
多溴二苯醚(PBDE)	●	●

● 表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572-2011规定限量要求以下。

× 表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T26572-2011规定限量要求。



本标识内数字表示产品在正常使用状态下的环保期限为5年

售后服务

1. 礼盒产品在正常使用和不影响二次销售的情况下，可享受7天无理由退换。
2. 移动电源与数据线提供一年内保修服务，相关运费由双方各自承担。
3. 保修服务仅限于保修期内及正常使用中出现的问题；一切非正常使用导致的损坏（未依据产品使用说明书正常使用、维护、保管所致的故障和损坏）或保修期满后的维修需求，用户需承担因此产生的维修费用。

退货、换货：

如需办理7天无理由退换货，请确保产品完好无损(外包装、塑封、吊牌等均需要完好无损)，不影响二次销售，并承担寄回产品所产生的运费。如因产品质量问题需要办理退、换货，请及时根据相关凭据（照片、视频）联系购买渠道的相关人员处理。

维修：

自移动电源与数据线签收之日起7天至一年内出现的质量问题，可直接联系购买渠道的相关人员处理，请勿自行拆开或试图维修本产品，否则您将会失去保修的权利。

数据线说明书

品名：「影刹天下人」雷电将军充能套餐 - 数据线

产品型号：SHJC20240523

尺寸：1m

主要材质：TPE+涤纶

数量：1 (条)

执行标准：Q/SQKJ001-2019

额定电流：3A

传输速率：480Mbps

产品接口：USB-C to USB-C



注意事项

一、连接与插拔步骤

1. 请确认电源适配器与充电线接口匹配，并将充电线的一端插入电源适配器。
2. 将充电线的另一端插入手机设备的充电接口，确保插入稳固，无晃动。
3. 连接完成后，将电源适配器接入电源插座，即可开始充电。

插拔时，请轻轻按下充电线接口，避免直接拉扯线身，以免损坏接口或线路。

二、充电时注意事项

1. 请使用符合规格的电源适配器，避免使用劣质或损坏的充电器，以免对设备造成损害。
2. 充电过程中，请勿过度弯曲或扭曲充电线，避免线路损坏或折断。
3. 充电时，请保持手机设备处于通风良好的环境，避免在高温、潮湿或密闭空间充电。
4. 充满电后，请及时断开充电线，避免长时间过充对设备电池造成损害。

三、保养与清洁建议

1. 使用时，请避免将充电线暴露在阳光直射或高温环境中，以免老化。
2. 清洁时，请使用干布轻轻擦拭线身和接口，避免使用化学清洁剂或液体，以免损坏绝缘层或接口。
3. 请勿将充电线置于潮湿或湿润的环境中，避免线路腐蚀或接口生锈。

四、安全使用提醒

1. 请勿在充电过程中使用设备，以免发生触电或短路等危险情况。
2. 如发现充电线有破损、断裂或变形等情况，请立即停止使用，并更换新线。
3. 请勿将充电线作为玩具或绑带使用，以免发生危险。

五、兼容性与适配范围

本充电线适用于多种品牌和型号的手机、平板等电子设备，请根据您的设备接口类型和充电需求选择适合的充电线。

手机支架说明书：

品名：「影刹天下人」雷电将军充能套餐单品-磁吸手机支架

产品型号：SHJC20240524

尺寸：直径57mm, 厚度7mm

主要材质：PC+锰钢+磁铁+聚氨酯合成革（PU）

数量：1 (个)

执行标准：GB/T 26572-2011

注意事项

产品使用说明：

1. 若用户手机为iPhone12及以上型号手机裸机，或者搭配具有磁吸手机壳，可直接使用本产品。首先请先撕掉产品表面的保护膜（如下图1），然后将本品磁吸面（黑色面）对准iPhone手机或者磁吸手机壳的磁吸圈，紫色图案朝外；即可实现为手机提供竖放或横放的支持功能；




（请使用前 请先撕下产品紫色图案面上的保护膜，更好呈现图案色彩）


支撑效果如下图：



提供手机竖屏支撑



提供手机横屏支撑



可以辅助手握手机，防止掉落

2. 若用户的手机无磁吸功能或无磁吸手机壳，可以使用我们搭配的引磁片配件。首先撕掉引磁片配件上的背胶，贴放到手机或者手机壳上，然后再使用本品（同样请先撕掉本品图案面上的保护膜），实现功能同上；

手机夹片挂绳说明书：

品名：「影寂天下人」雷电将军充能套餐 - 手机夹片挂绳

产品型号：SHJC20240525

主要材质：挂绳组件：锌合金+涤纶，夹片：尼龙布

数量：挂绳组件×1；夹片×2

尺寸：挂绳组件长：190mm；字母款夹片尺寸：60*28mm，表情包款夹片尺寸：42*55mm

执行标准：Q/SJZ 002-2024

注意事项

1. 请避免本品和硬物、锐物接触摩擦。
2. 产品表面如有污渍，请用软质湿布轻轻擦拭。
3. 避免与腐蚀性物质接触。
4. 产品非玩具，请放置于儿童不易接触的地方，禁止食用。
5. 夹片挂绳需要搭配全包式手机壳使用（建议选择硬度高的手机壳），装配好后注意下牢固度，确保无脱落风险再使用。




使用方法：

- 步骤一：将夹片放入手机壳中，夹片上的金属环勾穿过手机壳底部充电口处，注意夹片图案面朝向手机壳正面；
- 步骤二：挂绳挂钩勾住夹片上的金属环勾；
- 步骤三：将手机装回手机壳中，四周按压紧实牢固即可。

Gift box diagram

Bottom box:



Top box:





Diagram of Power Bank



- ① USB-C port, supporting I/O
- ② Transcendence: Baleful Omen — Power button
- ③ Chakra Desiderata - LED Power Indicator Ring
- ④ Eye of Stormy Judgment - LED Power Indicator

Performance Parameters

Product Name: 「Reign of Serenity」 Raiden Shogun Charging Bundle
- Portable Power Bank

Model: SHJC20240522 Dimension: 3.8inch×2.6inch×0.8inch

Battery capacity: 5,000mAh Rated energy of battery: 19.3Wh

Rated capacity: 2800mAh

Input(USB-C): 5V=2.6A, 9V=2A

Output(USB-C): 5V=2.4A, 9V=2.22A, 12V=1.67A

Wireless output: 5W/7.5W/10W(Max.)

FCC ID: 2BFZT-SHJC20240522 Quantity: 1 (piece)

Battery Type: Li-polymer battery Manufacturing date: June 30, 2024

Total output((USB-C+Wireless)) : 5V=2.4A(Max.)

Executive standards: GB 31241-2022/GB 4943.1-2022

Place of origin: Shenzhen, Guangdong

Manufacturer: Shenzhen Yostand Technology Co., Ltd.

Address: Room 701, Building 1, Jiuzhou Industrial Park, No.10, Road 19 Tongguan Road, Tianliao Community, Yutang Street, Guangming District, Shenzhen



WARNINGS:

- ⚠ Do not disassemble to avoid electric shock!
- ⚠ Do not use after being immersed in water!

Eye of Stormy Judgment

Definition of LED power indicator:

Eye of Stormy Judgment



Idle state

Power Less than 3%



First level

4%-75% Power



Second level

76%-100% Power

Battery Level Display Definition:



0%~3%



4%~10%

Chakra Desiderata - LED power indicator ring shows the remaining power of the power bank.

Battery Level Display Definition:



11%~25%



26%~50%

Chakra Desiderata - LED power indicator ring shows the remaining power of the power bank.

Battery Level Display Definition:




51%~75%



76%~100%

Chakra Desiderata - LED power indicator ring shows the remaining power of the power bank.

Product Use Method - Charging Method




Mode 1: Wireless charging

(mobile phone required to support wireless charging):

- (1) Place the power bank gently on the back of mobile phone. After it touches the mobile phone, Chakra Desiderata ③ Rotate once and then display the current power.(When battery power is > 75%, Eye of Stormy Judgment ④ Second level lights up)
- (2) After about 15 seconds, Chakra Desiderata ③ will completely close off, leaving only Eye of Stormy Judgment ④ First Level constantly lights up.


Product Use Method - Charging Method



Mode 2: Wired charging:


- (1) Plug USB-C cable into the port at the bottom of the mobile power bank, and connect the other end to the mobile phone. After the connection, Chakra Desiderata ③ will go through a complete rotation animation and then display the current power level.(When the battery level is > 75%, Eye of Stormy Judgment ④ Second level light up)
- (2) After about 15s, Chakra Desiderata ③ will all go out, leaving only Eye of Stormy Judgment ④ First Level constantly lights up.

Power Check_Step 1




(1) Prior to use, Chakra Desiderata③ will totally switch off.

Power Check_Step 2




(2) Click on Transcendence: Baleful Omen (2) Chakra Desiderata (3)
will rotate in an animation and stop at the current power.
(Current power: 51%-75%)

Power Check_Step 3



(3) After about 15s, all Chakra Desiderata③ will be extinguished.

Power Check_Step 4



(4) To power off, you can also double-click Transcendence: Baleful Omen ②.

The use method:

Power button:

Single click the button to start. Lights light up instantly with rotating animation and go out after 15s, that is, the device is in standby mode and can be used normally. Press the switch twice continuously, it will power off and the device will stop working.

Automatic identification and wake-up function:

The product has the function of automatic detection and identification. It may automatically start working when it identifies that a mobile phone is connected (wired/wireless).

Wireless charging tips:

iPhone 12 and above can be charged wirelessly directly, while earlier models or Android models need to be used with a magnetic sheet or a phone case that supports magnetic suction.

If the phone model used doesn't support wireless charging, wired charging mode is available.

Safety Warning Instructions:

1. This product is not a toy. Please place it out of reach of children. Do not allow children to use or play with it to avoid any accident.
2. Please be sure to use a charger that meets local safety standards (such as China's 3C certification standards) to charge this product to prevent electric shock or battery damage.
3. Do not press or knock this product and avoid causing it to fall or vibrate strongly. If these situations occur, or liquid seeps/splashes into the interior of this product, it may cause damage to the battery or circuit or short circuit. Please stop using it immediately and dispose of it properly.
4. If this product swells, deforms, leaks, or has a significant decrease in capacity, please stop using it immediately and dispose of it properly.
5. Do not place this product in the pocket of clothes, in a closed bag, on the bed, on the sofa, etc., where it may affect its heat dissipation, to charge or discharge it. And make sure that this product is not covered by clothes, pillows, bedding or other sundries during use. When charging other devices such as mobile phones for a long time, do not stack this product with other devices such as mobile phones to ensure good heat dissipation of mobile phones and other devices.
6. It is strictly forbidden to disassemble, squeeze, puncture, short-circuit this product, or put it into water, fire (including near stoves, heaters and other heat sources) or expose it to an environment with a temperature higher than 40°C.
7. When the weather is hot, do not place this product outdoors in an unmanned car or other places exposed to the sun.
8. This product contains Li-polymer batteries. It is strictly forbidden to disassemble the product shell at will so as to avoid battery damage or other dangers.

Cautions for Battery Use

1. This product doesn't contain any part that can be repaired by user, and the rechargeable battery can't be replaced.
2. It may cause an explosion to throw battery pack into a fire or heating furnace, or to mechanically squeeze or cut battery pack.
3. It may cause an explosion or leakage of flammable liquid or gas to place battery pack in an extremely high temperature environment.
4. If battery pack bears extremely low air pressure, it may cause an explosion or leakage of flammable liquid or gas.

ATTENTION

1. Please fully charge this product for the first use.
2. Since mobile power has conversion efficiency, battery capacity of mobile power isn't equivalent to rechargeable capacity.
3. When charging this product or using this product to charge other devices, please choose the appropriate charger and data line.
4. During the charging process of this product, make sure that someone is present. Please unplug the power supply when going out or leaving for a long time.
5. After this product is fully charged, or this product fully charges other devices, please unplug the connection cable in time to avoid loss caused by long-term connection.
6. If there is no power indication after pressing the button of this product, it may be in protection state. External charger can be utilized for recovery.
7. When this product is not used for a long time, please keep the power of this product in the range of about 25%-75% and store it in a cool and dry environment. Avoid storing this product for a long time in a fully charged or unpowered state to extend the battery life.
8. If consumer violates the warnings in user's manual and use the product inappropriately, the consumer would bear all liabilities both personal and property damage, and the company wouldn't bear any legal liability.

Wireless charging warnings

This product uses magnetic coupling and capacitive coupling mechanisms to fulfill non-beam near-field power transmission from power source to load. The equipment complies with the national 'Interim Regulations on Radio Management of Wireless Charging (Power Transmission) Equipment" and with other laws, regulations and national standards on product quality, electromagnetic radiation and electrical safety.

It is not allowed to change at will usage scenarios or conditions, or expand working frequency range, or increase transmission power (including installation of power amplifier).

It is forbidden to cause harmful interference to other legal radio services and stations, to make the protective requirement from radio interference and radiated radio wave interference. If it causes harmful interference to other legal radio services and stations, it shall stop immediately and can only be used after effective measures have been taken to eliminate the harmful interference.

In areas where wireless charging equipment is prohibited, wireless charging function is prohibited.

If charging equipment affects the reception of broadcast, it shall stop using immediately. Usage of wireless charging equipment in ship, aircraft and railway locomotive(including EMU train) shall comply with this regulations and regulations of relevant industry authorities.

After sales

1. Gift box can be returned or exchanged within 7 days without reason if it is used normally and doesn't affect secondary sales.
2. Power bank and data line have 1-year warranty, and the relevant shipment charges are borne by both parties.
3. The warranty is limited to issues that occur in the warranty period and for normal use; for all damages caused by abnormal use (failure and damage caused from usage, maintenance and storage not in accordance with user's manual) or maintenance demand beyond the warranty period, user shall bear the corresponding maintenance charge.

Return, exchange:

In case of returns for 7 days without reason, please ensure that the product is intact (packaging, plastic package and tag need to be intact) that doesn't affect the secondary sales and the client should bear the freight of returns. For returns from quality, please contact the person of channel according to the relevant evidence (photos, videos) in time.

Repair:

If any quality problem occurs in 7 days to one year from the date of receipt of the power bank and data line, it may directly contact the relevant personnel of purchase channel for treatment. Please do not disassemble or attempt to repair this product by yourself, or you will lose the warranty right.

Instruction for Data Line

Name: 「Reign of Serenity」 Raiden Shogun Charging Bundle - Data Line

Model: SHJC20240523

Dimension: 1m

Materials: TPE+Polyester

Quantity: 1 (piece)

Executive Standards: Q/SQKJ001-2019

Rated Current : 3A

Transmission rate : 480Mbps

Connector: USB-C to USB-C



ATTENTION

I. Connection and plugging steps

- 1) Please make sure that the power adapter matches the charging line interface, and insert one end of the charging line into power adapter.
- 2) Insert the other end of charging line into charging port of the mobile device, and make sure it is firmly inserted without shaking.
- 3) After the connection ends, plug power adapter into power socket to start charging. While plugging and unplugging, please press the charging line interface gently to avoid pulling the line body directly to avoid damaging the interface or circuit.

II. Cautions for charging

- 1) Please use a power adapter that meets the specification and avoid using any inferior or damaged charger so as to avoid damage to the device.
- 2) During charging, do not bend or twist the charging line excessively to avoid damage or breakage of circuit.
- 3) During charging, please keep the mobile phone in a well-ventilated environment and avoid charging in high temperature, humidity or confined space.
- 4) After fully charged, please disconnect charging line in time to avoid long-term over-charging and damage to device battery.

III. Suggestions on maintenance and cleaning

- 1) During using, please avoid exposing the charging cable to direct sunlight or high temperature environment to avoid aging.
- 2) During cleaning, please use a dry cloth to gently wipe the cable body and interface, and avoid using chemical cleaners or liquids to avoid damaging the insulation layer or interface.
- 3) Do not place the charging cable in a damp or humid environment to avoid the line corrosion or interface rust.

IV. Safety use alert

- 1) Do not use the device during charging so as to avoid dangers such as electric shock or short circuit.
- 2) If the charging line is damaged, broken or deformed, please stop using it immediately and replace it with a new line.
- 3) Do not use the charging cable as a toy or strap so as to avoid danger.

V. Compatibility and adaptation range

This charging cable is suitable for various brands and models of mobile phones, tablets and other electronic devices. Please choose the appropriate charging cable according to your device interface type and charging requirements.

Instruction for Magnetic Phone Stand

Name: 「Reign of Serenity」 Raiden Shogun Charging Bundle
- Magnetic Phone Stand

Model: SHJC20240524

Materials: PC+manganese steel+magnet+polyurethane synthetic leather (PU)

Dimension: Diameter 57mm, thickness 7mm

Quantity: 1 (piece) Executive standard: GB/T 26572-2011

ATTENTION

Product Instruction:

1. If the user's mobile phone is an iPhone 12 or above, or is paired with a Magsafe mobile phone case, this product can be used directly. First, please tear off the protective film on the surface of the product (as shown in Figure 1 below), and then align the magnetic surface (black side) of this product with the magnetic ring of the iPhone or Magsafe mobile phone case, with the purple pattern facing outward; this will provide support for the mobile phone to be placed vertically or horizontally;




(Please tear off the protective film on the purple pattern surface of the product before use to better show the color of the pattern)


The support is as follows:



Provide vertical screen support for mobile phone



Provide horizontal screen support for mobile phone



To help hold mobile phone to prevent it from falling

2. If user's mobile phone doesn't have a magnetic function or a magnetic case, our magnetic accessories can be used. First, tear off the adhesive on magnetic sheet accessory, stick it on mobile phone or its case, and then use this product (please also tear off the protective film on the pattern surface of this product first) to fulfill the same function as above;

Instruction for Phone Clip Lanyard

Name: 「Reign of Serenity」 Raiden Shogun Charging Bundle
- Phone Clip Lanyard

Model: SHJC20240525 Quantity: Lanyard assembly × 1; Clip × 2

Materials: Lanyard assembly: zinc alloy + polyester Clip: nylon

Dimension: Lanyard assembly length: 190mm; Size for letter style clip: 60*28mm;
Size for emoji style clip: 42*55mm

Executive standard: Q/SZJZ 002-2024

ATTENTION

1. Please avoid contact and friction between this product and hard/sharp objects.
2. If there are stains on the surface of the product, please wipe it gently with a soft damp cloth.
3. Avoid contact with corrosive substances.
4. This product is not a toy. Please keep it in a place where children can't easily reach it. It is forbidden to eat it.
5. Clip lanyard need be used with a full-cover mobile phone case (it is recommended to choose a mobile phone case with high hardness). After assembly, pay attention to the firmness to ensure that there is no risk of falling prior to use.



The use method:

- Step 1: Put the clip into phone case, and pass metal clasp on the clip through charging port at the bottom of phone case. Note that the pattern side faces the front of phone case;
- Step 2: Catch the lanyard hook to metal clasp on the clip;
- Step 3: Put mobile phone back into its case and press it firmly.

FCC Requirement

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment. This device should be installed and operated with minimum distance 20cm between the radiator & your body.



©miHoYo