



Foldable Wireless Charger Alarm Clock

Product Parameters

Product Name	Foldable Wireless Charger Alarm Clock	Product Model	JY - 01
Input Voltage	9V---2.22A	Built In Battery	1000mAh
Phone Output	10W (MAX)	Product Size	136 x 126 x 28(mm)

Packing List

Color Box, Product, Type-C Cord, User Manual.

User Guide

1. Power ON/OFF Switch

- Turn the power switch to "ON", The product is working normally.
- Turn the power switch to "OFF", The product will be shut down.

2. Night Light Key

- Short press this button to turn on light.
- Short press this button to select light colors.
- Long press this button to turn off the night light.
- The light colors include RGB, white, orange, yellow, purple, blue, light blue, green, red.

1

3. Alarm Clock 1 Switch

- Turn the alarm 1 switch to "ON", alarm 1 will turn on, and the indicator light for alarm 1 will turn on.
- Turn the alarm 1 switch to "OFF", alarm 1 will turn off, and the indicator light for alarm 1 will turn off.

4. Alarm Clock 1 Setting

- Long press "Alarm 1 Set" key for 1.5 seconds to enter the alarm clock 1 setting and the "hour" is flashing, then press + or - key to select.
- Then short press "Alarm 1 Set" key to enter the "minute" flashing, press + or - key to select.
- Lastly, short press "Time Setting" key or wait for 5 seconds to confirm the ringtone and return to time display.
- If you want to check Volume and Ringtone, please short press "Tunes Setting", Volume and Ringtone will be displayed 5 seconds.
- If you want to check alarm clock 1, please short press "Alarm 1 Set", Alarm Clock 1 time will be displayed 3 seconds.

5. Time Setting

12/24H

- Long press "Time Setting" key for 1.5 seconds to enter the time setting and the "hour" is flashing, then press + or - key to select.
- Then short press "Time Setting" key to enter the "minute" flashing, press + or - key to select.
- During alarm, press button except "Snooze / Light Setting" will turn off the alarm for the day.
- Lastly, short press "Time Setting" key to enter the "week" flashing, press + or - key to select.

2

6. Tunes Setting (Volume/Ringtone Setting)

- The Snooze function is set to a maximum of 3 times, after which the alarm for the day will be turned off. If the "Snooze / Light Setting" button is not pressed, the alarm will turn off for the day after 30 minutes of ringing.

7. Snooze / Light Setting

12/24H

- In the clock mode, short press "Snooze / Light Setting" Button to adjusts the brightness of display screen in 5 Levels: The Brightest, Medium Bright, Slightly Bright, The Darkest Brightness, Off.
- Then, short press "Alarm 2 Set" key to enter the "week" flashing, press + or - key to select.
- During alarm, press button except "Snooze / Light Setting" will turn off the alarm for the day.
- Lastly, Wait for 3 seconds to confirm the alarm and return to time display.

3

8. Up Key

- In the clock mode, the time separator does not flash by default. Long press the "UP" button for 1.5 seconds to switch to flashing.
- In setup mode, cooperate with modifying parameters.

9. Down Key

- In setup mode, cooperate with modifying parameters.

10. Alarm Clock 2 Setting

12/24H

- Short press this button to reset the factory settings.

11. Alarm Clock 2 Switch

- Turn the alarm 2 switch to "ON", alarm 2 will turn on, and the indicator light for alarm 2 will turn on.

12. Power off time memory protect function

- If the product battery is out of power, the battery indicator light will flash.
- If product still doesn't charge, product will automatically shut down.
- Time memory protection function activated.

13. Reset Key

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

14. Voice Control

- When the product is not plugged in the power, the display screen automatically shuts down. When there is a sound greater than 90 decibels, the display screen shows for 6 seconds.

Customer after-sale service

- Thank you for your purchase. The product comes with a 12-month warranty period. If you have any issues about the product, please feel free to contact us at any time.

Our email is: shenzhenchouyang@outlook.com

4

15. FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

16. Alarm Clock 2 Switch

- Turn the alarm 2 switch to "ON", alarm 2 will turn on, and the indicator light for alarm 2 will be displayed 3 seconds.

17. Power off time memory protect function

- If the alarm goes off and the "Snooze / Light Setting" Button is pressed, the indicator light on the clock alarm will flash. The alarm will temporarily stop until 9 minutes.

18. Up Key

- The Snooze function is set to a maximum of 3 times, after which the alarm for the day will be turned off. If the "Snooze / Light Setting" button is not pressed, the alarm will turn off for the day after 30 minutes of ringing.

19. Down Key

- When the alarm goes off and the "Snooze / Light Setting" Button is pressed, the indicator light on the clock alarm will flash. The alarm will temporarily stop until 9 minutes.

20. Power off time memory protect function

- If the alarm goes off and the "Snooze / Light Setting" Button is pressed, the indicator light on the clock alarm will flash. The alarm will temporarily stop until 9 minutes.

5

21. FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

22. Alarm Clock 2 Switch

- Turn the alarm 2 switch to "ON", alarm 2 will turn on, and the indicator light for alarm 2 will be displayed 3 seconds.

23. Power off time memory protect function

- If the alarm goes off and the "Snooze / Light Setting" Button is pressed, the indicator light on the clock alarm will flash. The alarm will temporarily stop until 9 minutes.

24. Up Key

- The Snooze function is set to a maximum of 3 times, after which the alarm for the day will be turned off. If the "Snooze / Light Setting" button is not pressed, the alarm will turn off for the day after 30 minutes of ringing.

25. Down Key

- When the alarm goes off and the "Snooze / Light Setting" Button is pressed, the indicator light on the clock alarm will flash. The alarm will temporarily stop until 9 minutes.

26. Power off time memory protect function

- If the alarm goes off and the "Snooze / Light Setting" Button is pressed, the indicator light on the clock alarm will flash. The alarm will temporarily stop until 9 minutes.

6