

Wireless Speaker User Manual



What's in Your Box

- 1x Bluetooth Speaker
- 1x Charging cable
- 1x User Guide

Please read the safety advice carefully and keep it for future reference.

Safety Instruction

- 1 This logo means that no naked flames, such as a candle can be placed on or near the device.
- 2 The electrical and electronic equipment are part of a separate collection. Do not throw electrical or electronic equipment away with unsorted municipal waste. Please use the collection system available in your community (household waste sorting centers, rubbish dump) are provided for you by local councils and retailers. By entrusting your end-of-life product to the proper recycling process, you are helping to protect the environment.
- 3 Children over the age of 8 or persons with poor physical conditions, perception or mental retardation, or persons who lack relevant experience and knowledge, can use this device under the condition that someone supervises or gives instructions on the safe use of equipment and understands the possible hazards.
- 4 Always unplug the device before cleaning it.

5 Clean the device with a soft dry cloth only. Never use solvents.


6 The battery (batteries or battery pack) shall not be exposed to excessive heat such as sunlight, fire or the like.

Please read the safety advice carefully and keep it for future reference.

Specification

Specification	
Bluetooth Version	V5.3
Speaker Output Power	10W
Built-in Power	2500mAh
SNR	75dB
Speaker Frequency	80Hz-20KHz
Wireless Transmission Distance	Up to 33 ft (10M)
Charging Time	About 3-4 hours
Playback Time	Up to 10 hours
Input power	- DC 5V

Product Diagram



Operation

- 1 Use the power cable to connect the charger and speaker for charging.

2 The orange power LED will turn on to indicate that the unit is charging. Then will turn to green when fully charged.

Note: A full charge takes approximately 3-4 hours.

Power On / Power Off

Power on: Press and hold the button for 2 seconds to power on the speaker.

The working state LED will flash.

Power off: Press and hold the button for 2 seconds to power off the speaker.

The working state LED will turn off.

Pairing Bluetooth Devices with Your Speaker

After the speaker is turned on, the working state LED light flashes blue. Then turn on the mobile phone Bluetooth, search for a device named TWS, click on the device to connect, and the working indicator light is always blue. After the next boot, the speaker will automatically connect back to the mobile phone. Of course, the Bluetooth of the mobile phone needs to be turned on.

Bluetooth Music Play/Pause

1 Open the music player and select a song to play. Press the button to pause / play the music.

2 Click the button to increase the volume or long press to skip to the next song.

3 Click the button to decrease the volume or long press to skip to the previous song.

Phone Calls

You can purchase two speakers to connect them together and enjoy the stereo effect.

1 After the two speakers are turned on, connect one of them to the Bluetooth of the mobile phone, and do not connect the other to any device. Then long press the button for 2 seconds to connect the two speakers. The working indicator light will flash blue and white alternately, and the working indicator will stop alternating flashing after the pairing. The one that is always blue is the left channel speaker, and the one that is always white is the right channel speaker. After the next boot, the two speakers will automatically connect back to TWS mode.

2 Clear connection: Press and hold the button for 2 seconds to clear and disconnect the Bluetooth and TWS connection, the speaker enters the waiting state for pairing, and the working indicator light flashes blue.

Colorful light adjustable & Turn off

The colorful radiator on the top of the speaker has colorful dazzling lighting effect. you can double click the button to switch the display effect or turn off the speaker.

Energy saving

When the speaker is suspended for more than 20 minutes, it will automatically shut down to save power except for charging.

Storage time

When the speaker is not in use, it can be stored for up to 1 year. It is recommended to charge once every 3 months.

After sales email
US CA : service-us@deoyaple.com
UK: service-eu@deoyaple.com

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.