

## Instructions for use

English

Main functions: (only support iOS system  "Find" application, Android is not applicable)

### Instructions for use:

1. Tag power on Press the switch button to activate the Tag (there is a short beep beep sound).

#### 2. Pairing Tag

Open Apple's "Find" App, click "Devices", then click the device you want to find.

Bring the Tag close to your iPhone, tap the "Items" tab to select "+" and "Tap Other Supported Items".

-Tap Connect. Fill in the "Custom Name" to name your Tag and select an emoticon, tap "Agree" to confirm that the Tag will be linked to your Apple device. tap Done.

#### 3. Enable Lost Mode

-Open "Find" app, tap "Tag", and then tap the name of the lost tag.

-Under "Lost Mode", click "Enable". Follow the on-screen instructions and click "Continue" to enter your contact number or email address. -Click "Next" to

check the information, and then click "Enable" again to complete the setup.

#### 4. Delete Device

-Open Apple's "Find App", tap "Tag" at the bottom of the screen, and then tap the name of the tag you want to remove.

Find "Remove Item" at the bottom of the list, tap "Remove" to finish the operation.

Note: The local unbinding operation of the anti-lost device: press the button 5 times quickly and continuously (the first 4 times you press the button once, there will be a "beep" sound).

5. Factory reset method:  
Remove the battery, then reinstall it, and repeat this operation five times to restore the factory settings.

Product Name: Finder Tag

Model: AK30

**DISCLAIMER:** This product cannot be used in all illegal ways!

## Instructions for use

English

### Federal Communications Commission Notice

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.  
-Increase the separation between the equipment and receiver.  
-Connect the equipment into an outlet on a circuit different from that to

which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.