



REMOTE CONTROLLER INTRODUCTION

1. Use a screwdriver to open the remote control battery cover, install 2xAAA correctly, and then close the battery cover and tighten the screws




2. switch it on and press any button on remote controller, the indicator light keep flashing which represents its function is normal.



3. USB CHARGING

- (1) Insert one end of the USB charging cable into the power socket.
- (2) Switch off the power of the tank and then insert another end of the USB charging cable into the charging jack of the tank. The LED lights up green during charging. As soon as the battery is fully charged, the LED goes out.
- (3) After about 30 minutes of charging, the charging indicator light will be off, which indicating the end of charging. The tank can travel for about 20 minutes with sufficient power.



WARNING


1. During the process of charging, please DO NOT pull or tug on the charging cable and plug.
2. Please ensure that the product is fully discharged before charging to avoid overcharging that may affect the using life of the battery.

STORAGE

1. After use, please wipe the dust off the tank clean and store it and pack the tank in a dry and well ventilated place.
2. After use, please switch off the power of the tank and the remote controller to improve the using life of the battery.
3. Before using it again, please check if the tank and remote controller have sufficient power.


INTRODUCTION OF REMOTE CONTROL FUNCTION

Operation lever go forward to adjust the speed of vehicle




operation lever go backward to adjust the turning angle of wheels


1. Push "Forward" Lever, the Tank will race forward.




2. push backward lever, the tank will backoff.



3. Push "Turn-left" Lever, the Tank will turn to the left.




4. Push "Turn-Right" Lever, the Tank will turn to the right.




5. Control to the Turret

LEFT ROTATION OF THE TURRET




RIGHT ROTATION OF THE TURRET



INFRARED BATTLE

Buying 2 or more Infrared Control Battle Tanks, you can start Infrared Ray Fighting Game. The following is the reaction of a tank after being hit in actual combat and how to restart the tank after being defeated.


1. put one tank IR emitter aim to the receiver of another tank, press the infrared battle button, when the tank got shoot from first to fourth times, it will rotate left and right, and its indicator light flashes faster.
2. When the Tank gets hit for the fifth time, the Tank turns left and right for one circle, then freezes. The Tank needs to be shut down again, wait for 5 seconds and then switch it on again before it can be activated.



TRIMMING FUNCTION

Fine tuning function it enables to adjust the turning angle when tank run out of straight line.

1. When wheels deviate to the right, press the button left fine tuning,
2. When wheels deviate to the left, press the button right fine tuning.



WARNING

1. Use this product and its accessories only when fully assembled and following the instructions in this manual. Adult supervision is strongly recommended.
2. CHOKING HAZARD. Not suitable for children under 36 months due to small parts.
3. This product is suitable for children at age 8 or above.
4. If there are radio signals nearby, it will interfere with the signal reception of the tank and affect its normal operation.
5. Dispose of used batteries safely and in accordance with local regulations.
6. Do not expose the product to water, moisture, or damp conditions.
7. When battery is wet with water, please clean it with a dry cloth.
8. Laser radiation, please DO NOT stare into laser beam directly.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FULL PROPORTIONAL MINI IR CONTROL BATTLE TANK MANUAL


Please read the instructions carefully before using and well keep it for future reference.

COMPONENTS




COMPONENTS DETAIL

TANK



REMOTE CONTROL



OPERATION GUIDE

Before operation, please turn on the power of remote controller and the tank, the LED lights up and make sound effect as soon as the frequency matching successfully, then put the tank on the flat surface, if no input is made via the remote control within three minutes, the model switches to sleep mode, the power switch must be pressed again to restart.