




<p>多功能手机蓝牙 指环遥控器</p> <p>JX-05</p>  <p>视频/阅读/自拍遥控器说明书</p>	<p>产品简介</p> <p>视频/阅读遥控器支持短视频(抖音、快手、微视等)及个别手机阅读APP的翻页功能, 支持调节手机音量加减, 真正释放双手! 还是一个自拍遥控器, 在观看短视频时, 拍个美美的自拍照!</p> <p>规格参数</p> <p>适用系统: 视频/阅读/自拍遥控器 支持iOS 14.8/Android 8.0以上 蓝牙版本: 蓝牙5.3 发射频率: 2.4-2.4835GHz 工作电压: 3.9-4.2V(聚合物锂电池) 工作温度: 0-50°C 通讯距离: 10m</p> <p>按键功能说明</p>  <p>1. 长按开关机, 单击暂停, 双击点赞, 短按2-3秒拍照 2. 单击上翻页, 长按加音量, 短按2-3秒拍照 3. 单击下翻页, 长按减音量, 短按2-3秒拍照 4. 单击左翻页, 长按返首页 5. 单击右翻页, 长按锁屏 6. 指示灯</p> <p>抖音拍照操作: 1. 点开抖音拍照 2. 右侧第三个选项 3. 打开使用音量键拍摄。以上设置就可以使用2号键正常拍照片啦。</p>	<p>使用说明</p> <p>操作如下: 手机型号: iPhone X, iOS14.8: 长按3秒1键开机, 蓝色指示灯闪烁时, 在手机蓝牙中搜索, 蓝牙设备名称: JX-05, 与手机蓝牙配对成功后, 进入短视频APP, 以抖音短视频APP为例: 按下①键播放或暂停视频, 双击①键给视频点赞, 按下②③④⑤键可实现视频上下左右(以实际为准)的翻动, 详情参照功能键操作。</p> <p>关于苹果手机</p> <p>使用苹果手机/平板时, 请注意一下几点: 1. 确保手机iOS软件为14.8以上 2. 辅助触控功能必须打开 iOS14.8以上版本需设置方可使用。设置如下: 设置→辅助功能→触控→辅助触控→打开, 出现圆点即可。 设置如下:</p>  <p>1. Control Center 2. Dynamic Effects 3. Accessibility 4. Use Game Controller 5. Tracking Sensitivity</p>	 <p>1. Assistive Touch 2. Accessibility 3. Control Center 4. Assistive Touch 5. Tracking Sensitivity</p> <p>Note: iOS system users can only use the touch assisted dot indicator to move up and down after the touch assisted dot indicator continues to jump up and down, he should adjust the tracking sensitivity.</p>	<p>3. 以上2项如果确认OK, 还是不能正常使用请把手机关机再开机一次 4. 打开辅助触控后, 会出现在2个点。大的圆圈是可以移动的, 小的是没有办法移动的, 不刷视频30秒消失, 安卓和鸿蒙没有这个点。 5. 苹果问题: 点击鼠标点跳动, 不能刷屏, 请把辅助触控关闭再开启就可以正常使用</p> <p>Android版本手机蓝牙配对即可使用, 如鼠标或圆点不在拍照键上, 可参考设置1。 提示: 如因iOS系统升级造成产品不能使用, 属不可抗力。</p>  <p>微信扫描二维码进入JX-05视频使用教程</p>	<p>合格证</p> <p>型号: _____</p> <p>检验员: _____ </p> <p>出厂日期: _____</p>
--	--	--	---	---	--

<p>Multifunction Mobile phone bluetooth Ring remote control</p> <p>JX-05</p>  <p>Video/Reading/Selfie Remote Control Instructions</p>	<p>Product introduction</p> <p>The video/reading remote control supports short videos (Tik Tok, Kuaishou, Weishi, etc.) and the page-turning function of individual mobile phone reading APPs, supports adjusting the volume of the mobile phone to increase or decrease, and truly releases both hands! It is also a selfie remote control, when watching short videos, take a beautiful selfie!</p> <p>Specifications</p> <p>Applicable system: video/reading/selfie remote control Support iOS 14.8/Android 8.0 and above Bluetooth version: Bluetooth 5.3 Transmission frequency: 2.4-2.4835GHz Working voltage: 3.9-4.2V (polymer lithium battery) Operating temperature: 0-50°C Communication distance: 10m</p> <p>Button function description</p> <p>1. Long press to turn on/off, click to pause, double-click to like, short press for 2-3 seconds to take a photo 2. Click on page up, long press to increase volume, short press for 2-3 seconds to take a photo 3. Click on page down, long press to reduce volume, short press for 2-3 seconds to take a photo</p>	 <p>4. Click on the left page and long press to return to the homepage 5. Click on the right page and long press to lock the screen 6. Indicator lights</p> <p>Tiktok photography operation: 1. Click on Tiktok photography 2. The third option on the right 3. Turn on and use the volume key to shoot. The above settings allow you to take photos normally using the 2nd key.</p> <p>Instructions for use</p> <p>The operation is as follows (iPhone X, iOS14.8): Press and hold the ① button for 3 seconds to turn on the power, when the blue indicator flashes, search in the Bluetooth of the mobile phone, the Bluetooth device name: JX-05, after successfully pairing with the Bluetooth of the mobile phone, enter the short video APP, take the Douyin short video APP as an example: Press the ① button to play or pause the video, double-click the ① button to like the video, and press the ②③④⑤ button to flip the video up, down, left and right (subject to the actual situation). For details, refer to the function key operation.</p> <p>About iPhone</p> <p>When using an iPhone/tablet, please note a few things:</p>	 <p>1. General 2. Accessibility 3. Touch 4. AssistiveTouch 5. Tracking Sensitivity</p> <p>Note: If the iOS system user is unable to operate up and down after the touch assisted dot indicator continues to jump up and down, he should adjust the tracking sensitivity.</p>	<p>1. Ensure that the iOS software of the mobile phone is 14.8 or higher 2. Auxiliary touch function must be turned on iOS14.8 and above versions need to be set before use. The settings are as follows: Settings → Accessibility → Touch → Assistive Touch → On, and a dot appears. The settings are as follows:</p>  <p>1. Control Center 2. Display & Brightness 3. Accessibility 4. Assistive Touch 5. Tracking Sensitivity</p> <p>From left to right to the adaptive position for normal use. (Execute touch gesture) must be turned on, as shown in the following figure</p> <p>Tracking sensitivity adjustment sliding, after adjustment, the auxiliary touch must be turned off and then turned on again</p> <p>If unable to operate normally, please lower the sensitivity.</p> <p>3. If the above two items are OK and still cannot be used normally, please turn off the phone and turn it on again 4. After opening the auxiliary touch, 2 dots will appear. The big circle can be moved, and the small one cannot be moved. It disappears in 30 seconds without brushing the video. Android and Hongmeng do not have this point. 5. Apple problem: Click the mouse to beat, can not brush the screen, please turn the auxiliary touch off and on can be used normally</p> <p>The Android version of the mobile phone can be used after Bluetooth pairing. If the mouse or dot is not on the camera button, please refer to Setting 1.</p> <p>Tip: If this product cannot be used due to the upgrade of the iOS system, it is a force majeure.</p>	<p>Certificate of conformity</p> <p>Model: _____</p> <p>Inspectors: _____ </p> <p>Date of manufacture: _____</p>
--	--	---	---	---	---

FCC Caution:

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful

interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.