

77\*32\*80mm



70\*70mm

<div data-bbox="142 1505 323 1547">无线翻页器</div> <div data-bbox="407 1510 517 1542">JX-07</div> <div data-bbox="191 1626 430 1875"> </div>	<div data-bbox="601 1500 685 1525">规格参数</div> <table border="1"> <tr> <td>翻页器:</td><td>遥控器:</td></tr> <tr> <td>电池容量: 200mAh</td><td>电池容量: 30mAh</td></tr> <tr> <td>充电输入: 5V</td><td>充电输入: 5V</td></tr> <tr> <td>充电时间: 约1.5小时</td><td>充电时间: 约30分钟</td></tr> <tr> <td>充电方式: USB-C</td><td>充电方式: USB-C</td></tr> </table> <div data-bbox="601 1663 685 1687">产品图示</div> <div data-bbox="601 1717 998 1909"> </div>	翻页器:	遥控器:	电池容量: 200mAh	电池容量: 30mAh	充电输入: 5V	充电输入: 5V	充电时间: 约1.5小时	充电时间: 约30分钟	充电方式: USB-C	充电方式: USB-C	<div data-bbox="1082 1500 1166 1525">使用说明</div> <div data-bbox="1082 1562 1480 1648"> </div> <div data-bbox="1070 1692 1493 1880"> <ol style="list-style-type: none"> <li>1. 点击翻页按钮 (翻页指示灯亮)</li> <li>2. 配对操作点击遥控操作按钮 (翻页指示灯闪烁)</li> <li>3. 将书页翻转器夹在Kindle的一侧, 按下遥控器功能按钮, 即可正常翻页 (如果您购买的是带有两个夹子的版本, 遥控器机器插上电源充电、长按可定义键3秒, 指示灯白灯快闪, 副机功能键定义完成, 则可以将它们夹在两侧以同时翻页)。</li> <li>4. 遥控器切换回原来模式, 同样操作。遥控器插上电源充电、长按可定义键3秒, 指示灯红灯快闪, 设置完成。</li> </ol> </div>	<div data-bbox="1554 1500 1638 1525">功能描述</div> <div data-bbox="1554 1537 1890 1621"> <ol style="list-style-type: none"> <li>1. 翻页器和遥控器, 充电状态指示灯闪烁, 充满电状态指示灯长亮。</li> <li>2. 如果遥控器在30分钟内未使用, 翻页器将自动关闭。遥控器和翻页器指示灯的每次操作都会闪烁一次</li> </ol> </div> <div data-bbox="1554 1697 1602 1722">警告</div> <div data-bbox="1554 1742 1867 1813"> <ol style="list-style-type: none"> <li>1. 长期储存后, 请在充电后使用。</li> <li>2. 产品不防水, 请勿在极寒、高温、潮湿的环境中使用。</li> <li>3. 不要粗暴地使用接收器, 以免损坏它。</li> </ol> </div>	<div data-bbox="2158 1576 2326 1621">合格证</div> <div data-bbox="2097 1663 2387 1692">型号: _____</div> <div data-bbox="2097 1727 2387 1754">检验员: _____</div> <div data-bbox="2097 1788 2387 1818">出厂日期: _____</div> <div data-bbox="2242 1707 2349 1793"> </div>
翻页器:	遥控器:													
电池容量: 200mAh	电池容量: 30mAh													
充电输入: 5V	充电输入: 5V													
充电时间: 约1.5小时	充电时间: 约30分钟													
充电方式: USB-C	充电方式: USB-C													
<div data-bbox="142 1990 504 2030">WIRELESS PAGE TURNER</div> <div data-bbox="407 2050 517 2082">JX-07</div> <div data-bbox="191 2106 430 2358"> </div>	<div data-bbox="601 1976 830 2005">Specification parameters</div> <table border="1"> <tr> <td>Page flipping device:</td><td>Remote control:</td></tr> <tr> <td>Battery capacity: 200mAh</td><td>Battery capacity: 30mAh</td></tr> <tr> <td>Charging input: 5V</td><td>Charging input: 5V</td></tr> <tr> <td>Charging time: about 1.5 hours</td><td>Charging time: about 30 minutes</td></tr> <tr> <td>Charging method: USB-C</td><td>Charging method: USB-C</td></tr> </table> <div data-bbox="601 2151 756 2180">Product Diagram</div> <div data-bbox="601 2202 1011 2397"> </div>	Page flipping device:	Remote control:	Battery capacity: 200mAh	Battery capacity: 30mAh	Charging input: 5V	Charging input: 5V	Charging time: about 1.5 hours	Charging time: about 30 minutes	Charging method: USB-C	Charging method: USB-C	<div data-bbox="1070 1976 1192 2005">Instructions</div> <div data-bbox="1082 2020 1480 2106"> </div> <div data-bbox="1070 2121 1480 2392"> <ol style="list-style-type: none"> <li>1. Click the page turning button (the page turning indicator light is on)</li> <li>2. Pairing operation: Click the remote control button (page turning indicator light flashes)</li> <li>3. Clip the page flipping device to one side of the Kindle, press the remote control function button, and you can flip pages normally (if you have purchased a version with two clips, plug in the remote control machine to charge, long press the defined button for 3 seconds, the indicator light will flash white, and the auxiliary machine function keys are defined, then you can clip them on both sides to flip pages at the same time)。</li> <li>4. Switch the remote control back to the original mode and perform the same operation. Plug in the remote control to charge, press and hold the defined button for 3 seconds, the indicator light will flash red, and the setting is complete.</li> </ol> </div>	<div data-bbox="1541 1976 1747 2005">Function Description</div> <div data-bbox="1541 2020 1964 2160"> <ol style="list-style-type: none"> <li>1. Page flipping and remote control, the charging status indicator light flashes, and the fully charged status indicator light stays on.</li> <li>2. If the remote control is not used within 30 minutes, the page flipping device will automatically turn off. The remote control and page flipping indicator lights will flash once every operation</li> </ol> </div> <div data-bbox="1541 2192 1602 2217">warn</div> <div data-bbox="1541 2237 1928 2323"> <ol style="list-style-type: none"> <li>1. After long term storage, please use it after charging.</li> <li>2. The product is not waterproof. Do not use it in extremely cold, hot or humid environments.</li> <li>3. Do not use the receiver roughly to avoid damaging it.</li> </ol> </div>	<div data-bbox="2023 1963 2446 2392"> <p><b>FCC Caution:</b> This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.</p> <p>This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.</p> <p>If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> <li>— Reorient or relocate the receiving antenna.</li> <li>— Increase the separation between the equipment and receiver.</li> <li>— Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.</li> <li>— Consult the dealer or an experienced radio/TV technician for help.</li> </ul> <p>The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</p> </div>
Page flipping device:	Remote control:													
Battery capacity: 200mAh	Battery capacity: 30mAh													
Charging input: 5V	Charging input: 5V													
Charging time: about 1.5 hours	Charging time: about 30 minutes													
Charging method: USB-C	Charging method: USB-C													