

63mm



规格参数


按键功能说明



使用苹果手机/平板时,请注意以下几点:

- 1.确保手机/iOS软件为14.8以上
- 2.苹果手机/需打开手机“设置”-“辅助功能”-“缩放”-“打开缩放”,开启缩放功能后屏幕将会放大,三指轻点两下,屏幕恢复至正常显示状态,即可使用
- 3.以上2项如果确认OK, 还是不能正常使用请把手机关机再开机一次

充电显示:充电时闪红灯,充满长亮蓝灯。



出厂日期: _____



Specifications

Button function description

The default first mode of power on:



Second mode: Photo taking and slow up and down sliding function indicator of pulley

Second mode: Photo taking and slow up and down sliding function indicator of pulley

The roller slides up and down slowly

Click to fine-tune and increase the focal length.
Press long to slowly increase the focal length

Click to take a photo and double-click to return to the main page


Click to fine-tune and reduce the focal length.
Press long to slowly reduce the focal length

Click "Photo Aggregation" and double-click to switch between the front and rear cameras

When using an iPhone/tablet, please note a few things:

1. Ensure that the iOS software of the mobile phone is 14.8 or higher
2. Apple phone/Open the "Settings", "Auxiliary functions", "Zoom" and "Open Zoom" of the phone. After the zoom function is enabled, the screen will become larger
3. If the above two items are OK and still cannot be used normally, please turn off the phone and turn it on again

Charging display: Red light flashes when charging, and blue light remains on when fully charged.



The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.