
128克8页7折 正面

LED projector



Attention

supervision of adults.

Please read this manual carefully before use and keep it for future reference.

1. The projector is non dustproof or waterproof. 2.In order to reduce the risk of fire and electric shock, do

not expose the projector to rain and fog. 3. Please use the original power adapter. The projector

should work under specified rated power supply.

4. When projector is working, please do not look directly into the lens, the strong light will flash your eyes and cause slight pain. Children should use the projector under the

5.Do not cover the vents of projector. Heating will reduce the life of projector and cause danger.

6. Regularly clean projector vents, or dust may cause cooling malfunction.

7.Do not use the projector in greasy, damp, dusty or smoky environment. Oil or chemicals will cause malfunction.


8. Please handle with care during daily use.


9. Please cut off the power if the projector is out of use for long time.


10. Non-professionals are forbidden to disassemble the projector for testing and maintenance.

Structure description


This manual is for reference only. It is subject to change without prior notice. Hotack reserves the right of final







Remote Component and Functions



Switch in the Applications

Click on"My apps"to view installed programs, click program icon to switch

between applications.

Move to "My Apps", click OK to enter. All Apps' can be clearly distinguished from the icons.



Settings

Enter to setup Networking, Bluetooth, Language, Other Setting, Projection, Audio, Date And Time



Networking Setting

Settings - Networking Setting - WIFI setting, WIFI "ON", select objective WIFI ID and input password to connect internet.



Bluetooth Setting


Settings - Bluetooth setting, Bluetooth "ON", click Refresh Device and choose objective device to pair.



8页7折 反面

Language Setting

Settings - Language Setting, enter to setup language and



Other Setting

Setting - Other Setting, enter to get Application setting, Factory Reset Setting, and Developer opinions.



Projection Setting

Setting - Projector setting, enter to setup projection mode, keystone correction.



Audio Setting

Setting - Audio setting, enter to adjust volume.



Date And Time Setting

Setting - Date And Time Setting, enter to setup timezone, timeformat, dateformat, date and time.



After connecting projector to other output device, enter HDMI or Audio/Video.




Miracast

Ensure that Android devices(phone,pad,ect)are in the same local wireless LAN with these devices

Home Screen→My Apps→Miracast→Open miracast service→
Turn on the phone mirroring→Connection



Operations Android phone devices




Airplay

Ensure that Apple devices(iphone,pad,ect)are in the same local wireless LAN with these devices

Operations on Devices: Home Screen→My Apps→ Air pin→Open Air pin service→ Turn on the phone mirroring



Operations iphone devices



Safety instructions

- Please pay attention to important information related to the operation and maintenance of the projector. You should read this information carefully to avoid problems. Following safety instructions will increase the life of projector.
- Please consult the qualified personnel for installation and repair services, and do not use damaged wires, accessories and other peripherals.
- Projector should be kept away from flammable, explosive, strong electromagnetic interference (large radar stations, power stations, substations) ,etc. Strong ambient light (avoid direct sunlight), etc.
- Do not cover projector vents.
- Please use the original power adapter.
- Keep adequate ventilation and make sure vents are not covered to avoid projector overheating
- When projector is working, please do not look directly into the lens, the strong light will flash your eyes and cause slight $% \left(1\right) =\left(1\right) \left(1\right) \left($
- Do not bend or drag the power cord.
- Do not put power cord under projector or any heavy objects.
- Do not cover other soft materials on power cord.
- · Do not heat the power cord.
- Avoid touching power adaptor with wet hands.

This manual is general instructions, The pictures and functions in this manual should subject to the actual product. Our company is devoting to improve product performance, we reserve the right to modify product functions and interface described in this manual without notice.

Please keep your device properly. We are not responsible for any loss caused by wrong operation of software/hardware or repairing or any other reasons. We are not responsible for any loss of any third party claims.

This manual has been carefully checked by professional engineer, please understand for any inevitable omissions.

FCC Statement



Please do not look directly into the lens when projecting to prevent the strong light doing harm to your eyes. Kids should use the projector under the supervision of adults.

