


POWERQI 产品配色与工艺说明图 Product Colour, Material & Finishing Specifications					
Product Model 产品型号	QIC-301	Brand 品牌		Job No. 图档编码	3-608Q3010602B0001
Product Type 产品类	说明书	Description 描述	/	Revision 版本号	QH-SMS-24016 V1.0(QIC-301- CO04)
Dimension 尺寸	76*105mm	Original Designer 原设计师		Date 日期	
Scale 比例	1:1	Technology 工艺	128g哑粉纸 四色印刷	Verifying 审核	



GRINDER



Shenzhen Cospro Technology USA Inc

Thanks for choosing us!

Important Safety Information Inside, Read all instructions before using. Use only as directed. Save these instructions, This product is designed for household use only.

ELECTRICAL REQUIREMENTS

Model: QIC-301
Compatible charger.
Input : AC100-240 Volts 50/60 Hz
Cordless Grinder.
Voltage: DC5 volts.
NOTE: If the plug does not fit fully in the outlet, contact a qualified electrician. Do not modify the plug in any way.

LITHIUM-ION BATTERY OPERATED PRODUCT DISPOSAL
Always dispose the battery operated products according to the federal, state, and local regulations. Contact a recycling agency in your area for recycling locations.

Getting Started
BEFORE FIRST USE
1. charge the battery until the battery status indicator turns solid green.
2. clean all the parts and accessories.
3. Remove all the packaging materials if present.

FCC ID: 2BGC6-QIC301
Radiated H-Field:-20.96 dBuA/m (@10m)
TX/RX Frequency Range :110-148kHz(Only for EU&UK)

BATTERY STATUS

Battery status	%Battery status
4 white	81% to 100%
3 white	61% to 80%
2 white	41% to 60%
1 white	21% to 40%
1 white flash	Less than 30% (nee to charge soon)




A single cordless grinder is fully charged within 2.5 hours. When charging, the grinder base indicator light breathes, the grinder battery status indicator light flows, and when fully charged, the base light stays on and all indicator lights of the grinder go off. According to the recommended battery maintenance, the cordless grinder will produce 70g of pepper powder and grind for 40 minutes when fully charged, using the thinnest level of white pepper as the standard.

Note: The cordless grinder will automatically charge when placed back on the base, ensuring that the battery is charged when a battery status indicator light flashes.
There should be no metal objects on the base of the wireless charger, otherwise it will affect charging efficiency or safety. It is best to store the cordless grinder at room temperature. When the device is charging, the automatic locking program will be enabled to prevent


BATTERY CHARGING

1. Release the charging cable to the appropriate length.
2. Plug the charging cable pins into the charging port.
3. Plug the charging adapter into a grounded power outlet.
4. The base indicator light is always on. Place the grinder on the base, and when the base breathing light is on and the grinder power indicator water light is on, it indicates that it is charging. After all batteries are fully charged, the grinder's power indicator light goes out and the base indicator light stays on.




HOW TO USE

- ① Open the container according to the indication icons Fill salt or pepper into container connect and lock the upper.
- ② Rotate the adjuster to adjust the grinding coarseness according to personal needs.
*Please make sure you screw it tightly and align the inverted triangle with the icon below, otherwise the bottom light may not be on.
- ③ Press the button and the grinder will start working. Release the button and the grinder stops working.



- ④ Use the included brush to clean the residue from the bottom of the product.
- ⑤ Remove the pull groove in the middle of the base to clean the excess residue.



IMPORTANT SAFE GUIDE

When using electrical appliances, basic safety precautions should always be followed :

- .Do not put the appliance in water or any othel liquid, this may cause personal injury and/or flammable fumes.
- .To protect against fire, do not operate the unit in the presence of hazardous materials and/or extreme temperatures.
- .Do not use the grinder for anything other than for its intended use.
- .For indoor use only. Do not expose this product to rain or other extreme conditions.
- .Never force the grinder to tighten or twist it or attempt to speed up the mechanism.
- .Do not attempt to disassemble the product by yourself, otherwise warranty will be invalid.
- .When recharging the electric grinder, please keep your workspace free from potential hazards.
- .The product is designed for grinding pepper and salt only, please do not use for other purposes.
- .Keep the grinder out of the reach of children.

FCC Warning

TThis device complies with part 18 of the FCC Rules.
Information on the following matters shall be provided to the user in the instruction manual or on the packaging if an instruction manual is not provided for any type of ISM equipment:

(a) The interference potential of the device or system

(b) Maintenance of the system

(c) Simple measures that can be taken by the user to correct interference.

FCC RF exposure statement:
The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance between 20cm the radiator your body.

EU-
This device in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. All essential radio test suites have been carried out. This restriction will be applied to all Member States of European Union.

1.The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.
2.. The device complies with RF specifications when the device used at 20cm form your body.

Declaration of Conformity
Hereby, Shenzhen Cospro Technology USA Incdeclares that the product type QIC-301 is in compliance with Directives 2014/53/EU & 2011/65/EU.
The full text of the EU declaration of conformity is available at the following internet address: <https://www.cospro-usa.com/>