

## FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by one or more of the following measures:  
—Reorient or relocate the receiving antenna.  
—Increase the separation between the equipment and receiver.  
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
—Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance; such modifications could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. This equipment complies with FCC's RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or conjunction with any other antenna or transmitter.

## MILITARY-GRADE OUTDOOR AUDIO

SMART WIRELESS CHARGING BLUETOOTH SPEAKER



## Indicator Lights

Startup: red,  
Paired successfully: blue breath lamp.  
Connected successfully (Bluetooth playback):  
blinking blue light.  
When charging: the blue light flashes.  
Full time: keep the blue light on.  
Sound effects / EQ:  
indoor/blue light, outdoor/red light, movie / green

## Product Charging

Please use the included charging cable to charge the speaker. Plug the Type-C end of the charging cable into the charging port of the speaker, and then plug the USB end into a suitable charging adapter (e.g., 5V/9V-1A-2A). The battery indicator will light up when the speaker is in the process of recharging.

## Precautions

The battery protection system is equipped to prevent instances of overcharging and over-discharging. Proper use of the battery may prolong the lifespan. Before using the speaker, the battery should be completely charged so that it can provide the best possible performance.

6

## Warranty

This warranty provides coverage for the product that exhibits defects under normal use within one (1) year from the date of purchase. However, it does not cover damage resulting from the following:  
1. The incorrect or improper use of, maintenance on, or connection for charging to an unsuitable voltage source or power supply;  
2. Accidents or damage caused by liquid exposure;  
3. Improper packing;  
4. Damage caused by accident, misuse, unauthorized maintenance, alteration, or disassembly.

## Care and Maintenance

1. Please take proper care of the speaker and its accessories and use them in a clean environment.
2. Prevent any contact of the speaker and its accessories with a flame or a lit cigarette.
3. Keep the speaker and its accessories dry. Avoid exposure to water and moisture.
4. Do not tread on, toss, or drop your speaker in any way.
5. When cleaning and wiping your speaker, please use an antistatic microfiber cloth. Never use any abrasives, chemical substances, or chemical solutions.
6. Do not place the speaker and its accessories in areas where the temperature is either too hot or too cold.
7. Do not dismantle the speaker without proper authorization. Otherwise, your entire warranty will be voided.

7

hapyia-s3



SMART WIRELESS CHARGING BLUETOOTH SPEAKER

Bluetooth 5.1 | Smart Wireless Charging PX67 Waterproof Speaker  
Hi-Fi Audio | Hands-free Calling | 3 Different Sound Effects

159mm (6.25in)

159mm

## Underside

## Echo wall state



Product Name: Portable Waterproof Outdoor Bluetooth Audio  
Product brand: hapyia  
Product model: S3  
Bluetooth version: 5.1  
Battery capacity: 10000mAh lithium battery  
Service time: about 41h  
Response frequency: 20Hz-20KHz  
Output peak value: 30W  
Product size: 8.62in\*3.59in\*3.71in  
Product weight: 994g  
Supported devices: laptops, iPads, computers, mobile phones  
Function description:  
1. Ultra heavy low-frequency stereo audio performance  
2. IPX7 waterproof, shockproof and dustproof design  
3. Strong sound effect, shocking clarity and deep bass effect  
4. Intelligent operating system enables you to select music and answer phone handsfree

## Bluetooth Connection

Press and hold the "Power" button to turn on the speaker, and then open up your smartphone settings. (NOTE: Bluetooth mode is always on by default.)



2. Enable Bluetooth on your smartphone and let it automatically search for the speaker.



3. Just tap on the name "HAPYIA S4" for connection.



You may now enjoy your favorite tunes! If you leave it idle for more than 10 minutes, it will automatically shut down.

2

## TWS Pairing

Pair Speakers in TWS mode:  
After turning on two S3 speakers, choose either one of them and then press the "Connect" button. When the prompt tone is heard, it indicates that the TWS pairing is successful.

Turn off TWS:

Press and hold the "Connect" button on either speaker to disable the TWS function. To reconnect two speakers to TWS, briefly press the "Connect" button.




## Wireless Charging

Just give the "Power" button a quick press when you are using wireless charging. Once the indicator light turns red, line up the middle of your smartphone with the charging center on the speaker and place it down. Your smartphone is now being charged wirelessly, and the charge status will be displayed on the phone.

3

## Key Description



## Key operation

- ① Power On/Off  
Introduction to the icons on buttons  
Press and hold: Power on/off
- ② Indoor/Outdoor/TWS Pairing  
Press briefly to alternate between three distinct sound effects: indoor, outdoor, and movie.  
TWS Press and hold the button to disconnect
- ③ Answer calls/Hang up / Recent calls  
Press: Answer/Hang up  
Press and hold: Reject/Voice assistant
- ④ Volume +/Volume -  
Press: Volume +  
Press and hold: next track
- ⑤ Volume -/previous track  
Press: Volume -  
Press and hold: Previous track
- ⑥ Disconnect Bluetooth/Music Play/Stop  
Press and hold: Disconnect Bluetooth  
Press: Music play/stop

4