



1 Photo documentation of the EUT

1.1 Scale



1 box ≅ 10 cm x 10 cm



or
1 box ≅ 1 cm x 1 cm


1.2 Internal views

Open housing




The test report merely corresponds to the test sample. It is not permitted to copy extracts of these test results without the written permission of the test laboratory.

Top view of the Processor-Board PCB




The test report merely corresponds to the test sample. It is not permitted to copy extracts of these test results without the written permission of the test laboratory.

Bottom view of the Processor-Board PCB




The test report merely corresponds to the test sample. It is not permitted to copy extracts of these test results without the written permission of the test laboratory.

Top view of the Power-Supply PCB



The test report merely corresponds to the test sample. It is not permitted to copy extracts of these test results without the written permission of the test laboratory.

Bottom view of the Power-Supply PCB



1.3 Internal views – Antenna

Antenna positions inside the equipment



The test report merely corresponds to the test sample. It is not permitted to copy extracts of these test results without the written permission of the test laboratory.


Top view of the Valve-Drive



Top view of the antenna module



Inside view of the antenna module



- End of Attachment B -