

# Operating instructions for spray stunt elf remote control vehicle

## 喷雾遥控车操作说明书 (NO. S664)

To ensure proper use, please read the instructions below and have a good understanding of the products before use. 为确保正确使用，请在使用前阅读以下说明并充分了解产品。

### Electric Control Products:

Suitable for children over years old.

All electronic products should be carefully used to prevent electric shock.

### 电控产品:

适合6岁以上儿童使用。

所有电子产品应小心使用，以防触电。

### Maintaining:

This product contains electronic components.

Don't use it in water or damp environment. Wipe the surface with cloth.

1. Set the switch on the OFF position of the car and the remote control. (if switch is available)

2. Use a cross head screwdriver to open the battery cover

3. Install the rechargeable battery pack according to the figure below, and install the battery according to the corresponding "+" and "-" poles in the battery box

4. Close the battery case and tighten it with cross head screws.

### 产品维护:

本产品含有电子元件。

不要在水或潮湿的环境中使用。用布擦拭表面。



1. 将开关置于车和遥控器的OFF位置。（如果有开关）

2. 用十字头螺丝刀打开电池盖

3. 按下图安装可充电电池组，按电池盒内相应的“+”和“-”极安装电池。

4. 关闭电池盒，用十字头螺钉拧紧。

### DESCRIPTION TO THE FUNCTIONS OF REMOTE CONTROL 遥控器功能说明



Note: The remote control must be turned off when using the watch remote control, both remote controls cannot be used at the same time.

注意: 使用手表遥控器时必须关闭遥控器，两种遥控器不可同时使用。

### OPERATIONS OF REMOTE CONTROL AND CARS 遥控器和遥控车的操作

1. Turn the switch on the car and remote control to "ON" position. (if switch is available)


2. Then, operate the car.

3. When your car starts to lose performance, power, or function, it may be time to replace the battery or charge the battery pack.

1. 将汽车和遥控器上的开关转到“ON”位置。如果有开关）

2. 然后，操作汽车。

3. 当你的汽车开始失去性能，动力或功能时，可能是时候更换电池 或为电池组充电了。



### ⚠ Note: ⚠ 注意:

When the remote control cannot control the remote control car, first remove the battery of the remote control and re-install the battery, then turn off the power of the remote control car, then turn on the power, and then the remote control resets the frequency.


当遥控器无法控制遥控车时，应先卸下遥控器电池重新安装电池，然后关闭遥控器电源，再打开电源，遥控器复频。

### Forward/Backward

#### 前进/后退

Operate the "Forward/Backward" button to control the vehicle to make forward and backward movement.

操作“左前/右前滑行”按钮，遥控车向左前/右前滑行。




### Left Forward/right forward Side-slip

#### 左前/右前滑行

Operate the button of "Left Forward/Right Forward Side-slip" the remote control car drift to the left front/the right front.

操作“左前/右前滑行”按钮，遥控车向左前/右前滑行。




### Left Sideways/Right Sideways

#### 左侧横行/右侧横行

Operate the button of "Left Sideways/Right Sideways" the remote control car drift to the left/right.

操作“左侧横行/右侧横行”按钮，遥控车向左/向右漂移。



### Watch remote control operation

#### 手表遥控器操作

Operate the following action to control the remote control car.

操作如下图动作，可以控制遥控车。



### Rotate Left/Right For 360-Degree

#### 向左/向右360度旋转

Operate the button of "Rotate Left/Right For 360-Degree", the remote control car rotates 360° to the left/360° to the right.

操作“前进/后退”按钮以操作遥控器的“向左/向右旋转360度”按钮控制车向左旋转360° / 向右旋转360°。控制车辆前进和后退。




### Left/Right Forward Turn、Left/Right Backward Turn

#### 左/右前转、左/右后转

Operate combined rocker "Left/Right Forward Turn、Left/Right Backward Turn", the remote control car turns left front、right front、turns left behind / right behind.

操作组合腰杆“左/右前转、左/右后转”，遥控车左前、右前、左后/右后转弯。




### One-key Demonstration

#### 一键演示

Operate the "One-key Demo" button to demonstrate the automatic stunt of the remote control vehicle.

操作“一键演示”按钮自动演示遥控车的特技。



**FCC Warning:**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.