


尺寸:70*72*15mm
材质:250单粉对裱250单粉+哑胶+V槽



TX15说明书 128g双铜双面 4色 风琴折 折后尺寸60*60mm

<p>GUO-LINK</p> <p>VISION TAG</p> <p>USER GUIDE</p> <p>正面</p> <p>Works with Apple Find My</p>	<p>Overview introduction</p> <p>Vision tag integrates with Apple Find My Network, providing a secure and user-friendly solution for finding belongings. It effortlessly locates keys, wallets and more using Apple Find My Network, prioritizing security. Designed for user convenience, Vision tag simplifies daily life. Say good bye to lost items with Vision tag and Apple Find My Network, experiencing a future of enhanced item finding and peace of mind. Trust Vision tag to redefine how you manage essentials effortlessly.</p> <p>How To Pair</p> <p>Note: iOS or macOS with the latest version.</p> <p>(Figure1) (Figure2) (Figure3)</p> <p>1.1 Place the Vision tag next to your Apple device like iPhone. 1.2 Turn on bluetooth on iPhone and connect to Internet. 1.3 Press the finder front button hear one beep to power on.</p>	<p>1.4 Open the 'Find My' app. 1.5 In 'Find My' app, tap '+', then 'Add Other Item'. As shown in Figure 1. 1.6 Once your Vision tag is located, tap 'Connect'. As shown in Figure 2. Enter a name and choose an emoji for your Vision tag and tap 'Continue'. As shown in Figure3. 1.8 Find My will ask for confirmation to add your Vision tag to your Apple ID. Tap 'Agree'. 1.9 Tap 'Finish' and your Vision tag will be set up already to be used.</p> <p>Battery</p> <p>Vision tag Contains a coin shaped battery. During the product's lifespan, it may be necessary to replace the battery. By observing the correct negative and positive connections, only replace batteries of the same type (CR2032) and rating.</p> <p>Battery replacement</p> <p>2.1 Pry off the back cover. 2.2 Replace a new battery. 2.3 Close the back cover.</p> <p>Additional Tips</p> <p>3.1 To switch from active mode to disable mode (airplane mode), simply remove the battery.</p> <p>3.2 To switch from disable mode (airplane mode) to working mode, reinstall the battery any Vision tag will be successfully paired after this. 3.3 Press and hold the button until you hear 1 prompt tone, followed by 2 consecutive prompt tones, and then 3 consecutive indicator tones. Continue to press for 5 seconds. When you hear a long indicator tone, release the button to restore the device to its factory settings. 3.4 To remove the Vision tag from your Apple devices, open the 'Find My' app, select 'Items', find the device, and scroll down to click on 'Remove this device'. 3.5 If the Vision tag fails to connect to the 'Find My' app, follow the instructions in section 3.3 to perform a factory reset, and then restart the pairing process.</p> <p>Important matters</p> <p>Vision tag contains delicate electronic parts, including a battery to avoid damage, loss of function, or potential harm. Please refrain from dropping, hitting, puncturing, crushing, disassembling, exposing it to extreme heat or liquids, or placing it in areas with a high concentration of industrial chemicals.</p>	<p>WARNING: Do not swallow the battery; There is a chemical burn hazard.</p> <p>Choking Hazard Warning</p> <p>Vision tag, its battery compartment door, the battery itself, and the case may pose a choking hazard or cause injury to small children. Please keep these items out of reach of young children.</p> <p>Medical Device Interference</p> <p>Vision tag contains components and radios that emit electromagnetic fields, as well as magnets. These elements may potentially interfere with pacemakers, defibrillators, or other medical devices. To ensure safety, maintain a safe distance between your medical device and Vision tag. We strongly advise consulting your physician and the manufacturer of your medical device for information that is specific to your situation. If you suspect that Vision tag is interfering with your pacemaker, defibrillator, or any other medical device, discontinue its use immediately.</p> <p>Important Handling Guidelines</p> <p>Vision tag is normal for Vision tag to show discoloration with regular use. To clean it, use a soft, dry, lint-free cloth. Avoid applying</p>
--	--	--	---

<p>GUO-LINK</p> <p>VISION TAG</p> <p>使用说明书</p> <p>反面</p> <p>Works with Apple Find My</p>	<p>概述介绍</p> <p>FINDER与苹果的Find My网络集成, 为追踪物品提供了一个安全且对用户友好的解决方案。使用 Find My 网络轻松定位钥匙、钱包等, 并优先考虑安全性。FINDER专为方便用户而设计, 简化了日常生活。使用FINDER和苹果的Find My网络告别丢失物品, 体验查找物品更便捷、更安全的生活。相信FINDER能重新定义您管理重要物品的新方式。</p> <p>如何配对</p> <p>注:请使用iOS或者macOS最新版本。</p> <p>(1) (2) (3)</p> <p>1.1将FINDER放在您的苹果设备(如iPhone)旁边。 1.2在您的苹果设备(如iPhone)上打开蓝牙并连接到互联网。 1.3按一下FINDER按钮, 听到一声蜂鸣声即可开机。</p>	<p>1.4 打开“查找”应用程序。 1.5 在“查找”应用程序中, 点击添加物品-其他支持物品。如图1所示。 1.6 点击“连接”。如图2所示。 1.7 命名您的FINDER, 并选择一个表情然后点击“继续”。如图3所示。 1.8 询问是否将FINDER添加到您的Apple账号, 点击“同意”。 1.9 点击完成即可添加成功。</p> <p>电池</p> <p>FINDER包含一个硬币形状的电池。在产品使用寿命期间, 可能需要更换电池, 通过观察正确的负极和正极连接, 只能更换相同类型(CR2032)和额定值的电池。</p> <p>电池更换:</p> <p>2.1: 拆开后盖。 2.2: 更换新电池。 2.3: 关上后盖。</p> <p>其他提示</p> <p>3.1要从工作模式切换到禁用模式(飞行模式), 只需卸下电池即可。 3.2要从禁用模式(飞行模式)切换到工作模式, 请重新安装电池。</p>	<p>池。在此之后, FINDER将成功配对。</p> <p>池。在此之后, FINDER将成功配对。</p> <p>窒息危险警告</p> <p>FINDER、电池舱门、电池本身和外壳可能会造成窒息危险或对幼儿造成伤害。请把这些东西放在小孩子够不着的地方。</p> <p>医疗设备干扰</p> <p>FINDER包含发射电磁场的组件和无线电。这些元件可能潜在干扰起搏器或其他医疗设备。为确保安全, 请在您的医疗设备和FINDER之间保持安全距离。我们强烈建议咨询您的医生和医疗设备制造商, 以获取针对您具体情况的信息。如果您怀疑FINDER干扰了您的起搏器或任何其他医疗设备, 请立即停止使用。</p> <p>重要处理指南</p> <p>FINDER在正常使用时出现变色是正常的。要清洁它, 请使用柔软、干燥、无绒布。避免用尖锐物体对设备内部的橡胶密封件或蓄电池触点施加压力。</p> <p>法律公告</p> <p>使用Works with Apple Find My徽章意味着产品已被设计为专门与徽章中确定的技术配合使用, 并已通过产品制造商的认证。</p>
--	---	---	--

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.