


Multi-Function Wireless Charger

Aroma Diffuser



User Manual

To ensure the correct use of the product, please read this user manual carefully

Aroma Diffuser Operation Guide

•Switch Button:


First time short press the switch button, turn on the continuous spray.
Second time turn on the intermittent spray.
Third time turn off the spray.

•Light Button:

First time short press the light button, turn on gradient lights.
Second short press switches to a fixed light color, with each press switching the light color until the light is turned off.

•**Protection Function:** Built in water shortage protection chipset, automatically stop working after detecting the water tank without water.


Product Operations




1. Open the upper cover



2. Add appropriate amount of water to the water tank




3. Insert the power



4. Touch the switch button to turn on the device

Clock Operation Guide



12 Hour Clock/24 Hour Clock Time Setting Button

Press and hold the icon once for 3 seconds to switch between 12-hour and 24-hour time. When the time is in 12-hour format, the AM/PM icon is displayed on the left side of the screen. Press and hold the icon again for 3 seconds, AM/PM will disappear and the time will switch to 24-hour format.

Alarm Time Setting Button

Press the icon for 3 seconds, the clock screen will flash quickly (currently is hour setting), click the icon continuously to set hour, after confirm the hour, soon press and hold the icon for 3 seconds, the minute screen will flash quickly (currently is minute setting), click the icon continuously to set the minute time, after confirm the minute, release the button and wait for 5 seconds after the beep sound, the alarm icon light will light up, and the alarm clock setting is completed.
Cancel the alarm is to press the icon for 3 seconds, the light of the alarm icon will turn off and with beep.
Click any icon to cancel the ring for the day.

(If there is no need to set the minute time, stop touch the button after confirm the hour time)

Local Time Setting Button

Press the icon for 3 seconds, the clock screen will flash quickly (currently is hour setting), click the icon continuously to set hour, after confirm the hour, soon press and hold the icon for 3 seconds, the minute screen will flash quickly (currently is minute setting), click the icon continuously to set the minute time, after confirm the minute release the button to complete the local time setting.

* Alarm clock notice: Adjust the alarm time according to the PM/AM icon when the time is 12-hour format.

Product Specification

Material: ABS/PP

Voltage: 12V

Power: ≤ 24W

Frequency: 2.4MHZ

Capacity: 150ml

Atomization Amount : 25mL/hr

Standard: GB4706.1-2005

GB4706.48-2009

Origin: Shenzhen, China

Wireless Charging :

Available for all devices which support Qi standard smartphones and devices

Power: 10W

Charge Distance: 4-6 mm

Charge Method: Electromagnetic induction

Product Contents

Product x1, Power Adapter x1, User Manual x1

Note

• The maximum water volume of the water tank is 150 ml, and the water injection volume shall not exceed the maximum water level indication line, otherwise the atomization effect will be affected or water leakage will cause damage to the machine

• Please fill the atomizer with pure water to avoid impurities in the water causing damage to the atomizer function and shortening its service life.

• During operation, the sound inside the water tank is the sound of atomization, which is a normal phenomenon.

• Do not roll or shake the product at work, otherwise it may cause damage.

Product Maintenance

1. When the product is not in use, turn off the product switch and disconnect the power supply.
2. Correctly pour the right amount of water into the water tank.
3. Please use soft cotton to wipe the water on the water tank and cover.
4. Please wipe the atomizer gently with cotton.
5. It is recommended to clean the product regularly.

If you feel that there may be something wrong with this product, please confirm the following points before asking us for repair:	
As soon as you turn on the switch. Less than a second. The incense machine will immediately. Automatic shutdown,	<ul style="list-style-type: none">● Please make sure there is water in the tank. Or is there enough water? --Please add water to the container.● Is the AC adapter properly connected to this product? --Please make sure that this product is fully connected to the adapter. Please unplug the charging wire and plug from this product again and plug in this product again.
No spray or. Spray anomaly	<ul style="list-style-type: none">● Is there too little water in the container? Or too much? --If there is not much water, please add water, and if the water exceeds the water mark, please pour out some of the water.● Is the ultrasonic atomization tablet defiled? --Please clean the atomization port in the container (wipe with a soft brush)● Is the suction port at the bottom covered with dust? --If the air intake at the bottom is covered with dust, the exhaust air volume will be greatly reduced, thus. As a result, there is not enough wind to spray the fog.
Aromatherapy machine leakage	<ul style="list-style-type: none">● Is the upper cover covered (coincident)? -- reinstall the upper cover● Is the water sprinkled into the air outlet when the product is tilted or poured? Please pour all the water out of the machine, then try hard to get rid of the moisture inside, then dry it and try again.

Use requirements.

1. This product is suitable using clean water or pure water, Do not use corrosive liquids.
2. If the operation is not correct, the water may leak into the main engine. If in that case, please unplug the power immediately, pour out the water, clean the device and leave it in a ventilated place for about 3 days, let it dry naturally before use it. If there is any other abnormal situation, please contact the local dealer or contact us directly.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Radiation Exposure Statement

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment.

The FCC certification of this device refers to RF exposure testing performed in typical operating conditions, where a person is no closer than 20 centimeters from the device surface at all times, except for non-repetitive patterns with transient time intervals in the order of a second. Only in the stated conditions, the device is shown to fully comply with the FCC RF Exposure requirements of KDB 447498.