

## barber case with bluetooth



### User Guide For Adjustable Stand

1. Open case to get four adjustable stands and stretch them.
2. Rotate the stand clockwise to place and make sure it is tightly attached to the bottom of the case without any shaking. Loosen the screw rings at one end of the stand by unscrewing it counter-clockwise.
3. Press the two height adjusted buttons located at upper part of the stand and stretch out the lower part of it simultaneously so as to adjust the stand to the right height, tighten the screw rings at the middle of the stand by screw down them clockwise.
4. Repeat steps 2-3 so as to make sure four support stands are of exactly the same height.
5. Lift up the case and make sure four support stands on the door evenly and steadily .

### Instructions For Locks And Bluetooth

6. Code to connect with the "MANE TAME" bluetooth:-0000,1234,2288 or 000000
7. Slide the resetable button from "OFF" to "SET"
8. Dial your desired code numbers(e.g.,888)
- 9.Return the resetable button to "OFF"position.Your lock is now set with new code.

## **User Guidance For Light Bulbs And Plug Socket**

- 10.The product can be used in countries with voltage rated at 110-250V,maximum wattage is 500W.
- 11.In case of smoke or fire ,please don't pull the plug with hand if the cause of smoke or fire is unidentified .Power supply must be cut off by using insulator to unplug the product and then ask professional technician for help .
- 12.Do not shake the support stand or case body as the makeup case may fall down or get damaged or it may pose a risk to personal safety .
- 13.You cannot reset the combination if the case is locked.Please select a memorable code,write it down and /or take a picture and store in a safe place to avoid getting locked out.

Please contact vendor in time if you have any questions regarding the use of the product.Thanks for your cooperation!

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### FCC Radiation Exposure statement

The device has been evaluatec to meeel general RF exposure requirement. The device can be used in porlable exposure condition without restriction.