











How to Pair with the App

1. Open the "Gosund" app and create your Gosund account.

2. Turn on the switch and place it near the router when pairing.

3. Hold the ON/OFF button for 5 seconds and release it when the switch starts to blink slowly to enter the network pairing mode.

Connect your phone to the Wi-Fi router, and click the "+" at the top right corner of the homepage to add a device.

You can add a device in two ways

You can add a device in two ways.

1)Bluetooth Auto-Discovery Mode (Recommended)
The app will suggest you turn on Bluetooth and Wi-Fi on your phone, and then select the device you want to add. Enter your Wi-Fi name and Wi-Fi password (supports 2.4G Wi-Fi only), and it will automatically connect to the network.

2)"Slow Flash" Mode (AP)

2)"Slow Flash" Mode (AP)

If Bluetooth networking fails, you can try AP networking mode.

Select "SW19" under "Electrician", enter your Wi-Fi name
and Wi-Fi password (supports 2.4G Wi-Fi only), choose "Slow
Blink" to ensure the LED indicator blinks slowly, connect your
phone to the device hotspot: "SmartLife-XXXX", then return to
the app interface, it will automatically connect to the router,
completing the configuration.

-12-

Ponet

Turn on the power, hold the Reset button for 5 seconds , and let it go when the Switch starts to flash slowly, the reset is successful.

When the Switch is in a new network environment, you need to restore the factory settings, and then reconnect to

Warnings and Precautions

Keep it out of the reach of children and pets.

Do not use this product in humid environments or outdoors. It's for indoor use only.

Do not place this product near heating devices, like microwave ovens, stoves, or radiators.

Protect the product from extreme temperatures, direct sunlight, strong jolts, high humidity, moisture, flammable gases, vapors, and solvents.

Do not disassemble, modify, or repair your device, and ask for help from authorized professionals for device malfunction.

Do not use the device when it is malfunctioning or visibly damaged.

-13 -

Do not store the device for extended periods in poor ambient conditions.

Never use aggressive detergents such as rubbing alcohol or other chemical solutions because these could damage the casing or even impair the functioning of the product.

Note: The image shown in the manual is indicative only. If there is inconsistency between the image and the actual product, the actual product shall govern.

MADE IN CHINA 4.02.000.1092 v1.0

-14 -

CUCO 深圳市酷客智能有限公司

品牌名:GHome Smart 名称:SW19 说明书		制图人:解搏君		
型号: SW19	比例(1:1)	单位(mm)	业务审核:	
物料编码:4.02.000.1092	版本: V1.0	日期: 2024/4/12	产品审核:	
尺寸: 75X100mm 材质:105g哑粉纸/4C印刷/风琴折/白牌		领导审批: 戴站华		

2 3 4 5 6

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.

FCC ID: 2BGPL-SW19