


Wireless Karaoke speaker

User Manual



In order to better use the product performance, please read the user manual carefully. Note : Please make sure fully charge the ts before first use.

 Do not use quick-charge



Bluetooth Connection

Connecting Bluetooth of Mobile Phone

1. Turn on the speaker: long press the power on/off button for 2 seconds to turn on the speaker, and then Bluetooth indicator light will flash.

2. Bluetooth connection: Open the Bluetooth setting on the phone, choose the Bluetooth named "YEFNK" for paring , You can hear the prompt sound after connecting successfully.

3. Open the Karaoke APP to play music.

Note: Once your mobile phone has connected with the Bluetooth. It will be connected automatically next time because it has memory function. If you want disconnect the Bluetooth, please cancel paring in your phone setting

4. Bluetooth speakers can only be paired with one mobile phone at a time, and other mobile phones need to cancel the Bluetooth connection of the connected phone before connecting to Bluetooth.

Mic Operating Instruction

1. Turn on the microphone: Long press the power button for 2 seconds to turn on the microphone
2. The microphone will connected with speaker automatically, the blue indicator flashes mean the Bluetooth connected successfully.
3. Open your karaoke App or musical player and choose songs to sing. Keep the microphone and speaker within 10 meters, it will give better sound effects.
4. If you only want to use the speaker to listen music, please shutdown the microphone to avoid making noise.
5. If the sound of the microphone is not good or the mic cannot be turned on, please charge the battery in time.
6. The use of microphone reverb adjustment, when the microphone speaks or sings, feel that the echo sound of the speaker is too loud, press the first key of the microphone once, after one press, a sound represents entering the "microphone reverb adjustment", after entering, then press the microphone plus or minus key to adjust to the appropriate sound .

Charging Description

1. When the battery is out of power, the product will shutdown automatically.
2. Use our USB charging cable to connect with standard charging plug to charging the battery for the product.
3. The charging time is about 3-4 hours, the red light is off automatically once the product is fully charged.
4. The working time is about 2-3 hours.

 Do not use quick-charge

Common Malfunction and Resolve Method.

Specification

Model : K30

Mic: Capacitive Speaker:4Ω6W

Charging voltage:DC 5V

Bluetooth Version :5.0 Material: ABS

Frequency Response Range:100Hz~10KHz

Maximum Sound Pressure Level:>115dB 1Khz THD<1%

Sound Mode: Reverb Mode

Rechargeable Battery:18650battery

Warning:

1. If the machine appears smoke or other abnormal phenomena, please contact our after-sales service for help
2. If the inside of the machine is affected by rain or damp, please put the machine in a ventilated place to dry.
3. Do not bake the machine at high temperature, otherwise it may cause the risk to burn the machine or destroy the internal components of the machine.
4. This product should not be exposed to overheating environment, such as sunlight, fire or inflammation.
5. Do not throw the machine, so as to avoid fall damage,
6. If consumers use a power adapter for power supply, please use the qualified power adapter with standard certification. It is forbidden to charge the high-power mobile phone fast charge charging equipment to charge this speaker device, which will result in damage to this equipment.



FCC Warning StatementChanges or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and(2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.