


88KEY

ELECTRONIC KEYBOARD USER MANUAL

Please read this manual carefully before using this product,
and properly kept. The contents of this manual contains the
attachment in detail.

BD-881



The function keys marked with (*) are only available in the keyboard light version

1. Power

Turn on the [Power] button to play the keyboard and enter the performance state.

2. Tone

After pressing [Tone] button, you can use the [+/-] button to select the tone.

3. Rhythm

After pressing [Rhythm] button, you can use the [+/-] button to select the rhythm.

4. Demo One

Press the [Demo One] for the first time to enter the [Demo One] mode, and press the [Demo One] for the second time to exit the Demo One mode.

After entering the Demo One mode, play the song from the first song.

When the song finishes playing, the current song is played repeatedly. In the Demo One mode, press the [+/-] key to switch songs.

5. Demo All

Press the [Demo All] for the first time to enter the continuous singing mode, and press the [Demo All] for the second time to exit the continuous singing mode. Play from the first song.

When the song is finished, continue to play the next song and play all the songs in a loop. In continuous singing mode, press [+/-] key to switch songs.

6. Volume

After pressing the [Volume], you can use the [+/-] keys to increase/decrease the volume. The volume control has a total of 16 segments (1~16), and the default value is the 13th segment after power-on.

7. Rhythm volume

After pressing the [Rhythm volume], you can use the [+/-] keys to increase/decrease the rhythm volume. The rhythm volume control has a total of 17 segments (0~16), and the preset value is the 13th segment after power-on.

R973	R&B Soul Ballad2	R983	Big Band Fast5	R993	Classic Big Band3
R974	Euro Hip Hop4	R984	Orchestra Swing8	R994	French Jazz5
R975	Trip Hop2	R985	Orchestra Swing9	R995	Jump Jive3
R976	Ibiza 2004_2	R986	Rock Cha Cha5	R996	Mod Big Band Shft5
R977	Soft Rock4	R987	Organ Swing3	R997	Modern Big Band5
R978	Chart GuitarPop3	R988	Secret Service3	R998	Big Band Shuffle 13
R979	Guilira5	R989	Animation Bld3	R999	Big Band Shuffle 14
R980	Easy Listening4	R990	Reggae4	R999	Big Band Shuffle 15
R981	Bebop3	R991	Frankly Soul3		
R982	Orch Big Band4	R992	Jazz Funk3		

23. Appendix 3 (Demo Songs list)

S001	Chopin Fantasie Impromptu	S044	Debussy Aeolian	S099	Czerny 599 No.049
S002	Chopin Nocturne	S045	Dubessy Clair De lune	S100	Czerny 599 No.050
S003	Chopin Petit Chien	S046	L-C Daquin Le Coucou	S101	Czerny 599 No.051
S004	Chopin Chanson De L'adieu	S047	Karl Bohm The Fountain	S102	Czerny 599 No.052
S005	Chopin Nocturne	S048	Burgmüller Pastorale	S103	Czerny 599 No.053
S006	Chopin Black keys	S049	Korsakov Bumblebee	S104	Czerny 599 No.054
S007	Chopin - Valse op.64 no.2	S050	Haydn-Sunrise	S105	Czerny 599 No.055
S008	Beethoven- Piano Sonata op.13 "Pathétique" 2nd mov	S051	Czerny 599 No.001	S106	Czerny 599 No.056
S009	Beethoven Mondschein	S052	Czerny 599 No.002	S107	Czerny 599 No.057
S010	Beethoven Minuet In G	S053	Czerny 599 No.003	S108	Czerny 599 No.058
S011	Beethoven Marcia Alla Turca	S054	Czerny 599 No.004	S109	Czerny 599 No.059
S012	Beethoven piano sonata op.49-2 1st mov	S055	Czerny 599 No.005	S110	Czerny 599 No.060
S013	Beethoven Ecossaise	S056	Czerny 599 No.006	S111	Czerny 599 No.061
S014	Mozart Twinkle Twinkle Little Star	S057	Czerny 599 No.007	S112	Czerny 599 No.062
S015	Mozart Turkish March	S058	Czerny 599 No.008	S113	Czerny 599 No.063
S016	Mozart Menuett	S059	Czerny 599 No.009	S114	Czerny 599 No.064
S017	Bach Waltz In A Minor	S060	Czerny 599 No.010	S115	Czerny 599 No.065
S018	Bach Menuett	S061	Czerny 599 No.011	S116	Czerny 599 No.066
S019	Bach The Well-Tempered Clavier	S062	Czerny 599 No.012	S117	Czerny 599 No.067
S020	Bach Bourree	S063	Czerny 599 No.013	S118	Czerny 599 No.068
S021	Bach Invention	S064	Czerny 599 No.014	S119	Czerny 599 No.069
S022	Schubert Military Marches	S065	Czerny 599 No.015	S120	Czerny 599 No.070
S023	Schubert Moments Musicaux	S066	Czerny 599 No.016	S121	Czerny 599 No.071
S024	Schumann Traumerel	S067	Czerny 599 No.017	S122	Czerny 599 No.072
S025	Schumann Frohlicher Landmann	S068	Czerny 599 No.018	S123	Czerny 599 No.073
S026	Schumann Sicilienne	S069	Czerny 599 No.019	S124	Czerny 599 No.074
S027	Richard Ballade Pour Adeline	S070	Czerny 599 No.020	S125	Czerny 599 No.075
S028	Richard Ping Pong Sous Les Arbres	S071	Czerny 599 No.021	S126	Czerny 599 No.076
S029	Richard A Comme Amour	S072	Czerny 599 No.022	S127	Czerny 599 No.077
S030	Richard Mariage D'amour	S073	Czerny 599 No.023	S128	Czerny 599 No.078
S031	Mendelssohn Jagerlied op.18b-3	S074	Czerny 599 No.024	S129	Czerny 599 No.079
S032	Mendelssohn Frühlingslied	S075	Czerny 599 No.025	S130	Czerny 599 No.080
S033	Mendelssohn Canon In D	S076	Czerny 599 No.026	S131	Czerny 599 No.081
S034	Pachelbel Canon In D	S077	Czerny 599 No.027	S132	Czerny 599 No.082
S035	Badarzewska Maiden's Prayer	S078	Czerny 599 No.028	S133	Czerny 599 No.083
S036	Liszt Liebestraume	S079	Czerny 599 No.029	S134	Czerny 599 No.084
S037	Tchaikovsky- Danse des miriltons	S080	Czerny 599 No.030	S135	Czerny 599 No.085
S038	Oesten Dolly's Dreaming	S081	Czerny 599 No.031	S136	Czerny 599 No.086
S039	Awakening	S082	Czerny 599 No.032	S137	Czerny 599 No.087
S040	Dvorak Humoresque	S083	Czerny 599 No.033	S138	Czerny 599 No.088
S041	Joplin The Entertainer	S084	Czerny 599 No.034	S139	Czerny 599 No.089
S042	Debussy La Fille aux Cheveux de Lin	S085	Czerny 599 No.035	S140	Czerny 599 No.090
S043		S086	Czerny 599 No.036	S141	Czerny 599 No.091
		S087	Czerny 599 No.037	S142	Czerny 599 No.092
		S088	Czerny 599 No.038	S143	Czerny 599 No.093
		S089	Czerny 599 No.039	S144	Czerny 599 No.094
		S090	Czerny 599 No.040	S145	Czerny 599 No.095
		S091	Czerny 599 No.041	S146	Czerny 599 No.096
		S092	Czerny 599 No.042	S147	Czerny 599 No.097
		S093	Czerny 599 No.043	S148	Czerny 599 No.098
		S094	Czerny 599 No.044	S149	Czerny 599 No.099
		S095	Czerny 599 No.045	S150	Czerny 599 No.100
		S096	Czerny 599 No.046		
		S097	Czerny 599 No.047		
		S098	Czerny 599 No.048		

Warm reminder

1. Only use 5V/cell phone charger, the USB cable is on the outside of the white foam on the left.

2. If you install the batteries by yourself.

Please take care of the following attentions.

- Do not attempt to disassemble or short-circuit the battery.
- Do not expose or burn it in the fire.
- Do not mix the new and old battery.
- Do not mix different types of batteries.
- Do not charge the battery.
- The positive and negative poles of the battery must be properly installed.
- Please remove the battery from the keyboard if you do not use for a long time.

16. Synthetic chords

Press [Synthetic chords] button for the first time to enter the Synthetic chord mode, and press [Synthetic chords] button for the second time to exit the Synthetic chord mode. [Synthetic chords] button only works in rhythm and normal mode.

When playing the rhythm, press [Synthetic chords] button and press the multi-fingered chord fingering within the range of the keys A1 ~F4#, and then you can hear the corresponding chord accompaniment sound. If you don't press the multi-fingered chord fingering, the single fingering will be played.

When the rhythm is not playing, press [Synthetic chords] button and press the multi-fingered chord fingering within the range of keys A1 ~F4#, and you will hear the corresponding chord sound. If you do not press the multi-fingered chord fingering, the single fingering will be played.

17. Record

Press the [Record] button for the first time to enter the recording mode, and the last record will be cleared; pressing the [Record] button for the second time will exit the recording mode. In the recording mode, the metronome will be played, and you can start recording by pressing any key. The maximum number of recordings is 176. When the recording is full, the next note cannot be recorded; during recording, you can press the [Play] button at any time to play the recorded notes or drum sounds.

18. Play/LED*

Press [Play/LED] for the first time to play the recorded note or drum sound, and press [Play] button for the second time to stop playing. Press [Play] button to exit the recording mode. If there is no recorded value before, press [Play] button and no action will occur.

(*The default value is the keyboard light on after power on, press and hold this key 5 seconds later can control the keyboard LED on/off)

19. Metronome

Press [Metronome] button, the action function is 1/4 beat → 7/4 beat → stop → 1/4 beat. The preset value of tempo is 120. There are 7 variations of the metronome sound, in sequence from 1/4 beat to 7/4 beat. When recording, press [Metronome] button to turn on/off the metronome sound.

20. Bluetooth/MP3 mode

Press (within 1 second) [Start/Stop] button shortly to play or stop playing the song. In stop mode, press [Start/Stop] button to continue playing the song.

Press (within 1 second) [-] button shortly to select the last song. Press (within 1 second) [+] button to select the next song.

Keep pressing [-] button for more than 1 second to decrease the volume. Keep pressing [+] button for more than 1 second to increase the volume.

Keep pressing [Start/stop] button for more than 1 second to switch mode, Bluetooth Audio>MP3 U disk (you can't select MP3 mode if you don't plug in the U disk).

21. Appendix 1 (Tone comparison table)

T001	Acoustic Grand Piano	T019	Rock Organ	T037	Slap Bass 1
T002	Bright Acoustic Piano	T020	Church Organ	T038	Slap Bass 2
T003	Electric Grand Piano	T021	Reed Organ	T039	Synth Bass 1
T004	Honky-tonk Piano	T022	Accordion	T040	Synth Bass 2
T005	Rhodes Piano	T023	Harmonica	T041	Violin
T006	Chorused Piano	T024	Tango Accordion	T042	Viola
T007	Harpichord	T025	Acoustic Guitar (nylon)	T043	Cello
T008	Clavichord	T026	Acoustic Guitar (steel)	T044	Contrabass
T009	Celesta	T027	Electric Guitar (jazz)	T045	Tremolo Strings
T010	Glockenspiel	T028	Electric Guitar (clean)	T046	Pizzicato Strings
T011	Music box	T029	Electric Guitar (muted)	T047	Orchestral Harp
T012	Vibraphone	T030	Overdriven Guitar	T048	Timpani
T013	Marimba	T031	Distortion Guitar	T049	String Ensemble 1
T014	Xylophone	T032	Guitar Harmonics	T050	String Ensemble 2
T015	Tubular Bell	T033	Acoustic Bass	T051	Synth Strings 1
T016	Dulcimer	T034	Electric Bass(finger)	T052	Synth Strings 2
T017	Drawbar Organ	T035	Electric Bass (pick)	T053	Choir Aahs
T018	Percussive Organ	T036	Fretless Bass	T054	Voice Oohs

R571	Cumbia3	R637	Pop Waltz3	R703	Pasodoble2
R572	Latin Rock	R638	Bhangra2	R704	Highland Waltz2
R573	Disco Latin	R639	Twist3	R705	Schlager Polka2
R574	Tijuana	R640	German March2	R706	Gruper2
R575	Reggae2	R641	Enka2	R707	Danzon2
R576	Salsa2	R642	Bolero Lento2	R708	Schlager Alp2
R577	Calypso	R643	Midnight Swing2	R709	Saeidy2
R578	Guad Dance	R644	French Jazz2	R710	Bhajan2
R579	Reggae 12Beat	R645	Latin Party Pop2	R711	Hip Hop Groove2
R580	Reggae 16Beat	R646	Tango6	R712	Hip Shuffle2
R581	Swing Fox	R647	Tango7	R713	Organ Groove2
R582	Slow Fox	R648	Parranda2	R714	Chart Pop3
R583	Organ Cha Cha	R649	Latin Rock2	R715	Country Ballad3
R584	Organ Quick Step	R650	Acoustic Rock3	R716	Romantic Ballad2
R585	Cat Groove	R651	80's Pop3	R717	Analog Ballad2
R586	Dixie Jazz	R652	60's Soul2	R718	Electro Pop2
R587	Medium Jazz	R653	Fusion Shuffl3	R719	Blues Rock2
R588	Jazz Big Band	R654	Fusion Shuffl4	R720	Rave2
R589	Jazz Club	R655	16 Beat Pop3	R721	US Chart Hit2
R590	Ragtime2	R656	16 Beat Pop4	R722	Alp Ballad3
R591	Big Band Shuffle 1	R657	60's Rock 3	R723	8 Beat Modern2
R592	Big Band Shuffle 2	R658	Brit Rock Pop2	R724	Euro Hip Hop2
R593	Big Band Shuffle 3	R659	Blueberry Blues2	R725	Disco Pop2
R594	Fast Band 1	R660	Skiffle3	R726	Disco Philly2
R595	Fast Band 2	R661	Mambo6	R727	Mod Big BandShff2
R596	Frankly Soul	R662	Mambo7	R728	Modern Big Band2
R597	Jazz Funk	R663	Club Pop3	R729	8 Beat Adria2
R598	Classic Big Band	R664	Schlager Italia2	R730	Disco Chocolate2
R599	French Jazz	R665	Power Rock3	R731	Euro Trance2
R600	Jump Jive	R666	Rock'n Roll 3	R732	Euro Beat3
R601	Standard Rock2	R667	Cool8 Beat2	R733	Techno4
R602	16 Beat Ballad3	R668	British Pop6	R734	Reggae3
R603	Contemp Rock2	R669	British Pop7	R735	Chillout Cafe2
R604	EP Ballad2	R670	8 Beat Soul3	R736	Love Song2
R605	Fusion4	R671	Brit Pop2	R737	French House2
R606	Fusion5	R672	Disco Latin2	R738	Jazz Waltz4
R607	Funk2	R673	Brit Pop Swing2	R739	Classic Piano2
R608	Guitar Serenade2	R674	Fast Gospel2	R740	Disco Party2
R609	Organ Ballad3	R675	Fast Bossa2	R741	Club Dance2
R610	Joropo2	R676	60's Guitar Pop2	R742	Jazz Gtr Club2
R611	Reggaeton2	R677	90's Soul	R743	Modern Jazz2
R612	French Waltz2	R678	Funk Shuffl 3	R744	Polka Pop2
R613	Merengue2	R679	8 Beat Rock3	R745	USA March2
R614	Pop Ballad2	R680	Rock Cha Cha2	R746	Ober Polka2
R615	Norteno2	R681	Guiljira2	R747	Easy Listening2
R616	Jig2	R682	Rock Ballad2	R748	Fast Band3
R617	Hawaiian2	R683	Soul 5	R749	Fast Band4
R618	70's Disco3	R684	Classic 8Beat2	R750	Big Band Fast3
R619	70's Disco4	R685	Bolero3	R751	Orchestra Swing3
R620	Club Beat2	R686	Soul Brothers2	R752	Orchestra Swing4
R621	Rap 4	R687	Happy Reggae2	R753	Finger Pickin2
R622	Disco House2	R688	Pop Latin2	R754	Hully Gully2
R623	MOR Swing2	R689	6-8Slow Rock2	R755	Viennese Waltz2
R624	Retro Pop2	R690	6-8 Modern2	R756	Show Tune2
R625	Calypso2	R691	6-8 Orchestral2	R757	Rumba3
R626	Trance Pop2	R692	Slow Soul2	R758	Schlager Rock4
R627	Big Band Shuffle4	R693	Piano Ballad3	R759	Jazz Waltz2
R628	Big Band Shuffle5	R694	Disco Trot2	R760	Country Ballad4
R629	Big Band Shuffle6	R695	Disco Hands2	R761	Dixieland2
R630	German Rock2	R696	British Pop8	R762	French Jazz3
R631	Schlager Beat2	R697	Italian Mazurka2	R763	Easy Country2
R632	Disco Funk2	R698	Bohemian Waltz2	R764	Country Hits2
R633	Disco Samba2	R699	Samba3	R765	Country 8 Beat2
R634	New Hip Hop2	R700	Samba4	R766	Blue Grass4
R635	Cat Groove2	R701	Jive3	R767	Blue Grass5
R636	Laff2	R702	Foxtrot3	R768	Blue Grass6

T247	Tsugaru 4	T311	Attack Barafon 4	T375	Bag Pipe 6	R187	China Folk 2	R251	Detroit Pop1	R315	New R&B
T248	Tsugaru 5	T312	Hard Barsoon 3	T376	Clavi 7	R188	China Opera 1	R252	Detroit Pop2	R316	Pop R&B
T249	Mute Barafon 4	T313	Dulcimer 4	T377	Hard Vibe 7	R189	China Opera 2	R253	Worship Med	R317	Chart R&B
T250	Dual Horns 4	T314	Twin Bones 4	T378	Kawala 7	R190	China Ballad	R254	Worship Fast	R318	Modern Shuffle
T251	Soft Sax 3	T315	Soft Sax 5	T379	Shanai 3	R191	China Pop	R255	Piano Boogie	R319	Blues Rock
T252	Bodhran 3	T316	Shamisen 5	T380	Suona 6	R192	Xin Jiang	R256	Lovely Shuffle	R320	Dream Dance
T253	Guitar Pinch 3	T317	Suona 4	T381	Jungle Bass 4	R193	Shan Bei	R257	60's Rock & Roll	R321	US Chart Hit
T254	Crystal 3	T318	Bodhran 4	T382	Grow Guitar 7	R194	Yun Nan	R258	Kool Funk	R322	Soul R&B
T255	Grow Guitar 2	T319	Shamisen 6	T383	Bag Pipe 7	R195	He Nan	R259	Blueberry Blues	R323	R&B Soul Ballad
T256	Jazz Organ 6	T320	Electric Vraphone 6	T384	Crystal 4	R196	An Hui	R260	Shuffle Blues	R324	Euro Hip Hop
T257	Attack Barafon 2	T321	Tsugaru 7	T385	Guitar Pinch 5	R197	Guang Dong	R261	Mambo 4	R325	Trip Hop
T258	Xylophone 4	T322	Oct Harp 3	T386	Woodblock 8	R198	Xi Zang	R262	Mambo 5	R326	Ibiza 2004
T259	Soft Santur 3	T323	Kalimba 4	T387	Soft Sax 7	R199	Mongolian	R263	Pop Classics	R327	Mod Big Band Shfl
T260	Kawala 4	T324	Soft Clav. 2	T388	Attack Barafon 5	R200	Korean	R264	Live 8 Beat	R328	Modern Big Band
T261	Soft Guitar 5	T325	English Horn 4	T389	Barafon 6	R201	J-Pop Hit	R265	Power Rock2	R329	Pop Gtr Ballad
T262	Nay 4	T326	Didgeridoo 6	T390	Organ Flute 4	R202	16 Beat Ballad2	R266	Acoustic Rock2	R330	Ibiza 2002
T263	Synth Harpsi. 3	T327	Barafon 4	T391	Mute Barafon 9	R203	70's Pop Ballad	R267	Cool 8 Beat	R331	Euro Trance
T264	Wind Organ 3	T328	Indian Flute 7	T392	Shanai 4	R204	EP Ballad	R268	Uptempo 8Beat	R332	6-8 Trance
T265	Shanai 2	T329	Organ Flute 2	T393	Soft Clav. 3	R205	Power Ballad	R269	90's Rock Ballad	R333	Latin DJ's
T266	Woodblock 6	T330	Soft Santur 4	T394	Oct Harp 5	R206	Guitar Ballad2	R270	Chart Rock Shfl2	R334	Bomba
T267	Electric Vraphone 4	T331	Mute Barafon 7	T395	Tron Flute 5	R207	New R&B Ballad	R271	Brit Pop	R335	Chillout Cafe
T268	Kawala 5	T332	Nay 7	T396	Bright String 3	R208	Guitar Serenade	R272	Brazilian Samba	R336	70's Glam Piano
T269	Grow Guitar 3	T333	Hard Vibe 5	T397	Jazz Organ 9	R209	Organ Ballad2	R273	Brit Pop Swing	R337	French House
T270	Grow Guitar 4	T334	Bari & Tenor 4	T398	Mute Barafon 10	R210	Joropo	R274	60's 8 Beat	R338	English Waltz
T271	Steel Bell	T335	Bag Pipe 4	T399	Slow Violin 2	R211	Reggaeton	R275	Fast Bossa	R339	8 Beat Ballad1
T272	Wind Organ 4	T336	Tenor Sax 3	T400	Soft Sax 8	R212	French Waltz	R276	60's Guitar Pop	R340	Club House
T273	Soft Accord 2	T337	Organ Flute 3	T401	English Horn 6	R213	Merengue	R277	70's 8 Beat	R341	House2
T274	Kalimba 3	T338	Dulcimer 5	T402	Reed Horn 4	R214	12-8 Ballad	R278	90's Guitar Pop	R342	Jazz Gtr Club
T275	Twin Bones 3	T339	Twin Bones 5	T403	Indian Flute 8	R215	Norteno	R279	Soft Rock2	R343	Modern Jazz
T276	Church Bells 3	T340	Grow Guitar 5	T404	Castanets 4	R216	Jig	R280	Chart Guita rPop	R344	Acoustic Jazz
T277	Koto 6	T341	Kalimba 5	T405	English Horn 7	R217	Hawaiian	R281	Gujiira	R345	Cool Jazz Ballad
T278	Attack Barafon 3	T342	Oct Harp 4	T406	Tron Flute 6	R218	Electronica	R282	Modern Pop Bld	R346	Modern Jazz Bld
T279	Mute Barafon 5	T343	Nay 8	T407	English Horn 8	R219	Funky House	R283	Soul	R347	Easy Listening
T280	Nay 5	T344	Dual Horns 5	T408	Hard Barsoon 4	R220	Club Beat	R284	Skiffle2	R348	Bebop
T281	Jungle Bass 2	T345	Didgeridoo 7	T409	Dulcimer 6	R221	Retro Club	R285	6-8Soul	R349	Orch Big Band1
T282	Soft Accord 3	T346	English Horn 5	T410	Xylophone 6	R222	Mod Chart Pop	R286	Soul Brothers	R350	Big Band Fast1
T283	Hard Vibe 3	T347	Kawala 6	T411	Mute Barafon 11	R223	MOR Swing	R287	Happy Reggae	R351	Orchestra Swing1
T284	Soft Clav.	T348	Marimba 5	T412	Nay 9	R224	Retro Pop	R288	Pop Latin	R352	Orchestra Swing2
T285	Bag Pipe 2	T349	Barafon 5	T413	Mute Barafon 12	R225	Rumba Flamenco	R289	6-8Slow Rock	R353	70's Ranking Country
T286	Oct Harp 2	T350	Soft Accord 5	T414	Dual Horns 7	R226	Trance Pop	R290	6-8 Modern	R354	Jazz Waltz Med
T287	Woodblock 7	T351	Mute Barafon 8	T415	Kawala 8	R227	Orch Big Band2	R291	6-8 Orchestral	R355	Mariachi Waltz
T288	Mute Barafon 6	T352	Dual Horns 6	T416	Soft Clav. 4	R228	Big Band Fast2	R292	Schlager Shuffle	R356	US March
T289	Guitar Pinch 4	T353	Church Bells 4	T417	Hard Barsoon 5	R229	Midnight Swing	R293	Schlager Pop	R357	Guitar Rumba
T290	Dulcimer 3	T354	Wind Organ 5	T418	Dulcimer 7	R230	German Rock	R294	Schlager Rumba	R358	Slow Blues
T291	Soft Sax 4	T355	Attack Clav. 5	T419	Soft Accord 6	R231	Schlager Beat	R295	Euro Pop Organ	R359	Jazz Waltz Fast
T292	Electric Vraphone 5	T356	Jazz Organ 7	T420	Church Bells 5	R232	Mellow Hip Hop	R296	70's French Hit	R360	70's Country Pop
T293	Tsugaru 6	T357	Reed Horn 3	T421	Shamisen 7	R233	Classic Hip Hop	R297	Italian Mazurka	R361	Dixieland
T294	Reed Horn 2	T358	Tenor Sax 4	T422	Synth Harpsi. 4	R234	New Hip Hop	R298	Bohemian Waltz	R362	40's Big Band
T295	Castanets 3	T359	Chorus Guitar. 2	T423	Crystal 5	R235	Duranguense	R299	Schlager Samba1	R363	Easy Country
T296	Tron Flute 3	T360	Didgeridoo 8	T424	Kawala 9	R236	Laff	R300	Schlager Samba2	R364	Country Hits
T297	Attack Clav. 3	T361	Soft Santur 5	T425	Dual Horns 8	R237	Ober Walzer	R301	Scand Slow Rock	R365	Country 8 Beat
T298	Bari & Tenor 3	T362	Clavi 6	T426	Clavi 8	R238	Bhangra	R302	Schlager 6-8	R366	Sci-fi March
T299	Indian Flute 6	T363	Kalimba 6	T427	Electric Vraphone 7	R239	Zouk	R303	Schlager Fox	R367	Tap Dance Swing
T300	Soft Guitar 6	T364	Didgeridoo 9	T428	Castanets 5	R240	German March	R304	Highland Waltz	R368	Orchestral Bolero
T301	Nay 6	T365	Wind Organ 6	T429	Tenor Sax 5	R241	Enka	R305	Italian Polka	R369	Gospel Sisters
T302	Didgeridoo 5	T366	Tron Flute 4	T430	Tenor Sax 6	R242	Bolero Lento	R306	Grupera	R370	Italian Waltz
T303	Marimba 4	T367	Soft Sax 6	T431	Didgeridoo 10	R243	Sherif fReggae	R307	Danzon	R371	6-8 March
T304	Attack Clav. 4	T368	Suona 5	T432	Kalimba 7	R244	Beguine2	R308	Schlager Alp	R372	Bluegrass
T305	Jungle Bass 3	T369	Soft Guitar 7	T433	English Horn 9	R245	Latin Disco	R309	Saeidy	R373	Mod Cntry Bld1
T306	Hard Barsoon 2	T370	Hard Vibe 6	T434	Guitar Pinch 6	R246	Tango4	R310	Bhajan	R374	Scand Country1
T307	Suona 3	T371	Jazz Organ 8	T435	Hard Vibe 8	R247	Tango5	R311	Hip Hop Groove	R375	Scand Country2
T308	Hard Vibe 4	T372	Grow Guitar 6	T436	Mute Barafon 13	R248	Rock &Roll	R312	Chart Pop1	R376	Scand Shuffle
T309	Bag Pipe 3	T373	Xylophone 5	T437	Tenor Sax 7	R249	Rock & Roll Shfl1	R313	Organ Groove	R377	Worship Slow
T310	Soft Accord 4	T374	Bag Pipe 5	T438	Bag Pipe 8	R250	Oldies R & R	R314	Chart Pop2	R378	Disco Teens

T631	Koto 11	T695	Viola Attack 9	T759	Suona 14	T823	Soft Guitar 18	T883	Crystal 14	T943	Church Bells 15
T632	Kalimba 12	T696	Hard Vibe 13	T760	Kalimba 13	T824	Xylophone 11	T884	Barafon 9	T944	Tenor Sax 14
T633	Suona 10	T697	Koto 13	T761	Suona 15	T825	Tenor Sax 12	T885	Reed Horn 12	T945	Dual Horns 14
T634	Oct Harp 6	T698	Tenor Sax 9	T762	Slow Violin 12	T826	Oct Harp 8	T886	Dual Horns 13	T946	Barafon 12
T635	Koto 12	T699	Kawala 15	T763	Reed Organ 7	T827	Shamisen 12	T887	Chorus Guitar. 12	T947	Steel Bell 12
T636	Shanai 8	T700	Steel Bell 6	T764	Kawala 19	T828	Reed Horn 10	T888	Grow Guitar 13	T948	Marimba 15
T637	Electric Guitar (Clean) 8	T701	Soft Accord 11	T765	Reed Horn 9	T829	Marimba 12	T889	Shanai 12	T949	Electric Viaphone 15
T638	Clavi 12	T702	Organ Flute 10	T766	Attack Harp 7	T830	Reed Organ 11	T890	Twin Bones 12	T950	Soft Accord 15
T639	Attack Harp 3	T703	Organ Flute 11	T767	Oct Harp 7	T831	Attack Clav. 13	T891	Barafon 10	T951	Steel Bell 13
T640	Attack Clav. 10	T704	Bright String 9	T768	Kalimba 14	T832	Hard Barsoon 15	T892	Jungle Bass 11	T952	Tenor Sax 15
T641	Bright String 6	T705	Soft Santur 11	T769	Twin Bones 9	T833	Dual Horns 12	T893	Marimba 13	T953	Electric Guitar (Clean) 15
T642	Organ Flute 7	T706	Hard Barsoon 10	T770	Attack Clav. 12	T834	Soft Clav. 13	T894	Grow Guitar 14	T954	Soft Clav. 15
T643	Electric Guitar (Clean) 9	T707	Wind Organ 14	T771	Bari & Tenor 11	T835	Church Bells 12	T895	Viola Attack 12	T955	Bari & Tenor 14
T644	Kawala 12	T708	Synth Harpsi. 11	T772	Attack Harp 8	T836	Oct Harp 9	T896	Shamisen 15	T956	Attack Harp 13
T645	Bodhran 11	T709	Soft Sax 19	T773	English Horn 16	T837	Oct Harp 10	T897	Tsugaru 12	T957	Chorus Guitar. 14
T646	Shanai 9	T710	Bright String 10	T774	Twin Bones 10	T838	Indian Flute 13	T898	Reed Horn 13	T958	Shanai 15
T647	Suona 11	T711	Bright String 11	T775	Soft Clav. 12	T839	Viola Attack 11	T899	Shanai 13	T959	Reed Organ 14
T648	Synth Harpsi. 10	T712	Jungle Bass 9	T776	Tubular Bells 10	T840	Clavi 14	T900	Castanets 13	T960	Bodhran 14
T649	Bari & Tenor 6	T713	Soft Accord 12	T777	Slow Violin 13	T841	Koto 15	T901	Reed Organ 12	T961	Jungle Bass 14
T650	Kawala 13	T714	Reed Horn 8	T778	Synth Harpsi. 15	T842	Soft Guitar 19	T902	Twin Bones 13	T962	Tsugaru 14
T651	Bari & Tenor 7	T715	Slow Violin 10	T779	Guitar Pinch 12	T843	Castanets 12	T903	Chorus Guitar. 13	T963	Shanai 16
T652	Reed Horn 7	T716	Synth Harpsi. 12	T780	Church Bells 10	T844	Jazz Organ 14	T904	Tron Flute 13	T964	Bag Pipe 16
T653	Shamisen 10	T717	Attack Harp 6	T781	Castanets 10	T845	Bag Pipe 14	T905	Koto 16	T965	Viola Attack 15
T654	Soft Clav. 11	T718	Soft Santur 12	T782	Twin Bones 11	T846	Steel Bell 8	T906	Oct Harp 12	T966	Steel Bell 14
T655	Bari & Tenor 8	T719	Hard Barsoon 11	T783	Indian Flute 12	T847	Church Bells 13	T907	Grow Guitar 15	T967	Crystal 15
T656	Soft Santur 9	T720	English Horn 15	T784	Woodblock 11	T848	Guitar Pinch 13	T908	Shanai 14	T968	Bright String 15
T657	Attack Harp 4	T721	Crystal 8	T785	Attack Harp 9	T849	Soft Clav. 14	T909	Electric Guitar (Clean) 12	T969	Reed Horn 14
T658	Bright String 7	T722	Bari & Tenor 10	T786	Crystal 10	T850	Tubular Bells 12	T910	Castanets 14	T970	Guitar Pinch 15
T659	Guitar Pinch 11	T723	Koto 14	T787	Mute Barafon 21	T851	Grow Guitar 12	T911	Reed Organ 13	T971	Oct Harp 15
T660	Wind Organ 11	T724	Didgeridoo 20	T788	Synth Harpsi. 16	T852	Steel Bell 9	T912	Electric Guitar (Clean) 13	T972	Twin Bones 15
T661	Soft Guitar 12	T725	Tenor Sax 10	T789	Reed Organ 8	T853	Chorus Guitar. 10	T913	Soft Accord 14	T973	Chorus Guitar. 15
T662	English Horn 14	T726	Bright String 12	T790	Steel Bell 7	T854	Crystal 13	T914	Twin Bones 14	T974	Bari & Tenor 15
T663	Kawala 14	T727	Hard Vibe 14	T791	Chorus Guitar. 8	T855	Reed Horn 11	T915	Marimba 14	T975	Tenor Sax 16
T664	Grow Guitar 11	T728	Dual Horns 10	T792	Reed Organ 9	T856	Steel Bell 10	T916	Jungle Bass 12	T976	Indian Flute 15
T665	Attack Harp 5	T729	Kawala 16	T793	Marimba 10	T857	Kawala 21	T917	Electric Guitar (Clean) 14	T977	Bodhran 15
T666	Bari & Tenor 9	T730	Kawala 17	T794	Electric Viaphone 11	T858	Attack Harp 10	T918	Barafon 11	T978	Shamisen 16
T667	Organ Flute 8	T731	Bag Pipe 13	T795	Soft Guitar 16	T859	Oct Harp 11	T919	Viola Attack 13	T979	Attack Harp 14
T668	Woodblock 10	T732	Electric Guitar (Clean) 10	T796	Viola Attack 10	T860	Kalimba 15	T920	Slow Violin 14	T980	Barafon 13
T669	Hard Vibe 11	T733	Tron Flute 10	T797	Reed Organ 10	T861	Tubular Bells 13	T921	Oct Harp 13	T981	Jungle Bass 15
T670	Mute Barafon 20	T734	Kawala 18	T798	Bari & Tenor 12	T862	Electric Guitar (Clean) 11	T922	Dulcimer 15	T982	Tron Flute 14
T671	Tubular Bells 7	T735	Tron Flute 11	T799	Soft Sax 22	T863	Jazz Organ 15	T923	Bari & Tenor 13	T983	Attack Harp 15
T672	Suona 12	T736	Tubular Bells 8	T800	Jazz Organ 13	T864	Attack Barafon 15	T924	Bag Pipe 15	T984	Koto 17
T673	Bright String 8	T737	Synth Harpsi. 13	T801	Soft Guitar 17	T865	Soft Guitar 20	T925	Attack Clav. 14	T985	Reed Organ 15
T674	Hard Vibe 12	T738	Soft Santur 13	T802	Xylophone 9	T866	Soft Accord 13	T926	Kalimba 16	T986	Attack Clav. 15
T675	Slow Violin 8	T739	Tubular Bells 9	T803	Xylophone 10	T867	Synth Harpsi. 17	T927	Hard Vibe 15	T987	Clavi 15
T676	Shamisen 11	T740	Attack Barafon 11	T804	Church Bells 11	T868	Bodhran 12	T928	Organ Flute 14	T988	Dual Horns 15
T677	Tron Flute 9	T741	Attack Barafon 12	T805	Suona 16	T869	Woodblock 12	T929	Jungle Bass 13	T989	Steel Bell 15
T678	Attack Clav. 11	T742	Electric Viaphone 10	T806	Crystal 11	T870	Attack Harp 11	T930	Electric Viaphone 14	T990	Slow Violin 15
T679	Dual Horns 9	T743	Dual Horns 11	T807	Chorus Guitar. 9	T871	Organ Flute 12	T931	Viola Attack 14	T991	Soft Santur 15
T680	Wind Organ 12	T744	Shanai 10	T808	Crystal 12	T872	Jazz Organ 16	T932	Bodhran 13	T992	Barafon 14
T681	Twin Bones 8	T745	Bright String 13	T809	Hard Barsoon 13	T873	Didgeridoo 21	T933	Tubular Bells 15	T993	Organ Flute 15
T682	Reed Organ 6	T746	Crystal 9	T810	Castanets 11	T874	Church Bells 14	T934	Indian Flute 14	T994	Castanets 15
T683	Organ Flute 9	T747	Clavi 13	T811	Kawala 20	T875	Synth Harpsi. 18	T935	Tenor Sax 13	T995	Guitar Pinch 16
T684	Slow Violin 9	T748	Soft Sax 20	T812	Nay 16	T876	Chorus Guitar. 11	T936	Guitar Pinch 14	T996	Tron Flute 15
T685	Dulcimer 12	T749	Tron Flute 12	T813	Tubular Bells 11	T877	Organ Flute 13	T937	Steel Bell 11	T997	Tsugaru 15
T686	Tsugaru 11	T750	Dulcimer 14	T814	Hard Barsoon 14	T878	Shamisen 13	T938	Tsugaru 13	T998	Reed Horn 15
T687	Wind Organ 13	T751	Slow Violin 11	T815	Barafon 8	T879	Jungle Bass 10	T939	Soft Santur 14	T999	Barafon 15
T688	Soft Santur 10	T752	Tenor Sax 11	T816	Marimba 11	T880	Shamisen 14	T940	Bright String 14	T000	Electric Guitar (Clean) 16
T689	Suona 13	T753	Nay 15	T817	Soft Sax 23	T881	Tubular Bells 14	T941	Oct Harp 14		
T690	Soft Guitar 13	T754	Attack Barafon 15	T818	Attack Barafon 13	T882	English Horn 17	T942	Attack Harp 12		
T691	Xylophone 8	T755	Shanai 11	T819	Electric Viaphone 12						
T692	Dulcimer 13	T756	Hard Barsoon 12	T820	Wind Organ 15						
T693	Marimba 9	T757	Synth Harpsi. 14	T821	Attack Barafon 14						
T694	Soft Guitar 14	T758	Soft Sax 21	T822	Electric Viaphone 13						

22. Appendix 2 (Rhythm comparison table)

R001	8Beat 1	R063	Power Rock	R125	Dance 2	T439	Shanai 5	T503	Bag Pipe 11	T567	Attack Barafon 8
R002	8Beat 2	R064	Dark Rock	R126	Disco	T440	English Horn 10	T504	Hard Barsoon 7	T568	Soft Clav. 9
R003	8Beat 3	R065	Jazz Rock	R127	House	T441	Didgeridoo 11	T505	Mute Barafon 15	T569	Tubular Bells 4
R004	8Beat 4	R066	Soft Rock	R128	Euro Beat	T442	Organ Flute 5	T506	Soft Sax 12	T570	Reed Organ 4
R005	8Beat 5	R067	Pop Rock 1	R129	Funky Dance	T443	Attack Barafon 6	T507	Attack Clav. 9	T571	Guitar Pinch 10
R006	8Beat 6	R068	Pop Rock 2	R130	80's Dance	T444	Jungle Bass 5	T508	Jazz Organ 12	T572	Bodhran 10
R007	8Beat 7	R069	Funky Rock 1	R131	Techno	T445	Barafon 7	T509	Soft Guitar 9	T573	Clavi 11
R008	8Beat 8	R070	Funky Rock 2	R132	Fusion	T446	Soft Santur 6	T510	Didgeridoo 13	T574	Viola Attack 6
R009	8Beat 9	R071	Ballad Rock	R133	Blues 1	T447	Slow Violin 3	T511	Bright String 4	T575	Synth Harpsi. 7
R010	8Beat 10	R072	Folk Rock	R134	Blues 2	T448	Hard Barsoon 6	T512	Electronic Glutar (Clean) 4	T576	Jungle Bass 7
R011	8Beat 11	R073	Slow Rock 1	R135	Blues 3	T449	Didgeridoo 12	T513	Tsugaru 9	T577	Koto 9
R012	8Beat 12	R074	Slow Rock 2	R136	Funky 1	T450	Kalimba 8	T514	Nay 10	T578	Church Bells 7
R013	8Beat 13	R075	Slow Rock 3	R137	Funky 2	T451	Electronic Glutar (Clean) 3	T515	Reed Horn 6	T579	Soft Accord 9
R014	8Beat 14	R076	Slow Rock 4	R138	Funky 3	T452	Dulcimer 8	T516	Didgeridoo 14	T580	Tubular Bells 5
R015	8Beat 15	R077	Rock&Roll 1	R139	Gospel	T453	Reed Horn 5	T517	Soft Clav. 5	T581	Bag Pipe 12
R016	8Beat 16	R078	Rock&Roll 2	R140	Rap 1	T454	Bodhran 5	T518	Soft Sax 13	T582	Grow Guitar 8
R017	8Beat 17	R079	Shuffle 1	R141	Rap 2	T455	Soft Sax 9	T519	Reed Organ 3	T583	Mute Barafon 18
R018	8Beat 18	R080	Shuffle 2	R142	Soul 1	T456	Mute Barafon 14	T520	Steel Bell 3	T584	Soft Accord 10
R019	16Beat 1	R081	Boogie 1	R143	Soul 2	T457	Guitar Pinch 7	T521	Clavi 10	T585	Electronic Glutar (Clean) 6
R020	16Beat 2	R082	Boogie 2	R144	Soul 3	T458	Wind Organ 7	T522	Wind Organ 8	T586	Viola Attack 7
R021	16Beat 3	R083	Boogie 3	R145	Soul 4	T459	Guitar Pinch 8	T523	Synth Harpsi. 6	T587	Kawala 11
R022	16Beat 4	R084	Twist	R146	Country 1	T460	Indian Flute 9	T524	Bari & Tenor 5	T588	Soft Santur 7
R023	16Beat 5	R085	Ballad 1	R147	Country 2	T461	Bag Pipe 9	T525	Steel Bell 4	T589	Bright String 5
R024	16Beat 6	R086	Ballad 2	R148	Country 3	T462	Crystal 6	T526	Soft Sax 14	T590	Electronic Glutar (Clean) 7
R025	16Beat 7	R087	Ballad 3	R149	Country 4	T463	Twin Bones 6	T527	Castanets 8	T591	Attack Barafon 9
R026	16Beat 8	R088	Ballad 4	R150	Country 5	T464	Crystal 7	T528	Didgeridoo 15	T592	Electric Vraphone 9
R027	Pop 1	R089	Ballad 5	R151	Jazz 1	T465	Soft Guitar 8	T529	Soft Sax 15	T593	Steel Bell 5
R028	Pop 2	R090	Soul Ballad	R152	Jazz 2	T466	Guitar Pinch 9	T530	Mute Barafon 16	T594	Mute Barafon 19
R029	Pop 3	R091	6/8 Ballad	R153	Jazz Waltz	T467	Attack Clav. 6	T531	Soft Guitar 10	T595	Chorus Guitar. 7
R030	Pop 4	R092	Acoustic Ballad	R154	Jazz Ballad	T468	Bodhran 6	T532	Soft Accord 8	T596	Soft Clav. 10
R031	Pop 5	R093	Colour Ballad	R155	Lounge	T469	Suona 7	T533	Wind Organ 9	T597	Viola Attack 8
R032	Pop 6	R094	Guitar Ballad	R156	Jive	T470	Chorus Guitar. 3	T534	Didgeridoo 16	T598	Church Bells 8
R033	Pop 7	R095	Piano Ballad	R157	Ragtime	T471	Slow Violin 4	T535	Electronic Glutar (Clean) 5	T599	Soft Santur 8
R034	Pop 8	R096	Organ Ballad	R158	Charlston	T472	Clavi 9	T536	English Horn 11	T600	Wind Organ 10
R035	Pop 9	R097	Groove 1	R159	Big Band	T473	Castanets 6	T537	Soft Sax 16	T601	Indian Flute 11
R036	Pop 10	R098	Groove 2	R160	Swing	T474	Slow Violin 5	T538	Soft Guitar 11	T602	Tsugaru 10
R037	Pop 11	R099	Groove 3	R161	Caribbean	T475	Jazz Organ 10	T539	Hard Barsoon 8	T603	Dulcimer 10
R038	Pop 12	R100	Groove 4	R162	Reggae	T476	Jazz Organ 11	T540	Kalimba 9	T604	Grow Guitar 9
R039	Pop 13	R101	Groove 5	R163	Cha Cha	T477	Electric Vraphone 8	T541	Koto 8	T605	Tubular Bells 6
R040	Pop 14	R102	Groove 6	R164	Rumba	T478	Bodhran 7	T542	Soft Clav. 6	T606	Jungle Bass 8
R041	Pop Bolero	R103	Groove 7	R165	Samba	T479	Steel Bell 2	T543	Xylophone 7	T607	Dulcimer 11
R042	Pop BossaNova	R104	Groove 8	R166	BossaNova	T480	Synth Harpsi. 5	T544	Soft Clav. 7	T608	Organ Flute 6
R043	Pop Waltz	R105	Groove 9	R167	Mambo	T481	Marimba 6	T545	Church Bells 6	T609	Nay 11
R044	Pop Dance	R106	Piano 1	R168	Salsa	T482	Marimba 7	T546	Kawala 10	T610	Attack Barafon 10
R045	Motown	R107	Piano 2	R169	Beguine	T483	Attack Barafon 7	T547	Didgeridoo 17	T611	English Horn 13
R046	British Pop 1	R108	Piano 3	R170	Cumbia	T484	Castanets 7	T548	Kalimba 10	T612	Suona 8
R047	British Pop 2	R109	Piano 4	R171	Latin	T485	Hard Vibe 9	T549	Castanets 9	T613	Reed Organ 5
R048	British Pop 3	R110	Piano 5	R172	Baroque	T486	Tron Flute 7	T550	Didgeridoo 18	T614	Shamisen 8
R049	Guitar Pop	R111	Piano 6	R173	Bolero	T487	Soft Accord 7	T551	Bodhran 8	T615	Koto 10
R050	Slow Pop	R112	Piano 7	R174	Holly Wood	T488	Shanai 6	T552	English Horn 12	T616	Shamisen 9
R051	50's Pop	R113	Piano 8	R175	Foxtrot	T489	Woodblock 9	T553	Hard Vibe 10	T617	Church Bells 9
R052	80's Pop	R114	Piano 9	R176	Paso Doble	T490	Soft Sax 10	T554	Bodhran 9	T618	Nay 12
R053	Rock 1	R115	Piano 10	R177	Quick Step	T491	Slow Violin 6	T555	Indian Flute 10	T619	Hard Barsoon 9
R054	Rock 2	R116	Unplugged 1	R178	Bachata	T492	Soft Sax 11	T556	Dulcimer 9	T620	Slow Violin 7
R055	Rock 3	R117	Unplugged 2	R179	Boston	T493	Chorus Guitar. 4	T557	Soft Clav. 8	T621	Soft Sax 17
R056	Rock 4	R118	Unplugged 3	R180	Tango	T494	Attack Clav. 7	T558	Viola Attack 5	T622	Grow Guitar 10
R057	50's Rock	R119	Unplugged 4	R181	Waltz	T495	Reed Organ 2	T559	Attack Harp	T623	Attack Harp 2
R058	60's Rock 1	R120	Unplugged 5	R182	March	T496	Viola Attack 4	T560	Mute Barafon 17	T624	Suona 9
R059	60's Rock 2	R121	Unplugged 6	R183	Polka	T497	Koto 7	T561	Tenor Sax 8	T625	Nay 13
R060	70's Rock	R122	Unplugged 7	R184	Classical 1	T498	Tsugaru 8	T562	Twin Bones 7	T626	Synth Harpsi. 8
R061	80's Rock	R123	Unplugged 8	R185	Classical 2	T499	Bag Pipe 10	T563	Chorus Guitar. 6	T627	Didgeridoo 19
R062	Big Rock	R124	Dance 1	R186	China Folk 1	T500	Attack Clav. 8	T564	Shanai 7	T628	Nay 14
						T501	Tron Flute 8	T565	Kalimba 11	T629	Synth Harpsi. 9
						T502	Marimba 8	T566	Jungle Bass 6	T630	Soft Sax 18