


尺寸:65*90mm

中文
中文


使用说明书
使用请阅读说明书



无线耳机与手机连接方法：
1. 请将耳机和手机（或连接设备）距离控制在1m范围内，距离越近越好。
2. 长按多功键约3秒，耳机提示灯红蓝灯交替闪，语音提示“开机”。
3. 打开手机或其他所需连接的设备的无线搜索功能，手机上会显示出耳机的产品型号。
4. 点击产品型号会自动与手机连接，指示灯灭，语音提示“已连接”。
5. 无线耳机的配对时间为5分钟，超时自动关机。如还需要连接手机，请重新按照1至4步骤操作，直到无线连接成功。



耳机连接指南



无线耳机与手机连接方法：

1. 请将耳机和手机（或连接设备）距离控制在1m范围内，距离越近越好。
2. 长按多功键约3秒，耳机提示灯红蓝灯交替闪，语音提示“开机”。
3. 打开手机或其他所需连接的设备的无线搜索功能，手机上会显示出耳机的产品型号。
4. 点击产品型号会自动与手机连接，指示灯灭，语音提示“已连接”。
5. 无线耳机的配对时间为5分钟，超时自动关机。如还需要连接手机，请重新按照1至4步骤操作，直到无线连接成功。

耳机功能操控指南



多功按钮

① 开机	长按多功键约3秒
② 关机	长按多功键约5秒
③ 播放/暂停	单击多功键
④ 接听电话	单击多功键
⑤ 挂断电话	单击多功键
⑥ 拒接电话	长按多功键约2秒
⑦ 加音量	双击音量由低到高（音量未满时）
⑧ 减音量	双击音量由高到低（音量满时）
⑨ 上一曲	三击上一曲（切到第一首后循环）
⑩ 下一曲	三击下一曲（切到最后一首后循环）
⑪ 打开/关闭语音助手	长按MFB键3秒（单击退出）
⑫ 中英文语言切换	开机未连接的状态下双击多功键

静音通话：

1. 耳机在通话状态下，连续点击三次多功键。
2. 耳机自动屏蔽麦克风的声音输出，语音提示“滴滴”声。
3. 再次三击恢复正常通话状态，单击则直接挂断。

产品参数



耳机基本参数

蓝牙版本：V 6.0
有效距离：10m(无障碍)
电池容量：90毫安
声道系统：立体声



充电基本参数

输入电压：DC 5V±1A
工作频率：2.4G

常见问题

我的耳机是否可用于支持该无线版本和功能的设备。有关规格的信息，请参阅耳机规格。	您的耳机可用于支持该无线版本和功能的设备。有关规格的信息，请参阅耳机规格。
通话时为什么听到静电或干扰声音？	无线电话和无线网络设备一类的设备可能会产生干扰，通常听起来像静电或躁声。要降低干扰，请勿将耳机靠近其他使用或发出无线电波的设备。
耳机会干扰车上的电子设备、收音机或计算机吗？	该耳机产生的功率远低于普通手机产生的功率。此外，它发出的信号完全符合国际无线标准。因此，您不必担心会干扰标准的消费品或电子设备。
其他无线耳机用户可以听到我的通话吗？	耳机与手机对话时，仅会在这两个无线设备之间建立加密链接。就传输功率而言，无线信号远低于普通手机信号的功率，因此第三方难以监听耳机所采用的无线技术。
在通话时为什么会听到回声？	调节耳机音量，或移动其他区域后再试。
如何清洁耳机？	用干的软布擦拭。
耳机无法充满电？	耳机可能未接好。请检查耳机接触是否正常，然后重新连接并给耳机充电。
我无法使用中所述的部分功能。	可用的功能可能随连接的设备的不同而不同。若耳机一次连接到两部设备，部分功能可能不可用。

注意事项

储存与维护

本产品应存放在阴凉干燥处。工作温度在0-38°C。日常清洁请用柔软干布清洁。不管任何时候都不要拆开你的耳机，因为这样做可能损坏耳机或导致电池自燃。请让产品远离热源或其它具有腐蚀性液体，避免在任何高温场所使用或放置。如果本产品的任何部件受损、发烫，请立即停止使用本产品。避免使耳机淋雨或放入液体之中。长时间不使用，请在使用前再次充电。

佩戴使用须知

有少数人会对特定材质产生特殊反应，当处于某些环境中，与肥皂、汗液、防晒霜等产品对皮肤有潜在刺激性物质长期接触时，可能会引起皮肤过敏反应。为减少皮肤刺激风险，请不要将产品穿戴在皮肤有伤的身体部位。如果您的皮肤出现发红、肿胀、发痒或任何其他刺激反应，请您立即停止佩戴，并向生产商咨询。

电磁干扰提示


有明文规定禁止或不宜使用无线设备的场所（例如，某些地区的机场、医疗场所等），请勿使用本产品，否则会干扰其它电子设备或导致其它危险。部分电子设备可能使本产品的无线电信号出现故障（如，部分汽车电子设备）。请联系该电子设备制造商咨询详细信息。

听力损伤

过高音量下听音乐可能会损伤您的听力，声音也可能丢失。

电池使用

用错误型号的电池组替换，可能会使安全防护失效。将电池组投入火中或加热炉中，或对电池组进行机械挤压或切割的处理可能会导致爆炸。将电池组放置在极高温度环境中，可能导致爆炸或泄漏可燃液体或气体。电池组承受极低气压，可能导致爆炸或泄漏可燃液体或气体。若出现严重鼓胀，请勿继续使用！



充电安全须知

建议充电器提供的功率必须在无线电设备所需的最小[0.5]瓦和最大[5.5]瓦之间，以达到最大充电速度。

英语
English


User Manual
Please read the instructions for use



Wireless headset and mobile phone connection:

1. Please keep the distance between the wireless headset and the mobile phone (or connected device) within 1 meter, the closer the better.
2. Press and hold the multi-function button for about 3 seconds, the headset indicator light will flash red and blue alternately, and the voice will prompt “Connect”.
3. Turn on the wireless search function of the mobile phone or other device you want to connect to, and the model of the headset will be displayed on the phone.
4. Click the product model to automatically connect to the mobile phone, the indicator light goes out, and the voice prompt “Connected” is heard.
5. The pairing time of the wireless headset is 5 minutes, and it will automatically shut down after the timeout. If you need to connect to a mobile phone, please follow steps 1 to 4 again until the wireless connection is successful.
6. When the headset is in a call state, click the multi-function button three times in a row.
7. The headset automatically blocks the sound output of the microphone, and the voice prompt “beep” sounds.
8. Click three times again to resume normal call status, and click once to hang up directly.

Function Introduction



Headphones Connection Guide



Wireless headset and mobile phone connection:

1. Please keep the distance between the wireless headset and the mobile phone (or connected device) within 1 meter, the closer the better.
2. Press and hold the multi-function button for about 3 seconds, the headset indicator light will flash red and blue alternately, and the voice will prompt “Connect”.
3. Turn on the wireless search function of the mobile phone or other device you want to connect to, and the model of the headset will be displayed on the phone.
4. Click the product model to automatically connect to the mobile phone, the indicator light goes out, and the voice prompt “Connected” is heard.
5. The pairing time of the wireless headset is 5 minutes, and it will automatically shut down after the timeout. If you need to connect to a mobile phone, please follow steps 1 to 4 again until the wireless connection is successful.
6. When the headset is in a call state, click the multi-function button three times in a row.
7. The headset automatically blocks the sound output of the microphone, and the voice prompt “beep” sounds.
8. Click three times again to resume normal call status, and click once to hang up directly.

Headphone Function Control



① Power on	Long press the multi-function key for about 3 seconds
② Power off	Long press the multi-function key for about 5 seconds
③ Play/Pause	Single click the multi-function key
④ Answer a call	Single click the multi-function key
⑤ Hang up a call	Single click the multi-function key
⑥ Reject a call	Long press the multi-function key for about 2 seconds
⑦ Increase volume	Double click to change the volume from low to high (when the volume is not full)
⑧ Decrease volume	Double click to change the volume from high to low (when the volume is full)
⑨ Previous song	Triple click to go to the previous song (switch to the first song and loop)
⑩ Next song	Triple click to go to the next song (switch to the last song and loop)
⑪ Turn on/off voice assistant	Long press the MFB key for 3 seconds (single click to exit)
⑫ Switch between Chinese and English	Double click the multi-function key when the device is powered on or not connected

Mute call:

1. When the headset is in a call state, click the multi-function button three times in a row.
2. The headset automatically blocks the sound output of the microphone, and the voice prompt “beep” sounds.
3. Click three times again to resume normal call status, and click once to hang up directly.

Product Parameters



耳机基本参数

蓝牙版本：V 6.0
有效距离：10m(无障碍)
电池容量：90毫安
声道系统：立体声



充电基本参数

输入电压：DC 5V±1A
工作频率：2.4G

Please Notes

Storage and maintenance

This product should be stored in a cool and dry place. The operating temperature is 0-38°C. Please use a soft cloth for daily cleaning. Never disassemble your headphones at any time, as doing so may damage the headphones or cause the battery to self-ignite. Keep the product away from heat sources or other corrosive liquids, and avoid using or placing it in any high-temperature places. If any part of this product is damaged or hot, please stop using this product immediately. Avoid exposing the headphones to rain or immersion in liquids. If not used for a long time, please charge them again before use.

Instructions for wearing and use

A small number of people will have special reactions to specific materials. When in certain environments, contact with potentially irritating substances to the skin such as soap, sweat, and UV protection products may cause allergic reactions.

To reduce the risk of skin irritation, please do not wear the product on parts of the body with skin irritations. If your skin becomes red, swollen, itchy, or has any other irritation, please stop wearing it immediately and consult a doctor.

Electromagnetic Interference Tips
Do not use this product in places where wireless devices are prohibited or inappropriate (e.g., airports, medical facilities, etc.). Otherwise, it may interfere with other electronic devices or cause other dangers. Some electronic devices may malfunction due to radio interference from this product (for example, some car audio devices). Please contact the manufacturer of the electronic device for details.

Hearing Damage

Listening to music at too high a volume may damage your hearing and the sound may be distorted.

Battery Use

Replacing the battery pack with the wrong model may render the safety protection ineffective. Putting the battery pack in a fire or heating furnace, or mechanically squeezing or cutting the battery pack may cause explosion or fire. Putting the battery pack in an extremely high temperature environment may cause an explosion or flame of gases.

Exposing the battery pack to extremely low air pressure may cause an explosion or fire of flammable liquids or gases. Do not expose the battery pack to extreme low air pressure or gases. Do not continue to use it if it is severely swollen.

Charging Safety Tips

It is recommended that the power provided by the charger must be between the minimum [0.5] watts and the maximum [5.5] watts required by the radio device to achieve maximum charging speed.



FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.