

## 1. Photographs of Conducted Emissions Test Configuration

Adapter Mode




Front view



Side view

**Under table view**



**USB Mode**



**Front view**



**Side view**

**Under table view**




## 2. Photographs of Radiated Emissions Test Configuration


For radiated emissions 9kHz~30MHz

Adapter Mode


Front view




Rear view



USB Mode




Front view



Rear view

For radiated emissions 30MHz~1GHz  
Adapter Mode


Front view




Rear view



USB Mode



Front view



Rear view

————THE END————