

Ambient Light

Press cycle through designated colors. Long press: turn off the light.

Auto-shutoff Timer

Press, sets the auto-shutoff timing duration in the 0-2H cycle, every time you press increase 1h. In other modes, a short press will display the current timing time.

Filter level

When the filter needs replacement, the red filter light will illuminate. Long press for 3 seconds until the buzzer beeps once to reset the filter life to 100%.

Display Icons

Icons	Description	Light Status
	1. Display: humidity, humidity, connect settings, timing time setting, light setting.	1. White light: Default display of humidity
	2. Displays the humidity level and ambient light setting when timing setting returns to humidity display after 5s.	2. Displays the humidity level and ambient light setting when timing setting returns to humidity display after 5s.
	3. Displays time when setting, then returns to humidity display after 5s.	3. Displays time when setting, then returns to humidity display after 5s.

Cleaning & Storage Instructions

Work Cleanly

- Remove the humidifier main unit and filter from the water tank.
- Rinse the water tank with clean water until all dirt and dust are gone from the inner walls.

Humidifier Main Unit Cleaning

After cleaning, dry towel to gently wipe the surface of the humidifier main unit or use a vacuum cleaner to remove dust from the surface until all dust is gone. Do not disassemble the humidifier main unit for cleaning!

Filter Cleaning

1. Remove the humidifier main unit from the water tank and take out the filter.

2. Remove the filter from the bracket.

3. Wash the filter under a tap or place it in a washing machine.

4. After cleaning, rinse the parts before using the humidifier.

Storage

When not using the humidifier for an extended period, empty the water tank and let the filter dry using a fan. Dry the filter, and then store the humidifier in a dust-proof storage bag.

App Installation

1. Download the **Hydricap** app from App Store (iOS device) or Google Play (Android device).

2. Register your account via email. After registration is completed, enter "Home", and select "Add device". "Humidifier", "Must be the Smart Humidifier".

3. Follow the on-screen instructions to add the Humidifier.

4. Add humidifier to control main functions.

FAQ

Problems	Possible Solution
No mist output.	This humidifier uses evaporative mist-free technology to prevent damages around the humidifier. The humidification process will not produce visible mist, so please use it with confidence.
The air does not seem to be humid.	Please increase the humidification level or increase the set humidity range. Clean the humidifier before using it again.
Humidifier won't turn on or power off.	Check if the power adapter is properly plugged into the socket and ensure it is not loose. Check for any damage to the adapter; if requesting a replacement, please contact customer service.
Humidifier leaks.	Please check whether the water tank is damaged. If not, please stop using the humidifier until a new water tank is replaced.

WIFI/BT Connection

Connecting white light (Wi-Fi). Online white light is always on.

Smart Thermo

Connect connection white light is always on.

Filter Cleaning

Red light always on; it lights up after the filter needs to be replaced for 1500 hours.

Humidifier Main Unit Cleaning

After cleaning, dry towel to gently wipe the surface of the humidifier main unit or use a vacuum cleaner to remove dust from the surface until all dust is gone. Do not disassemble the humidifier main unit for cleaning!

App Installation

1. Download the **Hydricap** app from App Store (iOS device) or Google Play (Android device).

2. Register your account via email. After registration is completed, enter "Home", and select "Add device". "Humidifier", "Must be the Smart Humidifier".

3. Follow the on-screen instructions to add the Humidifier.

4. Add humidifier to control main functions.

FAQ

Problems	Possible Solution
No mist output.	This humidifier uses evaporative mist-free technology to prevent damages around the humidifier. The humidification process will not produce visible mist, so please use it with confidence.
The air does not seem to be humid.	Please increase the humidification level or increase the set humidity range. Clean the humidifier before using it again.
Humidifier won't turn on or power off.	Check if the power adapter is properly plugged into the socket and ensure it is not loose. Check for any damage to the adapter; if requesting a replacement, please contact customer service.
Humidifier leaks.	Please check whether the water tank is damaged. If not, please stop using the humidifier until a new water tank is replaced.

Humidifier won't turn on or power off frequently.

Check for foreign objects in the intake or outlet and remove them.

The high-level humidification setting may increase the separation between the humidifier and the receiver.

The filter has been used for a long time. Please clean or replace the filter in time and press and hold "3" for 3 seconds to recharge the filter.

The water in water tank is consumed quickly.

Odor occurs when the humidifier is working.

Humidifier leaks.

Humidifier won't turn on or power off frequently.

Check for foreign objects in the intake or outlet and remove them.

The high-level humidification setting may increase the separation between the humidifier and the receiver.

The filter has been used for a long time. Please clean or replace the filter in time and press and hold "3" for 3 seconds to recharge the filter.

The water in water tank is consumed quickly.

Odor occurs when the humidifier is working.

Humidifier leaks.

Humidifier won't turn on or power off frequently.

Check for foreign objects in the intake or outlet and remove them.

The high-level humidification setting may increase the separation between the humidifier and the receiver.

The filter has been used for a long time. Please clean or replace the filter in time and press and hold "3" for 3 seconds to recharge the filter.

The water in water tank is consumed quickly.

Odor occurs when the humidifier is working.

Humidifier leaks.

材质：250G双铜版纸

折好尺寸：105*150mm

装订方式：风琴折页

印刷风格：黑白印刷