

THE  
FOURTH SPACE  
CYBERSTAKE AIR CONDITION

使用前請仔細閱讀此說明書  
Please read this manual carefully before use

### 简介



产品净重: 600g (不含电池)  
产品尺寸: 93\*61\*15mm

基本消息

在使用前，請認清國家本品的用戶手冊，以保  
持用戶手冊要與裝置以每日為參考。在道从法律  
利益于您的良好，我们会不断寻找能保护和升级  
和设置流程，还清除错误，如你发现信息差异，还  
请提交问题-微信公号，以获取最新的产品信息。

用戶使用手冊

### 3. Warning

- The operation of the product host button and remote control should not completely turn off the air conditioning power. If the air conditioner is not used for a long time, please unplug the power plug.

⚠ Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help.

This air conditioner is produced by Fourth Space Co., LTD.  
Service hotline: 400-616-7796

## User Manual

Please read the user manual of this product carefully before use to ensure you  
after full understanding. After reading, please keep the user manual for fu-  
ture reference. In the case of complying with laws and regulations, our company re-  
serves the right of final interpretation.

We are constantly iterating and upgrading our products, which may change  
different program software in the process. If you find any discrepancies in the  
process, please contact our customer service staff directly, or follow T  
space-WeChat official account to obtain the latest product  
information.

Thank you for your understanding and support.

## 1. Product Specification

Basic Information  
Product Name: Cybertake Remote Control  
Product model: YK-01  
Rated voltage: DC 3V  
Net weight of product: 600g (excluding battery)

## 2.Remote Control Instructions

The following content is only applicable to the remote control version. If you have any questions, please contact customer service directly.

## 2.1 Introduction to remote control buttons



## 2.2 Introduction to Remote Control Display Screen Icons

The diagram illustrates a fuzzy inference system for an air conditioning controller. It consists of three input variables at the bottom: 'Room Temperature' (range 16-30), 'Room Humidity' (range 30-80), and 'Room Air Speed' (range 0.5-1.5). Arrows from these inputs point to a central 'Fuzzy Inference Function' block. From the top of this block, three arrows point to a 'Defuzzification Function' block. The outputs of the defuzzification function are 'Air Speed Function', 'Energy saving mode', and 'Heating Function'.

### 2.3 Operating instructions

- **Matching connectors:**
  - ① Install the battery into the remote control and turn on the remote control;
  - ② When the air conditioner is turned on, press and hold the ECO button on the conditioner for 6 seconds to enter pairing mode. When -- is displayed on the screen, press any key on the remote control to complete the matching.
- **On/Off button:** Press and hold for 1 second to turn on the air conditioner, and press and hold for 2 seconds to turn off the air conditioner.

- Function button:**  
Short press the function button to select cooling, dehumidification, air supply, and heating functions;  
Note: The heating function is applicable to both cold and warm models. Please contact customer service for more information.
- Mode selection:** In the cooling function,  
Can choose MAX mode, ECO+sleep mode, ECO energy-saving mode, and AUTO mode;  
Short press the MAX button once to enter MAX mode, and short press again to enter AUTO mode;  
Short press the ECO button once to enter ECO+sleep mode; short press twice to enter ECO energy-saving mode; short press three times to enter AUTO mode;

- **Timer button:** Can be set to turn off the air conditioning at a fixed time within 0-12 hours; Short press to increment, long press to scroll through numbers; After completing the timer setting, press and hold the timer button for 2 seconds to reset the timer to zero and reset it; When the air conditioner, press the timer button twice in a row can directly time for 1 hour


- **Light on/off button:** Short press the light button to turn on/off the screen and the power indicator light on the air conditioner.
- **Wind speed increase/reduce button:** There are a total of 6 levels of wind speed, which can be adjusted by short pressing the increase/reduce button.
- **Temperature increase/reduce button:** Short press the temperature increase/reduce button to adjust the temperature. The temperature setting range is:  
Cooling Function: 16~28℃, with an interval of 1℃,  
Heating Function: 29~32℃, with an interval of 1℃.

- Screen display functions:

- **Temperature and humidity display:**

- **Magnetic adsorption function:**  
The remote control is equipped with a built-in magnet, which can be directly magnetically attached to any magnetic object to avoid loss.

- **Power supply:** Use 2 pieces LR03 AAA (1.5V) batteries.



2.5 Note:

- This remote control is not waterproof and should not be submerged in water.
- When not using the remote control for a long time, please remove the battery.
- Please replace the batteries according to the specified model and dispose of the used batteries in accordance with relevant national regulations.