

三折页（A4大小291\*160mm，折后97\*160mm）

正面



Floor lamps are a popular choice for living rooms, bedrooms, and homeoffices, as they can be easily positioned to provide liaht where it is neededWe are committed to producing high quality products and we hopethat every buyer who chooses us will have a satisfactory shoppingexperience.

Having trouble?

Please do not rush refund/returns  
Please contact us:  
Telephone: (725) 255-2966  
Email: support001@keepsmile.vip  
We will help you solve the problem!

Troubleshooting

1. The remote control does not work

- a. Check if the remote control battery has power.
- b. Reset the remote control, then re-pair it.

Reset the remote:

Within 30 seconds after power-on, long press the turn on/off button on the pole for 3-5 seconds. Reset the remote successfully when the lamp fast flashes.

Re-pairing:

Within 30 seconds after power-on, long press the turn on/off button on the top right of the remote for 3-5 seconds. Re-pair the remote successfully when the lamp fast flashes.

2. Other issues.

Please call or email us, we will provide you with a satisfactory solution.

Packing List

Lamp Head with pole	1
Iron Poles	3
Heavy Base	1
Power Adapter with Cable	1
Remote Controller	1
User Manual	1

Installation


Step1:

Check if all the parts are completely. Place them neatly to avoid wires twisting. Connect the power adapter to check if floor lamp work normally.




Warning

Be sure to test before installing. Any questions, please feel free to contact us by email or phone



Check if all the parts are completely.Place them neatly to avoid wires twisting which may cause poor wire contact.



Connect the wires on the pole with the power adapter.Plug in, to check if they work normally.


背面

Step2:

Assemble the Floor Lamp in the order of ①-⑦（As illustrated）


1. Connect all Iron poles and Lamp Head in order ①-④ by spinning clockwise
2. Connect the Base with the Iron pole by spinning clockwise. (④ and ⑤)
3. Connect Power Cable and Power Adapter (⑥ and ⑦)

- ① Lamp Head
- ②-④ Iron poles
- ⑤ Base
- ⑥ Power Cable
- ⑦ Power Adapter




Control Manner

Control Button



12 Keys RF Remote Control

12Keys RF remote is portable and magnetic. Put on the pole and it could be sucked on it tightly.



WARNING:

1. Indoor use only.It is non-waterproof.
2. Please use the packaged adapter to meet the working power requirement.
3. Power off before installation, cleaning and idle.
4. Please do not use it in humid environments or at high temperatures.
5. Please do not use it while exceeding the voltage , the proper voltage of US is AC110- 120V , 50-60Hz.
6. Please do not plug or unplug the power cord with wet hands , keep it in a dry environment.
7. Please stop using it if there are any defective issues found in the product.

Specification

Input Voltage	AC100-240V, DC 24V
Color Temperature	3000K-6500K
Max Luminous Flus	1000LM
Controlled by	Remote/Button
Height	69in
Beam Angle	360 degree
Material	Iron+Plastic
Wattage	12W

FCC Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.



Made in China

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.