


# 60\*100mm (正反面)

### 咪丝乳夹震动器



18岁及以上用户使用  
回收标志  
WEEE标志  
RoHS标志  
CE标志  
FCC ID: 2B2H2X-HB2409

使用说明书

#### 清洗、存放和安全

每次使用前后都要彻底清洗本产品。建议您使用优质水溶性润滑油。如我们配送的清洁剂。如果您没有清洁剂，您还可以使用温水和优质除菌香皂清洗产品机身，然后用干净的温水冲洗。最后用干爽的无纺布或毛巾轻轻拍打至完全干燥为止。

- 请勿使用酒精、汽油或丙酮的清洁剂。
- 请勿将产品直接放到沸水锅中。
- 请避免阳光直射，同时切勿将产品暴露在高温下。


#### 包装清单

产品1对	遥控器1个
说明书1张	USB充电线1条

#### 产品规格


产品名称	咪丝	产品型号	HB2409
产品尺寸	66*19.4*68mm	防水性能	生活防水
产品材质	环保硅胶+ABS	最大噪音	≤55分贝
产品颜色	粉色、橙色、红色	供电方式	USB充电
电池容量	120mAh	额定电压	3.7 V
充电时间	60分钟	使用时间	60分钟
产品功能	10频震动	产品用途	自慰、调情

#### 产品示意图及使用方法



开关按键  
频率增加键  
遥控开关键  
频率减少键  
充电口

#### 产品尺寸



66.0  
19.4  
68.0


#### 充电注意事项

- /请先关闭产品,然后连接USB充电线。
- /插拔充电线时请保持双手干燥。
- /充电过程中,LED灯持续闪烁。充电完成后,LED灯停止闪烁。
- /充电时无法启动振动器。

#### 防伪验证

- (1) 请查看产品包装盒上的防伪标,刮开防伪标上的涂层后,得到该产品的防伪标。
- (2) 扫描产品包装盒上面的二维码查询。
- (3) 企业标准:Q/441900HBWL001-2022
- (4) 电话查询400-6142-315。
- (5) 短信查询918#防伪码至12114查询。

### Breast clamp vibrator



18岁及以上用户使用  
回收标志  
WEEE标志  
RoHS标志  
CE标志  
FCC ID: 2B2H2X-HB2409

User's Guide

#### Cleaning, Storage and Safety

Please clean it with neutral soap and water before and after each use (it is recommended to use a special cleaner for sex toys), then wipe it gently with a dry non-woven cloth or towel, and then let it air dry until it is completely dry. Finally, store this product in a cool, ventilated, and dry place until next use.

- Do not use alcohol, gasoline or acetone cleaners.
- Do not put the product directly into the boiling water pot.
- Please avoid direct sunlight and never expose the product to high temperatures.


#### Package list

1 pair × Product  
1 pcs × Remote control  
1 pcs × USB Charging Cable  
1 pcs × User Manual

#### Product Specifications

Name	Misi vibrator	Model	HB2409
Material	Silicone+ABS	Waterproof	Life waterproof
Size	66*19.4*68mm	Max noise	≤55dB
Color	Pink, Orange, Red	Power by	USB charging
Usage	Masturbate Flirt	Rated voltage	3.7 V
Battery	120mAh	Charging time	60minutes
Function	10 vibration	Usage time	60minutes

#### Product functions & Usage



ON/OFF  
"+"

Switch Button  
"-"  
Charging port

#### Precautions

- (1) This nipple clamp vibrator has 10 different vibration modes and 3 adjustable clamping forces. It is soft and elastic, and the delicate touch feels like real skin to care for your delicate nipples. Spice up your sex life.
- (2) **Product switch button:** Press and hold for 3 seconds to turn on the phone, the LRD light will turn on. A short press can switch the vibration mode between 10 frequencies, and a long press for 3 seconds turns off the function.
- (3) **Remote control buttons:** **① Frequency increase button:** Short press when the product is turned on to increase the frequency. There are 10 frequency function cycles in total.  
**② Remote control switch key:** Short press to turn off all modes.  
**③ Frequency reduction key:** When the product is turned on, press it briefly to reduce the frequency. There are 10 functional cycles in total.
- (4) Easy charging via USB data cable or mobile phone adapter.
- (5) When charging, the LED light continues to flash; after fully charged, the LED light stops flashing.
- (6) The vibrator cannot be activated while charging.

#### FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
-Reorient or relocate the receiving antenna.  
-Increase the separation between the equipment and receiver.  
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
-Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. such modifications could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. This equipment complies with FCC's RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or conjunction with any other antenna or transmitter.

FCC ID:2B2H2X-HB2409

100mm

60mm