

Cooler Specifications:

Leak-Proof & Insulated
10 Liter Capacity
11.8w"x9.5h"x7.8d"

Speakers Specifications:

Output Watts: 6W
Driver Size: 57mm
Input Voltage: 5V

Frequency Response: 20Hz~20KHz
IPX Rating: IPX4
Bluetooth® Range: 30ft
BT IC Model/Version: AC6969/V5.3
Battery Capacity: 400mAh
Charging Port: Micro USB
Charging Time: 1-2 hours
Playing Time: 1-3 hours*
*Depends on individual use.

FCC NOTICE:

This device complies with Part 15 of the FCC Rules. Operation is subject to the two following conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation

FCC WARNING STATEMENT

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

TECHNICAL SUPPORT:

Please do not attempt to fix the product by yourself. If you are experiencing any problems with the product, please do not return it to the store you bought it from. You can contact our technical support representatives and they will assist you with any questions you might have.

For assistance operating your product, please consult the User's Manual first, then feel free to contact Merkury Innovations technical support!

Merkury Innovations

45 Broadway, 3rd Floor
New York, New York 10006
www.merkuryinnovations.com
E-mail: support@merkuryinnovations.com

© 2025 Merkury Innovations LLC

To explore our full selection of products, visit us at: www.merkuryinnovations.com
The illustrated product and specifications may differ slightly from that supplied.
The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc.
All other trademarks and trade names are those of their respective owners.
Made in China.

MERKURY
INNOVATIONS



CHILLTUNES

INSULATED COOLER + WIRELESS SPEAKER



USER MANUAL MI-IC101-148JCP

INCLUDES:


Cooler Bag,
Bluetooth® Speakers with Battery Box,
Charging Cable,
User Manual.

If you have any questions or problems e-mail: support@merkuryinnovations.com

If you have any questions or problems e-mail: support@merkuryinnovations.com

IMPORTANT: PLEASE READ THIS MANUAL CAREFULLY BEFORE USING THE PRODUCT

PRODUCT INTRODUCTION



CHARGING

- Please fully charge the battery case before its first use.
- Power Source: Operates using an internal rechargeable Lithium battery.
- Charging: Charge the battery case using the included Micro USB cable. Insert the USB end of the cable into a powered USB source, such as a computer, laptop, or USB AC adapter (not included).
- Charging Indicator: When charging, the indicator light will turn red.
- Charge Completion: Once fully charged, the red light will turn off.

OPERATION

- Plug the 3.5mm audio cable into the battery case.
- Turn your Bluetooth® speaker on by sliding the power switch to 'ON' position.
- The indicator light will begin to flash blue slowly. This indicates that the speaker is in pairing mode and is searching for your Bluetooth® device.
- Make sure the Bluetooth® function on your device is turned on.
- Search the speaker named, "MERKURY IC101".
- Once you have selected the speaker, your device will pair without a password.
- Once your speaker is paired, the indicator light will stop flash.
- Start playing music on your device. Make sure that you keep your device within a 33 feet range of your Bluetooth® speaker.
- Adjust the volume of your device to a comfortable level.
- Turn off the Bluetooth speaker when it is not in use.

RECONNECT BLUETOOTH®

- You only need to pair your Bluetooth® device with the speaker once.
- With your previously paired device's Bluetooth® turned on and in range, power on the speaker.
- The speaker will automatically reconnect to the last Bluetooth® device it was connected to.
- If you have a previously paired device that does not auto-reconnect, navigate to the Bluetooth® settings menu on your device, select "MERKURY IC101" from the list of paired Bluetooth® devices, press "forget this device," and then follow the instructions on how to pair the speaker to a Bluetooth® enabled device.

TROUBLESHOOTING

No power	Recharge your speaker using the included USB charging cable. Try using a different USB cable.
Music is not playing over Bluetooth®	Make sure your Bluetooth® device has A2DP profile. Check if both devices are paired and connected over Bluetooth®. Restart the speaker to reconnect your Bluetooth® device.
Bluetooth® device will not reconnect with the speaker	Navigate to your Bluetooth® settings menu on your Bluetooth® device, tap "MERKURY IC101," and select "Forget." Now follow the steps to pair your device again.

WARNING

- DO NOT submerge the speakers in water. This device is not intended to function properly after being underwater.
- This cooler bag is rated IPX4, which means the speakers can be splashed with water or left in the light rain (but not submerged in water). If the speakers get wet, it is recommended that you dry the speakers completely before using them again.
- This is not a toy. Please keep away from children.
- Low battery may cause poor connection and/or may cause the Bluetooth® function to not work.
- The cooler bag is designed to insulate, which means it will retain heat as well as cold. For this reason, try to store your cooler in a cool environment prior to loading it with ice. If stored in direct sunlight, a warm garage, or a hot vehicle prior to use, a significant amount of ice will be wasted cooing the cooler itself.

USER MANUAL MI-IC101-148JCP

INCLUDES:

Cooler Bag,
Bluetooth® Speakers with Battery Box,
Charging Cable,
User Manual.