



4.变换灯效  FN+INS 使键盘调节灯光模式 FN+DEL 切换单色颜色 FN+END 关闭/打开背光	6.回连 1.键盘开机默认上次连接的设备 2.FN+Q (FN+W, FN+E)白灯慢闪回连 *键盘必须曾经配对过该装置才可实现此功能	8.兼容系统 支持操作系统：ANDROID/ISO/Win XP/Win7/Win8/Win10/MAC	10.故障排除 1.确保将产品的USB无线接收器正确插入到电脑的USB端口。 2.确保电脑满足系统要求。 3.产品和无线接收器超出有效连接距离，请减少和接收器之间的距离。
5.充电  充电状态 默认界面下右上角出现充电指示动画 *1.灯亮工作电流420MA 可持续时间15小时左右(一直工作) *2.灯灭工作电流40MA 可持续时间80小时左右(一直工作) *3.待机电流0.5MA 待机时间180天左右 *4.键盘无动作2分钟进入待机模式 按任何键启动键盘进入工作模式	7.储存、使用环境  1.储存温度：-20°C~+70°C 2.工作温度：-20°C~+60°C 3.储存湿度：非凝结状态下相对湿度30%RH~95%RH	9.自定义驱动  扫码下载驱动程序或： www.ckiller.cn 温馨提示：驱动程序仅支持有线模式下自定义	7 8

FN组合功能键(WIN系统)  FN + Esc 长按3s恢复出厂设置 FN + 1 多媒体 FN + 2 音量减 FN + 3 音量加 FN + 4 静音 FN + 5 上一曲 FN + 6 下一曲 FN + 7 暂停播放 FN + 8 CD Stop (停止)	FN组合功能键(WIN系统)  FN + T 切换线模式 FN + Win 锁WIN键 FN + Back 查询电量 (无线模式下电池供电有效) FN + INS 主背光灯效切换 FN + TAB 屏主界面与自定义界面切换 FN + Q 短按切换蓝牙1，长按蓝牙1配对 FN + W 短按切换蓝牙2，长按蓝牙2配对 FN + UP 屏显查询(循环) FN + I . FN + E 短按切换蓝牙3，长按蓝牙3配对	FN组合功能键(MAC系统)  FN + Esc 长按3s恢复出厂设置 FN + 1 显示器亮度减 FN + 2 显示器亮度加 FN + 3 平铺展开当前活动的多个窗口 FN + 4 直接进入应用程序主界面 FN + 5 键盘背光亮度减 FN + 6 键盘背光亮度加 FN + 7 上一曲 FN + 8 暂停播放	FN组合功能键(MAC系统)  FN + T 切换有线模式 FN + Win 锁WIN键 FN + Back 查询电量 (无线模式下电池供电有效) FN + INS 主背光灯效切换 FN + TAB 屏主界面与自定义界面切换 FN + Q 短按切换蓝牙1，长按蓝牙1配对 FN + W 短按切换蓝牙2，长按蓝牙2配对 FN + UP 屏显查询(循环) FN + I . FN + E 短按切换蓝牙3，长按蓝牙3配对
9 10 11 12			

<p><b>CooKiller</b> CK 68Mechanical keyboard</p> <p><b>List of contents:</b></p> <p>specification x 1 Ammunition box x 1 Double head key extractor x 1 Mechanical keyboard x 1 Air spring data cable x 1</p>	<p><b>CK 68specification</b></p> <p>Product name: CK 68 Key count: 69 Light: RGB light effect Connection port: USB Type-C Mode: Three modes PCB: Support for hot swap Mute cotton: Two sheets of silicone mute cotton + shaft underpad Product weight: 980g Product size: 350*120*43mm</p>	<p><b>Quick Start Guide</b></p> <p>If you are a MAC user, flip the switch to switch to a MAC system (After the conversion is successful, the lower left corner of the screen is MAC by default.)</p> <p>If you are a WIN user, please flip the system conversion switch to WIN (After successful conversion, the lower left corner of the screen is WIN by default.)</p> <p>① Power switch (built-in lithium battery) ② System transfer switch</p>	<p><b>1.Bluetooth connection</b></p> <p>Short press FN+Q/W/E and long press FN+Q/W/E Put the keyboard into pairing mode The keyboard pairing name: CK 68 5.0/CK 68 3.0 Long press Q/W/E and the light will flash. After the pairing is successful, the Q/W/E key is on for 2 seconds and the backlight is restored (The Bluetooth logo is in the lower right corner of the screen in the default interface)</p> <p><b>2.Connecting wire</b></p> <p>Short press FN+T and long press FN+T Set the keyboard to wired mode Long press T button after the white light flash, After the pairing is successful, T key is on for 2 seconds and the backlight is restored By default, the lower right corner of the screen is </p>
13	14	15	16

<p><b>4.Switching effect</b></p> <p>FN+INS Enable keyboard to adjust light mode FN+DEL Switch monochromatic colors FN+END Turn off/on the backlight</p>	<p><b>6.Back connection</b></p> <p>1.Keyboard startup defaults to the last connected device 2.FN+Q (FN+W, FN+F) White slowly blinking connection *The keyboard must have been paired with the device for this function</p>	<p><b>8.Compatible system:</b></p> <p>Support operating system: ANDROID/ISO/Win XP/Win7/Win8/Win10/MAC</p>	<p><b>10.troubleshooting</b></p> <p>1.Make sure your product's USB wireless receiver is properly plugged into the USB port on your computer. 2. Ensure that the computer meets system requirements. 3.The product and the wireless receiver are beyond the effective connection distance, please reduce the distance between the product and the receiver.</p>
<p><b>5.charge</b></p> <p>Charging status The charging indicator animation appears in the upper right corner of the default screen *1,Lamp working current 220MA sustainable time about 15 hours (working all the time) *2,Lamp off working current 40MA sustainable time about 80 hours (always working) *3,Standby current 0.5MA Standby time about 180 days *4,Enter standby mode. Press any key to start the keyboard and enter working mode.</p>	<p><b>7.Storage and use environment</b></p> <p>1.Storage temperature: -20°C~+70°C 2.Operating temperature: -20°C~+60°C 3.Storage humidity: The relative humidity in the non-condensing state is 30%-95% RH</p>	<p><b>9.Custom driver</b></p> <p>Scan code to download the driver or: <a href="http://www.cookiller.cn">www.cookiller.cn</a> Warm tip: The driver only supports wired mode customization</p>	<p>17</p> <p>18</p> <p>19</p> <p>20</p>

<p><b>FN Combination key (WIN system)</b></p> <table border="0"> <tr> <td></td><td>Switch wire mode</td><td></td><td>PRTSC</td></tr> <tr> <td></td><td>multimedia</td><td></td><td>le</td></tr> <tr> <td></td><td>Volume reduction</td><td></td><td>MyComputer</td></tr> <tr> <td></td><td>Volume plus</td><td></td><td>Calculator</td></tr> <tr> <td></td><td>mute</td><td></td><td>Switch between the home screen and the custom screen</td></tr> <tr> <td></td><td>Previous song</td><td></td><td>Short press to switch Bluetooth 1 and long press Bluetooth 1 to pair</td></tr> <tr> <td></td><td>Next song</td><td></td><td>Short press to switch Bluetooth 2 and long press Bluetooth 2 to pair</td></tr> <tr> <td></td><td>Pause play</td><td></td><td>Short press to switch Bluetooth 3 and long press Bluetooth 3 to pair</td></tr> <tr> <td></td><td>CD Stop</td><td></td><td></td></tr> </table>		Switch wire mode		PRTSC		multimedia		le		Volume reduction		MyComputer		Volume plus		Calculator		mute		Switch between the home screen and the custom screen		Previous song		Short press to switch Bluetooth 1 and long press Bluetooth 1 to pair		Next song		Short press to switch Bluetooth 2 and long press Bluetooth 2 to pair		Pause play		Short press to switch Bluetooth 3 and long press Bluetooth 3 to pair		CD Stop			<p><b>FN Combination key (WIN system)</b></p> <table border="0"> <tr> <td></td><td>Switch wire mode</td><td></td><td>PRTSC</td></tr> <tr> <td></td><td>Lock WIN key</td><td></td><td>SCRLK</td></tr> <tr> <td></td><td>Query power (battery powered in wireless mode)</td><td></td><td>PAUSE</td></tr> <tr> <td></td><td>Main backlight effect switch</td><td></td><td>HOME</td></tr> <tr> <td></td><td>Main backlight color switch</td><td></td><td>Main backlight brightness+</td></tr> <tr> <td></td><td>Keyboard light switch</td><td></td><td>Main backlight brightness-</td></tr> <tr> <td></td><td>Screen query (loop)</td><td></td><td>Main backlight speed-</td></tr> <tr> <td></td><td>.</td><td></td><td>Main backlight speed+</td></tr> </table>		Switch wire mode		PRTSC		Lock WIN key		SCRLK		Query power (battery powered in wireless mode)		PAUSE		Main backlight effect switch		HOME		Main backlight color switch		Main backlight brightness+		Keyboard light switch		Main backlight brightness-		Screen query (loop)		Main backlight speed-		.		Main backlight speed+	<p><b>FN Combination Key (MAC)</b></p> <table border="0"> <tr> <td></td><td>Press and hold for 3s to restore factory Settings</td><td></td><td>Next song</td></tr> <tr> <td></td><td>Display dimming</td><td></td><td>mute</td></tr> <tr> <td></td><td>Display brightness plus</td><td></td><td>Volume reduction</td></tr> <tr> <td></td><td>Tile expands the currently active multiple Windows</td><td></td><td>Volume plus</td></tr> <tr> <td></td><td>Go directly to the main screen of the application</td><td></td><td>Switch between the home screen and the custom screen</td></tr> <tr> <td></td><td>Keyboard backlight brightness decreased</td><td></td><td>Short press to switch Bluetooth 1 and long press Bluetooth 1 to pair</td></tr> <tr> <td></td><td>The keyboard is brightly backlit</td><td></td><td>Short press to switch Bluetooth 2 and long press Bluetooth 2 to pair</td></tr> <tr> <td></td><td>Previous song</td><td></td><td>Short press to switch Bluetooth 3 and long press Bluetooth 3 to pair</td></tr> <tr> <td></td><td>Pause play</td><td></td><td></td></tr> </table>		Press and hold for 3s to restore factory Settings		Next song		Display dimming		mute		Display brightness plus		Volume reduction		Tile expands the currently active multiple Windows		Volume plus		Go directly to the main screen of the application		Switch between the home screen and the custom screen		Keyboard backlight brightness decreased		Short press to switch Bluetooth 1 and long press Bluetooth 1 to pair		The keyboard is brightly backlit		Short press to switch Bluetooth 2 and long press Bluetooth 2 to pair		Previous song		Short press to switch Bluetooth 3 and long press Bluetooth 3 to pair		Pause play			<p><b>FN Combination Key (MAC)</b></p> <table border="0"> <tr> <td></td><td>Switch wire mode</td><td></td><td>PRTSC</td></tr> <tr> <td></td><td>Lock WIN key</td><td></td><td>SCRLK</td></tr> <tr> <td></td><td>Query power (battery powered in wireless mode)</td><td></td><td>PAUSE</td></tr> <tr> <td></td><td>Main backlight effect switch</td><td></td><td>HOME</td></tr> <tr> <td></td><td>Main backlight color switch</td><td></td><td>Main backlight brightness+</td></tr> <tr> <td></td><td>Keyboard light switch</td><td></td><td>Main backlight brightness-</td></tr> <tr> <td></td><td>Screen query (loop)</td><td></td><td>Main backlight speed-</td></tr> <tr> <td></td><td>.</td><td></td><td>Main backlight speed+</td></tr> </table>		Switch wire mode		PRTSC		Lock WIN key		SCRLK		Query power (battery powered in wireless mode)		PAUSE		Main backlight effect switch		HOME		Main backlight color switch		Main backlight brightness+		Keyboard light switch		Main backlight brightness-		Screen query (loop)		Main backlight speed-		.		Main backlight speed+
	Switch wire mode		PRTSC																																																																																																																																								
	multimedia		le																																																																																																																																								
	Volume reduction		MyComputer																																																																																																																																								
	Volume plus		Calculator																																																																																																																																								
	mute		Switch between the home screen and the custom screen																																																																																																																																								
	Previous song		Short press to switch Bluetooth 1 and long press Bluetooth 1 to pair																																																																																																																																								
	Next song		Short press to switch Bluetooth 2 and long press Bluetooth 2 to pair																																																																																																																																								
	Pause play		Short press to switch Bluetooth 3 and long press Bluetooth 3 to pair																																																																																																																																								
	CD Stop																																																																																																																																										
	Switch wire mode		PRTSC																																																																																																																																								
	Lock WIN key		SCRLK																																																																																																																																								
	Query power (battery powered in wireless mode)		PAUSE																																																																																																																																								
	Main backlight effect switch		HOME																																																																																																																																								
	Main backlight color switch		Main backlight brightness+																																																																																																																																								
	Keyboard light switch		Main backlight brightness-																																																																																																																																								
	Screen query (loop)		Main backlight speed-																																																																																																																																								
	.		Main backlight speed+																																																																																																																																								
	Press and hold for 3s to restore factory Settings		Next song																																																																																																																																								
	Display dimming		mute																																																																																																																																								
	Display brightness plus		Volume reduction																																																																																																																																								
	Tile expands the currently active multiple Windows		Volume plus																																																																																																																																								
	Go directly to the main screen of the application		Switch between the home screen and the custom screen																																																																																																																																								
	Keyboard backlight brightness decreased		Short press to switch Bluetooth 1 and long press Bluetooth 1 to pair																																																																																																																																								
	The keyboard is brightly backlit		Short press to switch Bluetooth 2 and long press Bluetooth 2 to pair																																																																																																																																								
	Previous song		Short press to switch Bluetooth 3 and long press Bluetooth 3 to pair																																																																																																																																								
	Pause play																																																																																																																																										
	Switch wire mode		PRTSC																																																																																																																																								
	Lock WIN key		SCRLK																																																																																																																																								
	Query power (battery powered in wireless mode)		PAUSE																																																																																																																																								
	Main backlight effect switch		HOME																																																																																																																																								
	Main backlight color switch		Main backlight brightness+																																																																																																																																								
	Keyboard light switch		Main backlight brightness-																																																																																																																																								
	Screen query (loop)		Main backlight speed-																																																																																																																																								
	.		Main backlight speed+																																																																																																																																								
21	22	23	24																																																																																																																																								

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.