


802.11ax-HE20 In-Band Emission - Ant 2 (Nss = 4)

Channel 181 (6855MHz)




Channel 185 (6875MHz)




Channel 189 (6895MHz)



Channel 209 (6995MHz)




Channel 229 (7095MHz)




802.11ax-HE40 In-Band Emission - Ant 2 (Nss = 4)


Channel 35 (6125MHz)



Channel 59 (6245MHz)




Channel 91 (6405MHz)



Channel 99 (6445MHz)




Channel 107 (6485MHz)




Channel 115 (6525MHz)



Channel 123 (6565MHz)




Channel 147 (6685MHz)




802.11ax-HE40 In-Band Emission - Ant 2 (Nss = 4)


Channel 179 (6845MHz)




Channel 187 (6885MHz)




Channel 195 (6925MHz)



Channel 211 (7005MHz)




Channel 227 (7085MHz)




802.11ax-HE80 In-Band Emission - Ant 2 (Nss = 4)


Channel 39 (6145MHz)




Channel 55 (6225MHz)




Channel 87 (6385MHz)




Channel 103 (6465MHz)




Channel 119 (6545MHz)




Channel 135 (6625MHz)



Channel 151 (6705MHz)




Channel 167 (6785MHz)




802.11ax-HE80 In-Band Emission - Ant 2 (Nss = 4)


Channel 183 (6865MHz)



Channel 199 (6945MHz)




Channel 215 (7025MHz)




802.11ax-HE160 In-Band Emission - Ant 2 (Nss = 4)


Channel 47 (6185MHz)



Channel 79 (6345MHz)




Channel 111 (6505MHz)




Channel 143 (6665MHz)



Channel 175 (6825MHz)




Channel 207 (6985MHz)




802.11be-EHT20 In-Band Emission - Ant 2 (Nss = 4)

Channel 33 (6115MHz)



Channel 61 (6255MHz)



Channel 93 (6415MHz)



Channel 97 (6435MHz)




Channel 105 (6475MHz)



Channel 113 (6515MHz)



Channel 117 (6535MHz)




Channel 149 (6695MHz)




802.11be-EHT20 In-Band Emission - Ant 2 (Nss = 4)

Channel 181 (6855MHz)



Channel 185 (6875MHz)



Channel 189 (6895MHz)



Channel 209 (6995MHz)




Channel 229 (7095MHz)




802.11be-EHT40 In-Band Emission - Ant 2 (Nss = 4)


Channel 35 (6125MHz)




Channel 59 (6245MHz)




Channel 91 (6405MHz)



Channel 99 (6445MHz)




Channel 107 (6485MHz)




Channel 115 (6525MHz)



Channel 123 (6565MHz)




Channel 147 (6685MHz)




802.11be-EHT40 In-Band Emission - Ant 2 (Nss = 4)


Channel 179 (6845MHz)



Channel 187 (6885MHz)




Channel 195 (6925MHz)



Channel 211 (7005MHz)




Channel 227 (7085MHz)




802.11be-EHT80 In-Band Emission - Ant 2 (Nss = 4)


Channel 39 (6145MHz)




Channel 55 (6225MHz)




Channel 87 (6385MHz)




Channel 103 (6465MHz)




Channel 119 (6545MHz)




Channel 135 (6625MHz)



Channel 151 (6705MHz)




Channel 167 (6785MHz)




802.11be-EHT80 In-Band Emission - Ant 2 (Nss = 4)


Channel 183 (6865MHz)



Channel 199 (6945MHz)




Channel 215 (7025MHz)




802.11be-EHT160 In-Band Emission - Ant 2 (Nss = 4)


Channel 47 (6185MHz)



Channel 79 (6345MHz)




Channel 111 (6505MHz)



Channel 143 (6665MHz)



Channel 175 (6825MHz)




Channel 207 (6985MHz)



802.11be-EHT320-1 In-Band Emission - Ant 2 (Nss = 4)

Channel 95 (6425MHz)




Channel 159 (6745MHz)



802.11be-EHT320-2 In-Band Emission - Ant 2 (Nss = 4)

Channel 63 (6265MHz)



Channel 127 (6585MHz)



Channel 191 (6905MHz)




802.11ax-HE20 In-Band Emission - Ant 4 (Nss = 4)

Channel 33 (6115MHz)




Channel 61 (6255MHz)



Channel 93 (6415MHz)




Channel 97 (6435MHz)



Channel 105 (6475MHz)




Channel 113 (6515MHz)



Channel 117 (6535MHz)




Channel 149 (6695MHz)



802.11ax-HE20 In-Band Emission - Ant 4 (Nss = 4)


Channel 181 (6855MHz)




Channel 185 (6875MHz)




Channel 189 (6895MHz)



Channel 209 (6995MHz)




Channel 229 (7095MHz)




802.11ax-HE40 In-Band Emission - Ant 4 (Nss = 4)


Channel 35 (6125MHz)




Channel 59 (6245MHz)




Channel 91 (6405MHz)



Channel 99 (6445MHz)




Channel 107 (6485MHz)



Channel 115 (6525MHz)



Channel 123 (6565MHz)




Channel 147 (6685MHz)



802.11ax-HE40 In-Band Emission - Ant 4 (Nss = 4)


Channel 179 (6845MHz)




Channel 187 (6885MHz)



Channel 195 (6925MHz)



Channel 211 (7005MHz)



Channel 227 (7085MHz)

