



802.11be-EHT40 In-Band Emission- Ant 2


Channel 123 (6565 MHz)




Channel 147 (6685 MHz)




Channel 179 (6845 MHz)




Channel 187 (6885 MHz)




Channel 195 (6925 MHz)



Channel 211 (7005 MHz)




Channel 227 (7085 MHz)




802.11be-EHT80 In-Band Emission- Ant 2


Channel 7 (5985 MHz)




Channel 55 (6225 MHz)




Channel 87 (6385 MHz)




Channel 103 (6465 MHz)



Channel 119 (6545 MHz)




Channel 135 (6625 MHz)




802.11be-EHT80 In-Band Emission- Ant 2


Channel 151 (6705 MHz)




Channel 167 (6785 MHz)




Channel 183 (6865 MHz)



Channel 199 (6945 MHz)




Channel 215 (7025 MHz)




802.11be-EHT160 In-Band Emission- Ant 2


Channel 15 (6025 MHz)




Channel 47 (6185 MHz)




Channel 79 (6345 MHz)




Channel 111 (6505 MHz)




Channel 143 (6665 MHz)



Channel 175 (6825 MHz)




Channel 207 (6985 MHz)



802.11be-EHT320-1 In-Band Emission- Ant 2


Channel 31 (6105 MHz)



Channel 95 (6425 MHz)




Channel 159 (6745 MHz)




802.11be-EHT320-2 In-Band Emission- Ant 2

Channel 63 (6265 MHz)



Channel 127 (6585 MHz)



Channel 191 (6905 MHz)




802.11ax-HE20 In-Band Emission- Ant 3

Channel 1 (5955 MHz)




Channel 49 (6195 MHz)



Channel 93 (6415 MHz)




Channel 97 (6435 MHz)



Channel 105 (6475 MHz)



Channel 113 (6515 MHz)




802.11ax-HE20 In-Band Emission- Ant 3

Channel 117 (6535 MHz)




Channel 149 (6695 MHz)




Channel 181 (6855 MHz)




Channel 185 (6875 MHz)




Channel 189 (6895 MHz)



Channel 209 (6995 MHz)




Channel 229 (7095 MHz)




802.11ax-HE40 In-Band Emission- Ant 3


Channel 3 (5965 MHz)




Channel 51 (6205 MHz)




Channel 91 (6405 MHz)




Channel 99 (6445 MHz)



Channel 107 (6485 MHz)




Channel 115 (6525 MHz)




802.11ax-HE40 In-Band Emission- Ant 3


Channel 123 (6565 MHz)




Channel 147 (6685 MHz)




Channel 179 (6845 MHz)




Channel 187 (6885 MHz)




Channel 195 (6925 MHz)



Channel 211 (7005 MHz)




Channel 227 (7085 MHz)




802.11ax-HE80 In-Band Emission- Ant 3


Channel 7 (5985 MHz)




Channel 55 (6225 MHz)




Channel 87 (6385 MHz)




Channel 103 (6465 MHz)



Channel 119 (6545 MHz)




Channel 135 (6625 MHz)




802.11ax-HE80 In-Band Emission- Ant 3


Channel 151 (6705 MHz)




Channel 167 (6785 MHz)




Channel 183 (6865 MHz)



Channel 199 (6945 MHz)




Channel 215 (7025 MHz)




802.11ax-HE160 In-Band Emission- Ant 3


Channel 15 (6025 MHz)




Channel 47 (6185 MHz)




Channel 79 (6345 MHz)




Channel 111 (6505 MHz)




Channel 143 (6665 MHz)



Channel 175 (6825 MHz)




Channel 207 (6985 MHz)




802.11be-EHT20 In-Band Emission- Ant 3


Channel 1 (5955 MHz)




Channel 49 (6195 MHz)




Channel 93 (6415 MHz)



Channel 97 (6435 MHz)



Channel 105 (6475 MHz)



Channel 113 (6515 MHz)

