

G12 Smart Watch

G12 SMART WATCH

Thank you for choosing the G12 Smart Watch as your fitness transformation companion.


Allow this manual to guide you through the functioning of your smart watch.

Please read it thoroughly before using your smart watch. Keep this manual for later use as well.



PACKAGE CONTAINS:

- G12 Smart Watch x1
- USB Magnetic Charging Cable x1
- User Manual x1
- Quick Start Guide x1
- Warranty Card x1



CHARGING THE WATCH

The smartwatch must be charged before initial use. It takes up to 2 hours to be fully charged. Connect and charge the watch with the image below as a reference, using a 5V/2A adapter.



TURNING THE WATCH ON/OFF

To turn the watch on/off, long-press the side button for 3–5 seconds. You can wake the screen by lifting your wrist.



CONNECTING TO THE APP

1. Download Apex Wear app on your phone. Available on both App Store (iOS 13.0 and above) and Google Play Store (Android 6.0 and above)

OR

Scan [QR CODE] (Also available on the watch)

2. Connect the device with Apex Wear app.

3. Select G12 Smart Watch on the home screen of the app and click pair to connect.

4. To use all features of your G12 Smart Watch seamlessly, tap on 'yes' to the 'connection' and 'grant access' system prompt.

5. Turn on your phone's Bluetooth and GPS on. Go to phone's settings, find Bluetooth and turn on / find Privacy -> Location Service and turn on.

6. Disable battery optimization.

Note:

To ensure connectivity throughout your journey, make sure the app is allowed to run in the background of your phone at all times. iPhones will not prompt any information unless you complete Bluetooth pairing with G12 Smart Watch.

SYNCING YOUR SMARTWATCH TO THE APP

Data Synchronization:

- Open the app on your phone.
- Make sure your smart watch is connected; refer to "CONNECTING TO THE APP" section of this manual.
- Synchronization will start automatically once you enter the app interface.

Note:


Synchronize data at least once every day to avoid data loss in the watch.

NAVIGATING THROUGH THE FUNCTIONS PRESS THE BUTTON AT THE HOME SCREEN TO ACCESS THE MAIN MENU

Workout

Choose from multiple sports mode like outdoor run, outdoor walk, indoor walk, outdoor cycle, indoor run, hike, exercise, indoor cycle, elliptical, yoga, climbing, trail run, rowing.

Tap on any sport mode to start the activity. Press the side button to pause or stop the activity. If the activity is less than 3 mins, it will not be recorded. Sync your smartwatch to the app to get the detailed analysis.



BT Calling

Making and receiving calls via Bluetooth function.




Heart Rate Monitor

Wear the watch on your wrist, then click on the icon to start measurements. You can also view the data on the app.

Note:

Measurements are for reference only and not for medical purposes.



Stress monitoring

Click this option to start the stress monitoring. Make sure you wear your watch on your wrist properly to get the accurate results. Analysis of the measurement is Relax: 1–29 Normal: 30–59 Medium: 60–79 High: 80–100

Note: Measurements are for reference only and not for medical purposes.



SpO2 monitoring

Wear the watch on your wrist, then click on the icon to start measurements. You can also view the data on the app.

Note: Measurements are for reference only and not for medical purposes.




Activity

Click on this to check your daily activity data like step count, calorie and distance covered.



Breath

Click on the breath training icon to regulate your breathing with the instructions given to relax.




Sleep Monitor

Tap on the icon to review the sleep data from the previous night. The default watch setting is to detect the user's sleep during the whole day. Once you lie down, the watch detects reduced /No movement and if it meets the sleep patterns it will start recording, and will stop recording if it detects excessive movement. You can check the data on the app only after the awake criteria is met. You can also track sleep scores on Apex Wear app.


Note:

*For accurate sleep data recording, the sleep criteria has to be met which includes limited movement, wrist positions and angles, and more. The awake criteria will be met only after it records some noticeable movement




Alarm

Press the button at the home screen of the watch and scroll to find the alarm setting.




Notification

Swipe up to see your phone notifications such as SMS and app notifications




Calendar

Press the button at the home screen and scroll down to access the calendar function.




Timer

Press the button at the home screen and scroll down to find the timer setting.



Music Control


Press the button at the home screen and scroll down to find the music control function. From here you can control music that is playing on your phone. You can play, pause, skip songs and adjust the volume.



Note: Some apps with different protocols might not work.


Stopwatch

Press the button at the home screen and scroll down to access the stopwatch function.



Camera Control Mode

Tap on the remote camera icon on your smartwatch to click a photo from your phone.



Note: It doesn't connect directly with phone's native camera. Please open Apex Wear app, go to "Device" page and find "Take a picture" and then click on it to use this feature.

Find My Phone


Press the button at the home screen then scroll down to find the "Find My Phone" function. Once you tap start, your phone will start ringing. Tap again to stop.



Note: Your smartwatch should be connected to your phone via Bluetooth and within its range for this feature to work.

Calculator

Press the button at the home screen and scroll down to access the calculator function.




Settings

Note: Either swipe down at the home screen on the watch and tap the gear icon, or press the button at the home screen and scroll down to find the settings option.


Watch Faces

more watch faces are available to download through the app. In the Apex Wear app, go to the "Device" page and find "watch face" and then click on more to choose from a large selection of watch faces.



Power Saving

Tap the on/off button to enter power saving mode.




Brightness

Tap on this to adjust the brightness.




Timeout

Adjust the time that your watch screen stays active.




Vibration

Tap on this to adjust the vibration to strong, normal, weak or off. It can also be adjusted in the APP



Time Set

The time and date is set automatically once you pair the watch with your phone. However in case you would like to adjust the time and date manually, you can do so in the settings of the watch. You can also adjust the time format here between 12h or 24 hours.




QR code

Scan the QR code to download Apex Wear app.




Restart

Tap on this to restart watch.



Power off


Tap on this to switch your watch off.



Reset


Tap on this to reset watch data.

Note: All data will be erased if watch is reset.



Theme

You can select your favorite theme of watch from here.



Swipe up to access notifications

You can access the most recent 10 notifications from here.

Swipe down for shortcut menu

You can access Wake gesture, Brightness, Do not disturb, Find phone, Find phone, Power saving, Flashlight, QR code, About device and Settings.

Swipe left and right to switch favorites card

You can switch your selected favorite card from here.

Additional functions in the app

Notifications

Select specific notifications you would like to turn off (i.e. Facebook, Twitter, WhatsApp and etc.) Do Not Disturb Set do not disturb for specific periods of time.

PRODUCT PARAMETERS:

Model	G12 Smart Watch
Screen type	2.01" HD Display
Battery capacity	270mAh
Net weight	19.7g
Bluetooth version	Bluetooth
Working temperature	0–45°C
Charging time	2 Hours
Working time	7 Days
Water resistance	IP68
Frequency band	2400 – 2483.5MHz

MAINTENANCE:

Regularly clean your wrist and the strap of the smartwatch, especially after sweating during exercise or being exposed to substances such as soap or detergent, which may get stuck on the other end of the product. Do not wash the strap with a household cleanser. Please use soap less detergent, rinse thoroughly and wipe with a piece of soft towel or napkin. For spots or stains that are not easy to remove, scrub the area with rubbing alcohol and then follow the above procedure.

FAQ

Search for the app to connect keeps failing

- 1.Keep Apex Wear app updated to the latest version.
2. There is no obstacle in between the watch and the phone.
3. Make sure the app is running in background.

Note: Make sure your phone system meets Android 7.0 and above and iOS 13.0 and above.

My G12 Smart Watch is receiving no alerts, texts or phone calls

Make sure smart reminders on the app are on and synced to the G12 Smart Watch. Also make sure your notification center of the phone is displaying messages. Only then will your smartwatch also display those notifications. Make sure app is running in the background and battery optimization feature on the phone is disabled.

My Bluetooth keeps getting disconnected

1. Make sure there is not more than 30' (9.1 m) distance between Bluetooth on the phone & the watch.
2. There is no obstacle in between the watch and the phone.
3. Make sure the app is running in background.

Which functions of the G12 Smart Watch need Bluetooth to work?

Call & Text Notifications, Find My Phone, Music control, Camera control, Weather forecast, Cloud and custom watch faces need Bluetooth connectivity to work.

Will it be okay to take a bath wearing the G12 Smart Watch?

The watch can be used for shallow water activities in swimming pools or along the coast. It should not be worn while taking a hot shower, soaking in a hot springs or sauna, or engaging in other deep water activities or activities involving the high-speed flow of water.

SAFETY & PRODUCT INFORMATION

Battery

- Do not disassemble, bore or damage the battery.
- Do not disassemble the built in batteries of non-replaceable battery devices.

- Do not use sharp objects to remove the battery

Battery

- Do not disassemble, bore or damage the battery.
- Do not disassemble the built in batteries of non-replaceable battery devices.
- Do not use sharp objects to remove the battery

Health Warning

- If you are wearing a pacemaker or other implanted electronic devices, please consult your doctor before using the heart rate monitor of the watch.
- The optical heart rate sensor will glow green. If you suffer from epilepsy or are sensitive to blinking light sources, please consult your physician before wearing this device.
- The device tracks your daily activities through sensors. This data is intended to tell you about your daily activities such as steps, sleep, distance, heart rate and calories, but may not be completely accurate.
- The device accessories, heart rate sensor, oxygen level monitor, and other relevant data is designed for fitness and not for medical purposes. They are not applicable to the diagnosis, monitoring, treatment or prevention of any diseases or symptoms. The heart rate and blood pressure data is for reference only. We're not responsible for any deviation in data.
- Avoid wearing the watch too tightly. Make sure you keep your skin dry – the area that comes in contact with the watch. If symptoms such as redness or swelling appear on your skin, immediately stop using the watch and consult the doctor.

Things to keep in mind

- Sync data everyday to avoid data loss.
- Water Resistance will not work for seawater, acidic and alkaline solutions, chemical reagents & other corrosive liquid. The damage or defects caused by misuse or improper use are not covered by the warranty.
- Sports modes support up to 6 hours of exercise at a time.
- Avoid wearing the watch too tight in daily use. Keep the parts of skin touching the watch dry.
- Keep your arm still while measuring data for accurate measurement.

Disclaimer: This product is an electronic monitoring product and is not intended as a medical reference. We reserve the right to modify or improve any of the functions described in this manual without any prior notice. At the same time, we hold the right to continuously update the product content.

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT SUBSTITUTE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort, you contribute to recycle valuable raw materials and treatment of toxic substances.