



Press power switch button, Place the NFC card at the NFC indicator label sensor area to unlock it, and then the scooter is ready to go.



If the NFC key card is lost, please consult your dealer to purchase the new card.

How to match the new NFC key card with your scooter? Please follow the steps below:

- 1、 Hold the low-speed and horn button for 10 seconds, the NFC indicator light will start flashing after hearing the buzzer "beep"
- 2、 Take a card near the NFC indicator light, and the NFC matching is automatically completed.



Please take attention that changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.