





Buttons function introduction

NO.	Buttons	Function	Operation	Notes
1		Power on	long Press 5S	Power off state
2		Manual Power off	long Press 5S	Power on state
		Auto Power Off	Power on and unconnected state, automatically power off after 3 mins	Not connected state
3		Up/Flip up	Single click	
4		Down/Flip down	Single click	
5		Left/Flip left	Single click	
6		Right/Flip right	Single click	
7		Confirmation	Single click	
8		Single like	Double click	
9		Continuous likes	Long press 3S	
10		Exit continuous likes	Long press 3S	In the continuous likes state
11		Take photos	Single Click	
12		Photo focus	Long press 3S	In the photo state
13		Photo focus	Single click	In the photo state
14		Volume +	Single Click	Not in the camera state
15		Volume -	Double click	Not in the camera state
16		Disconnect currently pairing	Press 2 buttons at the same time, red and blue lights flash alternately	Disconnect currently connected device
17		Horizontal screen switch	Long press 3S	Only supports horizontal orientation on one side



FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

* RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.