





















<h3>产品规格</h3> <p>型号:HTC NE11</p> <p>蓝牙 范围:≈10m 版本:5.0</p> <p>喇叭 直径:14.2mm 阻抗:16Ω</p> <p>耳机功率 输入:5V=40mA 电池容量:40mAh 使用时间:≈5小时 充电时间:≈1.5小时</p> <p>充电仓功率 输入:5V=400mA 输出:5V=80mA 电池容量:400mAh 充电时间:≈1.5小时 充电仓充满电时,能给耳机充电3次</p>  <p>快速入门指南 使用前请阅读使用说明书 HTC NE11</p>	<h3>物品清单</h3>  <p>充电仓</p>  <p>2只耳机</p>	 <p>快速入门指南</p>  <p>USB-C充电线</p>  <p>挂绳</p>	<h3>部件</h3>  <p>耳机指示灯</p>  <p>多功能触摸键</p>  <p>充电触点</p>  <p>耳机喇叭</p>	 <p>Type-C 充电口</p>  <p>多功能按键</p>	<h3>取出耳机并配对</h3>  <p>如果您需要第一次使用耳机,请将两个耳机从充电仓中取出,其中一个耳机的LED灯将会交替闪烁白灯和红灯,表示它们处于配对模式。 注: ·如果耳机与任何设备配对,打开后会自动进入配对模式。配对成功后,您会听到两声滴声。 ·如果耳机之间已配对,打开后会自动同步数据,连接时您会听到滴声。</p>										
<h3>如何佩戴耳机</h3>  <p>1</p>	 <p>2</p>	 <p>3</p>	 <p>4</p>	<h3>开机和关机</h3> <p>开机 单点耳机:将耳机从充电仓中取出,耳机开机。 长按耳机:长按3秒,耳机开机。 关机 单点耳机:将耳机放入充电仓中,耳机关机。 长按耳机:长按3秒,耳机关机。 注:当耳机开机后,30秒未与蓝牙设备配对,便会自动关机;当配对的蓝牙设备超出信号有效范围距离,且未重新连接时,30秒后,耳机自动关机。</p>	<h3>连接到蓝牙设备</h3>  <p>1. 在您的设备上,打开蓝牙,并选择要配对“HTC NE11”。</p>	<h3>基本操作</h3>  <p>开机/关机: 长按3秒, 耳机开机/关机。 播放/暂停: 单击2次, 耳机播放/暂停。 上一曲: 单击1次, 耳机上一曲。 下一曲: 单击1次, 耳机下一曲。 音量+/-: 单击2次, 耳机音量+/-。 语音助手: 单击2次, 耳机语音助手。 快速充电: 单击2次, 耳机快速充电。 快速充电: 单击2次, 耳机快速充电。</p>									
<h3>功能操作</h3> <p>· 暂停/播放: 轻触任一耳机一次。 · 音量+: 轻触右耳机二次。 · 音量-: 轻触左耳机二次。 · 上一曲: 轻触左耳机三次。 · 下一曲: 轻触右耳机三次。 注: 单击耳机时, 将正在播放的耳机切换, 均可实现语音助手。 · 游戏模式与音乐模式切换: 按下右耳机的2秒触摸。 注: 单击耳机时, 无法切换游戏模式和音乐模式。 注: 出“设置”菜单时, 无法切换游戏模式和音乐模式。 注: 通过耳机麦克风的功能游戏模式。</p> <p>指示灯显示</p> <table border="1"> <thead> <tr> <th>耳机指示灯</th> <th>状态</th> </tr> </thead> <tbody> <tr> <td>白灯和红灯交替闪烁</td> <td>两个耳机: 开机 单耳机: 未配对</td> </tr> <tr> <td>白灯亮</td> <td>充电中</td> </tr> <tr> <td>红灯亮</td> <td>配对成功或充满电</td> </tr> <tr> <td>充电仓指示灯</td> <td>状态</td> </tr> <tr> <td>白色常亮</td> <td>充电中</td> </tr> <tr> <td>蓝色常亮</td> <td>充满电</td> </tr> </tbody> </table> <p>注意: 为了保护您的隐私并节省电量, 无任何操作时, 显示屏在30秒后熄灭。</p>	耳机指示灯	状态	白灯和红灯交替闪烁	两个耳机: 开机 单耳机: 未配对	白灯亮	充电中	红灯亮	配对成功或充满电	充电仓指示灯	状态	白色常亮	充电中	蓝色常亮	充满电	<h3>如何清除蓝牙配对历史记录</h3>  <p>1. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 2. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 3. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 4. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 5. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 6. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 7. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 8. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 9. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 10. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 11. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 12. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 13. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 14. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 15. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 16. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 17. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 18. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 19. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 20. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 21. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 22. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 23. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 24. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 25. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 26. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 27. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 28. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 29. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 30. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 31. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 32. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 33. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 34. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 35. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 36. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 37. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 38. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 39. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 40. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 41. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 42. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 43. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 44. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 45. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 46. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 47. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 48. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 49. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 50. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 51. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 52. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 53. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 54. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 55. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 56. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 57. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 58. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 59. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 60. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 61. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 62. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 63. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 64. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 65. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 66. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 67. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 68. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 69. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 70. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 71. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 72. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 73. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 74. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 75. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 76. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 77. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 78. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 79. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 80. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 81. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 82. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 83. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 84. 单击耳机上的触摸键, 长按3秒, 耳机进入配对模式。 85. 单击耳机上的触摸键, 长按3</p>
耳机指示灯	状态														
白灯和红灯交替闪烁	两个耳机: 开机 单耳机: 未配对														
白灯亮	充电中														
红灯亮	配对成功或充满电														
充电仓指示灯	状态														
白色常亮	充电中														
蓝色常亮	充满电														

<div> <div> <div> <div>Wireless Earphones 11</div> <div></div> </div> </div> <div> </div> <div> <div>Quick Start Guide</div> <div>HTC NE11</div> </div> </div>	<div> <div>Product Specifications</div> <div>Model: HTC NE11</div> <div>Bluetooth</div> <div>Range: ≈ 10 m</div> <div>Version: 4.0</div> <div>Speaker</div> <div>Diameter: 14.2 mm</div> <div>Impedance: 32 Ω</div> <div>Earphone power</div> <div>Input: 5 V=400 mA</div> <div>Battery capacity: 40 mAh</div> <div>Battery life: ≈ 5 hrs</div> <div>Charging time: ≈ 1.5 hrs</div> <div>Charging case power</div> <div>Input: 5 V=400 mA</div> <div>Output: 5 V=80 mA</div> <div>Battery capacity: 400 mAh</div> <div>Charging time: ≈ 1.5 hrs</div> <div>Earphone recharges: 3 charges (when case is fully charged)</div> </div>	<div> <div>What's in the box</div> <div> <div>Charging case</div> </div> <div> <div>2 Earphones</div> </div> <div> <div>Quick Start Guide USB-C cable Lanyard</div> </div> </div>	<div> <div>Components</div> <div> <div>Earphone LED</div> </div> <div> <div>Touchpad</div> </div> <div> <div>Charging contact</div> </div> <div> <div>Earphone speaker</div> </div> </div>	<div> <div> <div>Charging case display screen</div> </div> <div> <div>USB Type-C port</div> </div> <div> <div>Multi-Function Buttons</div> </div> </div>	<div> <div>Take out and pair the earphones</div> <div> </div> <div> <p>If you're using the earphones for the first time, remove both from the charging case. The LED on one earphone will blink white and blue alternately, indicating that they are in pairing mode.</p> <p>Note:</p> <ul style="list-style-type: none"> If the earphones have not been paired with each other, they will automatically enter pairing mode when turned on. You'll hear two beeps when pairing is successful. If the earphones have been paired before, they will automatically reconnect to each other when turned on. You'll hear a beep when they connect. </div> </div>	<div> <div>How to put on the earphones</div> <div> </div> </div>																
<div> <div> </div> <div> <div>3</div> </div> </div>	<div> <div>Power on and off</div> <div> </div> <div> <p>Power on</p> <p>Taking the earphones out of the charging case will automatically turn them on.</p> <p>To manually turn on each earphone, press and hold the touchpad for three seconds.</p> <p>Power off</p> <p>Placing the earphones in the charging case will automatically turn them off.</p> <p>To manually turn off each earphone, press and hold the touchpad for five seconds.</p> <p>Note: If the earphones are not paired with a Bluetooth device within three minutes after powering on, they will automatically power off. They will also power off after three minutes if the paired Bluetooth device moves out of the effective connection range and has not reconnected.</p> </div> </div>	<div> <div>Connect to Bluetooth device</div> <div> </div> <div> <p>On your device, turn on Bluetooth and choose to connect to "HTC NE11".</p> </div> </div>	<div> <div>Basic operations</div> <div> </div> </div>	<div> <div>Key functions</div> <ul style="list-style-type: none"> Play/Pause: Tap either earphone once. Volume up: Tap the right earphone twice. Volume down: Tap the left earphone twice. Play previous track: Tap the left earphone three times. Play next track: Tap the right earphone three times. Answer/End call: Tap either earphone once. Reject call: Press and hold either earphone for two seconds. Activate voice assistant: Press and hold the left earphone for two seconds. <p>Note: When using a single earphone only, press and hold the active earphone for two seconds.</p> <ul style="list-style-type: none"> Switch between Game and Music modes: Music mode is the default mode. Press and hold the right earphone for two seconds to switch between modes. (The louder notification sound indicates Game mode.) <p>Note: Mode switching is disabled when you're using a single earphone only.</p> <table border="1"> <thead> <tr> <th>Earphone LED</th> <th>Status</th> </tr> </thead> <tbody> <tr> <td>Blinking white and blue</td> <td>Both earphones: Powered on</td> </tr> <tr> <td></td> <td>Single earphone: Unpaired</td> </tr> <tr> <td>Solid white</td> <td>Charging</td> </tr> <tr> <td>Off</td> <td>Paired or fully charged</td> </tr> </tbody> </table> <table border="1"> <thead> <tr> <th>Charging case display screen</th> <th>Status</th> </tr> </thead> <tbody> <tr> <td>Solid white icon</td> <td>Case charging</td> </tr> <tr> <td>Solid blue icon</td> <td>Case fully charged</td> </tr> </tbody> </table> <p>Note: The display screen turns off after 30 seconds of inactivity to protect privacy and save power.</p> </div>	Earphone LED	Status	Blinking white and blue	Both earphones: Powered on		Single earphone: Unpaired	Solid white	Charging	Off	Paired or fully charged	Charging case display screen	Status	Solid white icon	Case charging	Solid blue icon	Case fully charged	<div> <div>How to reset the earphones</div> <p>If the earphones fail to pair or reconnect to each other, reset them by tapping both earphones five times simultaneously. Note: Resetting the earphones will clear the Bluetooth pairing history.</p> </div>	<div> <div>Case Display Screen: Basic Operations</div> <div> </div> <div> <p>Activate the Display Screen</p> <p>Touch Activation: Tap the display area when screen is off.</p> <p>Button Activation: Single-click the multi-function button.</p> <p>Deactivate the Display Screen</p> <p>Auto-Deactivation: Display turns off automatically after 30 seconds of inactivity.</p> <p>Manual Deactivation: Press the multi-function button once to turn off the display.</p> <p>Note: Initial activation required for first-time use</p> <p>Method 1: Charge the charging case via the Type-C port to activate and power on.</p> <p>Method 2: Press and hold the multi-function button for 8 seconds to power on.</p> <p>Tip: The product is preset in shutdown mode upon factory shipment. Initial activation is required before first use.</p> </div> </div>
Earphone LED	Status																					
Blinking white and blue	Both earphones: Powered on																					
	Single earphone: Unpaired																					
Solid white	Charging																					
Off	Paired or fully charged																					
Charging case display screen	Status																					
Solid white icon	Case charging																					
Solid blue icon	Case fully charged																					
<div> <div>Multi-function Button Operations</div> <div> </div> <div> <p>Single-click: Turn the screen on/off.</p> <p>Triple-click: Pair the earphones.</p> <p>Triple-click again: Pair the charging case with the earphones. Press and hold for 2 seconds: Open the system menu ("Powered Off" or "Restart").</p> <p>Press and hold for 8 seconds: When powered off: Powered On.</p> <p>When powered on: Restore to factory settings.</p> </div> </div>	<div> <div>Status Icons Guide</div> <table border="1"> <thead> <tr> <th>Icon</th> <th>Status</th> </tr> </thead> <tbody> <tr> <td>Solid red</td> <td>Earphones in case, not connected to phone</td> </tr> <tr> <td>Solid white</td> <td>Case connected to earphones, but earphones offline</td> </tr> <tr> <td>Solid green</td> <td>Case connected to earphones, earphones paired to phone</td> </tr> <tr> <td>Solid blue</td> <td>Earphones charging</td> </tr> <tr> <td>Solid white</td> <td>Earphones in use/Earphones fully charged</td> </tr> <tr> <td>Solid blue</td> <td>Case charging</td> </tr> <tr> <td>Solid white</td> <td>Case in use/Case fully charged</td> </tr> </tbody> </table> </div>	Icon	Status	Solid red	Earphones in case, not connected to phone	Solid white	Case connected to earphones, but earphones offline	Solid green	Case connected to earphones, earphones paired to phone	Solid blue	Earphones charging	Solid white	Earphones in use/Earphones fully charged	Solid blue	Case charging	Solid white	Case in use/Case fully charged	<div> <div>Case Display Screen: Feature Overview</div> <div> </div> <div> <p>Lock Screen Interface</p> <p>Swipe right: Unlock the screen.</p> <p>Music Playback</p> <p>Previous Track Play/Pause Next Track</p> </div> </div>	<div> <div>Volume adjustment</div> <div> </div> <div> <p>Spatial sound</p> <p>Movie Mode Music Mode Game Mode</p> <p>Equalizer</p> <p>Click icon: Switch Between Different Sound Effect</p> </div> </div>	<div> <div>Light Level</div> <div> </div> <div> <p>Language switch</p> <p>Click icon: Switch between languages of different countries/regions.</p> <p>Kaleidoscope Menu</p> <p>Swipe up to enter the Kaleidoscope menu interface. Swipe left or right to navigate between options and tap to select. (Within sub-menus: Swipe right to return to the main menu; Swipe down to fully exit the Kaleidoscope interface.)</p> </div> </div>	<div> <div>Find My Earphone</div> <div> </div> <div> <p>Tap L/R buttons: Displays Screen</p> <p>Cancel: Exits the current function</p> <p>Start: Displays Screen and activates the beeping sound from the earphones speaker</p> <p>Click icon: Stops the beeping sound</p> </div> </div>	<div> <div>Screen Lock switch</div> <div> </div> <div> <p>Click icon: Switches between lock screen wallpapers</p> <p>TIKTOK Page Flipping and Like Function</p> <p>After connecting the earphones to the mobile phone and entering TIKTOK, you can adjust the volume, switch to the previous video, switch to the next video, and give a like using the charging case. (For iOS devices, you need to enable AssistiveTouch in Settings > Accessibility > Touch > AssistiveTouch.)</p> <p>1. This function is only available for use with TIKTOK software.</p> <p>Other apps may not support it.</p> <p>2. This feature may have compatibility issues with certain phones, and some phones may not be able to use it.</p> <p>3. If this feature is unavailable, please disregard it.</p> </div> </div>
Icon	Status																					
Solid red	Earphones in case, not connected to phone																					
Solid white	Case connected to earphones, but earphones offline																					
Solid green	Case connected to earphones, earphones paired to phone																					
Solid blue	Earphones charging																					
Solid white	Earphones in use/Earphones fully charged																					
Solid blue	Case charging																					
Solid white	Case in use/Case fully charged																					
<div> <div>Camera Control</div> <p>Requires Bluetooth connection to a compatible device (e.g., smartphone).</p> <p>1. Native camera exclusivity - Only works with the device's pre-installed camera application. Third-party photography apps are unsupported.</p> <p>2. Compatibility limitations - Functional restrictions may occur on certain smartphone models.</p> <p>3. Non-functional handling - Disable this feature if inoperative on your device.</p> <div> </div> <p>Open your phone's camera app and click the device button to take photos.</p> <div> <div>Translation</div> </div> <p>Click icon: Activates translation mode</p> </div>	<div> <div>Important Safety Instructions</div> <p>Carefully read all the safety instructions in this document before using the product.</p> <p>General safety instructions</p> <ul style="list-style-type: none"> Use the product with care and store it in a clean environment that is free from extreme temperature, pressure, and humidity. Make sure that the product is stored in a location where it cannot be bent or deformed. Repairs and replacements should only be performed by authorized after-sales service staff. Do not attempt to disassemble or replace any part of the product yourself to prevent injuries or damage to the device. Any unauthorized modification to the product voids the warranty. Only use the product in environments where Bluetooth transmission is permitted. <p>Personal safety instructions</p> <ul style="list-style-type: none"> Do not use the product if it is obviously defective or exhibits abnormalities such as bulging or excessive heating. Do not use the product when performing high-risk tasks that require your full attention. For your hearing protection, do not listen at high volume for long periods. </div>																					