

htc

无线蓝牙耳机30

快速入门指南  
使用前请阅读使用说明书  
HTC NE30

产品规格

型号: HTC NE30

蓝牙

范围: ≈10m  
版本: 6.0

喇叭

直径: 14.2 mm  
阻抗: 16Ω

耳机功率

输入: 5V≈40mA  
电池容量: 40mAh  
使用时间: ≈5小时  
充电时间: ≈1.5小时

充电仓功率

输入: 5V≈300mA  
输出: 5V≈80mA  
电池容量: 300mAh  
充电时间: ≈1.5小时  
充电仓充满电时, 能给耳机充电约2次

产品清单

充电仓

2 耳机

快速入门指南

USB-C充电线

部件

多功能触控键

耳机指示灯

耳机喇叭

充电触点

充电仓指示灯

Type-c 充电口

取出耳机并配对

如果您第一次使用耳机, 请将两个耳机从充电仓中取出, 其中一个耳机的LED灯将会交替闪烁白灯和青灯, 表示它们处于配对模式。  
注:  
•如果耳机未与任何设备配对, 打开后会自动进入配对模式。配对成功后, 您会听到两声滴滴声。  
•如果耳机之前已配对, 打开后会自动重新连接。连接时您会听到嘟嘟声。

如何佩戴耳机

1

2

3

4

开机和关机

开机

自动开机: 将耳机从充电仓中取出, 耳机开机。  
手动开机: 长按3秒, 耳机开机。

关机

自动关机: 耳机放入充电仓中, 耳机关机。  
手动关机: 长按5秒, 耳机关机。

连接到蓝牙设备

在您的设备上, 打开蓝牙并选择连接到“HTC NE30”。

HTC NE30

基本操作

L

R

开机/关机

电源按钮 3s/5s

音乐模式

音量+ x2 音量- x2 播放/暂停 x1 上一首 x1 下一首 x1

清除蓝牙配对历史记录

长按电源按钮 5s x5

通话模式

接听/挂断电话 x1 拒接电话 2s

功能操作

• 暂停/播放: 轻触任一耳机一次  
• 音量加: 轻触右耳机二次  
• 音量减: 轻触左耳机二次  
• 上一曲: 轻触左耳机三次  
• 下一曲: 轻触右耳机三次  
• 接听/挂断电话: 轻触任一耳机一次  
• 通话拒接: 按住任一耳机2秒  
• 启动语音助手: 按住左耳机12秒  
注: 单耳使用时, 按压已开机的耳机2秒, 均可激活语音助手  
• 游戏模式与音乐模式切换: 按住右耳机2秒切换  
注: 单耳使用时, 无法切换游戏模式和音乐模式  
注: 出厂设置默认为音乐模式  
注: 通知声音较大的是游戏模式

指示灯显示

耳机指示灯	状态
白灯和青灯交替闪烁	两个耳机: 开机 单个耳机: 未配对
白灯常亮	充电中
灭灯	配对成功或充满电
充电仓指示灯	状态
环闪灯光	充电仓充电中
绿色常亮	充电仓充满电

如何清除蓝牙配对历史记录

L

R

双耳从充电仓取出后会自动开机配对, 耳机未与蓝牙设备连接或耳机从蓝牙设备取消连接状态下, 分别对左耳机和右耳机连续五击多功能键, 提示音“嘟”四声后, 耳机自动关机后将双耳机放回充电仓, 再将双耳机取出, 双耳机将自动配对, 完成后即可连接蓝牙耳机设备。  
适用于以下情况:  
A: 双耳无法配对时, 单边音时, 双配对名时;  
B: 使用单耳机分别连接不同蓝牙设备时;  
C: 清除连接的所有蓝牙设备时。  
  
特别提示:  
当单边耳机出现无声, 或者无法配对时, 请按以上恢复重置操作。

产品中有害物质名称及含量

部件名称	有害物质						
	铅(Pb)	汞(Hg)	镉(Cd)	六价铬(Cr(VI))	多溴联苯(PBB)	多溴二苯醚(PBDE)	
印刷电路组件	○	○	○	○	○	○	
外壳等小结构件	○	○	○	○	○	○	

本表格依据SJ/T 11364的规定编制。  
○ : 表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下。  
× : 表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求。  
表中标记“X”的部件, 皆因全球技术发展水平限制而无法实现有害物质的替代。

印刷电路板组件: 包括印刷电路板及其零部件、电子元件等, 根据产品类型不同, 您所购买的产品可能不会含有以上所有部件

重要安全说明

在使用本产品之前, 请仔细阅读本说明书中的所有安全说明。

常规安全说明

- 小心使用本产品, 并将其存放在没有极端温度、高温高压和潮湿的清洁环境中, 确保产品存放在不易弯曲或挤压的地方。
- 维修和更换只能由授权的售后服务人员进行。
- 请勿自行拆卸或更换产品的任何部件, 以防受伤或损坏设备。
- 对产品的任何未经授权的修改都将使保修无效。
- 仅在允许蓝牙传输的环境中使用本产品。

个人安全说明

- 如果产品有明显缺陷或出现故障或温度过高等异常, 请勿使用。
- 执行需要全神贯注的高风险任务时, 请勿使用本产品。
- 为了保护听力, 请勿长时间高音量收听。
- 请将产品及其包装放在儿童和宠物接触不到的地方, 以防发生吞咽和窒息等事故

电池安全说明

该产品内置可充电电池, 请参阅以下说明, 确保安全使用和处置。

- 请勿将产品长时间暴露在热源中, 如明火或阳光直射。
- 仅将产品存放在环境温度约为 0°C 至 35°C (32°F 至 95°F) 的环境中。
- 请勿在产品产生灰尘、烟雾、高温、高压或高温度的环境中使用或存放本产品。
- 保持产品干燥, 远离液体或湿气。
- 只能使用经 FCC 或 CCC 认证、输出电压为DC 5V/1A的充电器。
- 充电时不要使用产品。
- 产品充电时间不要超过8小时。
- 按照当地的废物管理规定负责处理地处理产品。

法律声明

商标和许可:

HTC和HTC标志为HTC公司的商标。  
授权给深圳市卜兰沃德科技有限公司使用。  
2025版权©归深圳市卜兰沃德科技有限公司。  
本文档仅供参考, 不构成任何形式的保证, 本公司保留所有权利。

10

11

12

13

14

15

16

<div data-bbox="129 1181 190 1205"> <h1>HTC</h1> </div> <div data-bbox="129 1209 299 1222"> <h2>Wireless Earphones 30</h2> </div> <div data-bbox="173 1308 340 1468"> </div> <div data-bbox="193 1545 325 1578"> <h3>Quick Start Guide HTC NE30</h3> </div>	<div data-bbox="429 1181 596 1194"> <h3>Product Specifications</h3> </div> <div data-bbox="429 1207 504 1215"> <p>Model: HTC NE30</p> </div> <div data-bbox="429 1233 484 1241"> <h4>Bluetooth</h4> </div> <div data-bbox="429 1252 487 1274"> <p>Range: ≈10 m Version: 6.0</p> </div> <div data-bbox="429 1291 478 1302"> <h4>Speaker</h4> </div> <div data-bbox="429 1310 504 1332"> <p>Diameter: 14.2 mm Impedance: 16 Ω</p> </div> <div data-bbox="429 1351 519 1360"> <h4>Earphone power</h4> </div> <div data-bbox="429 1369 542 1418"> <p>Input: 5 V≈40 mA Battery capacity: 40 mAh Battery life: ≈ 5 hrs Charging time: ≈ 1.5 hrs</p> </div> <div data-bbox="429 1435 542 1446"> <h4>Charging case power</h4> </div> <div data-bbox="429 1455 677 1504"> <p>Input: 5 V=300 mA Output: 5 V=80 mA Battery capacity: 300 mAh Charging time: ≈ 1.5 hrs Earphone recharges: 2 charges (when case is fully charged)</p> </div> <div data-bbox="429 1586 435 1595"> <p>11</p> </div>	<div data-bbox="793 1181 922 1194"> <h3>What's in the box</h3> </div> <div data-bbox="793 1215 922 1356"> </div> <div data-bbox="824 1360 891 1369"> <p>Charging case</p> </div> <div data-bbox="793 1377 922 1472"> </div> <div data-bbox="824 1476 891 1485"> <p>2 Earphones</p> </div> <div data-bbox="738 1496 842 1554"> </div> <div data-bbox="752 1558 827 1567"> <p>Quick Start Guide</p> </div> <div data-bbox="870 1504 977 1554"> </div> <div data-bbox="896 1558 971 1567"> <p>USB-C cable</p> </div> <div data-bbox="718 1586 732 1595"> <p>12</p> </div>	<div data-bbox="1110 1181 1208 1194"> <h3>Components</h3> </div> <div data-bbox="1055 1215 1251 1302"> </div> <div data-bbox="1055 1306 1113 1315"> <p>Touchpad</p> </div> <div data-bbox="1055 1323 1113 1332"> <p>Earphone LED</p> </div> <div data-bbox="1026 1341 1277 1390"> </div> <div data-bbox="1026 1397 1142 1405"> <p>Earphone speaker</p> </div> <div data-bbox="1026 1414 1142 1422"> <p>Charging contact</p> </div> <div data-bbox="1026 1431 1251 1500"> </div> <div data-bbox="1026 1504 1142 1513"> <p>Charging case LED</p> </div> <div data-bbox="1026 1522 1142 1530"> <p>USB Type-C port</p> </div> <div data-bbox="1015 1586 1032 1595"> <p>13</p> </div>	<div data-bbox="1343 1181 1571 1194"> <h3>Take out and pair the earphones</h3> </div> <div data-bbox="1381 1215 1534 1390"> </div> <div data-bbox="1315 1427 1594 1554"> <p>If you're using the earphones for the first time, remove both from the charging case. The LED on one earphone will blink white and cyan alternately, indicating that they are in pairing mode. Note: • If the earphones have not been paired with each other, they will automatically enter pairing mode when turned on. You'll hear two beeps when pairing is successful. • If the earphones have been paired before, they will automatically reconnect to each other when turned on. You'll hear a beep when they connect.</p> </div> <div data-bbox="1315 1586 1332 1595"> <p>14</p> </div>	<div data-bbox="1643 1181 1871 1194"> <h3>How to put on the earphones</h3> </div> <div data-bbox="1669 1215 1848 1373"> </div> <div data-bbox="1839 1332 1868 1369"> <p>1</p> </div> <div data-bbox="1687 1386 1822 1571"> </div> <div data-bbox="1839 1539 1868 1576"> <p>2</p> </div> <div data-bbox="1615 1586 1632 1595"> <p>15</p> </div>	<div data-bbox="1952 1215 2142 1373"> </div> <div data-bbox="2139 1332 2168 1369"> <p>3</p> </div> <div data-bbox="1995 1386 2131 1571"> </div> <div data-bbox="2139 1539 2168 1576"> <p>4</p> </div> <div data-bbox="1914 1586 1932 1595"> <p>16</p> </div>	<div data-bbox="2252 1181 2416 1194"> <h3>Power on and off</h3> </div> <div data-bbox="2252 1215 2468 1373"> </div> <div data-bbox="2226 1381 2503 1446"> <p><b>Power on</b> Taking the earphones out of the charging case will automatically turn them on. To manually turn on each earphone, press and hold the touchpad for three seconds. <b>Power off</b> Placing the earphones in the charging case will automatically turn them off. To manually turn off each earphone, press and hold the touchpad for five seconds.</p> </div> <div data-bbox="2226 1513 2503 1576"> <p>Note: If the earphones are not paired with a Bluetooth device within three minutes after powering on, they will automatically power off. They will also power off after three minutes if the paired Bluetooth device moves out of the effective connection range and has not reconnected.</p> </div> <div data-bbox="2214 1586 2229 1595"> <p>17</p> </div>	<div data-bbox="2552 1181 2768 1194"> <h3>Connect to Bluetooth device</h3> </div> <div data-bbox="2552 1215 2633 1418"> </div> <div data-bbox="2540 1422 2650 1463"> <p>On your device, turn on Bluetooth and choose to connect to "HTC NE30".</p> </div> <div data-bbox="2661 1297 2768 1509"> </div> <div data-bbox="2514 1586 2529 1595"> <p>18</p> </div>									
<div data-bbox="193 1632 320 1645"> <h3>Basic operations</h3> </div> <div data-bbox="155 1666 325 1806"> </div> <div data-bbox="155 1815 351 2030"> </div> <div data-bbox="118 2033 135 2041"> <p>19</p> </div>	<div data-bbox="418 1623 493 1636"> <h3>Key functions</h3> </div> <div data-bbox="418 1640 695 1776"> <ul style="list-style-type: none"> <li>• Play/Pause: Tap either earphone once.</li> <li>• Volume up: Tap the right earphone twice.</li> <li>• Volume down: Tap the left earphone twice.</li> <li>• Play previous track: Tap the left earphone three times.</li> <li>• Play next track: Tap the right earphone three times.</li> <li>• Answer/End call: Tap either earphone once.</li> <li>• Reject call: Press and hold either earphone for two seconds.</li> <li>• Activate voice assistant: Press and hold the left earphone for two seconds.</li> </ul> <p>Note: When using a single earphone only, press and hold the active earphone for two seconds.</p> <ul style="list-style-type: none"> <li>• Switch between Game and Music modes: Music mode is the default mode. Press and hold the right earphone for two seconds to switch between modes. (The louder notification sound indicates Game mode.)</li> </ul> <p>Note: Mode switching is disabled when you're using a single earphone only.</p> </div> <div data-bbox="418 1785 493 1793"> <h4>Indicator LEDs</h4> </div> <div data-bbox="418 1798 695 2015"> <table border="1"> <thead> <tr> <th>Earphone LED</th><th>Status</th></tr> </thead> <tbody> <tr> <td>Blinking cyan and white</td><td>Both earphones: Powered on Single earphone: Unpaired</td></tr> <tr> <td>Solid white</td><td>Charging</td></tr> <tr> <td>Off</td><td>Paired or fully charged</td></tr> </tbody> </table>   <table border="1"> <thead> <tr> <th>Charging case LED</th><th>Status</th></tr> </thead> <tbody> <tr> <td>Color cycle</td><td>Case charging</td></tr> <tr> <td>Solid green</td><td>Case fully charged</td></tr> </tbody> </table> </div> <div data-bbox="418 2033 435 2041"> <p>20</p> </div>	Earphone LED	Status	Blinking cyan and white	Both earphones: Powered on Single earphone: Unpaired	Solid white	Charging	Off	Paired or fully charged	Charging case LED	Status	Color cycle	Case charging	Solid green	Case fully charged	<div data-bbox="718 1623 963 1636"> <h3>How to reset the earphones</h3> </div> <div data-bbox="718 1640 994 1690"> <p>If the earphones fail to pair or reconnect to each other, reset them by tapping both earphones five times simultaneously. Note: Resetting the earphones will clear the Bluetooth pairing history.</p> </div> <div data-bbox="726 1694 989 2011"> </div> <div data-bbox="718 2033 732 2041"> <p>21</p> </div>	<div data-bbox="1015 1623 1240 1636"> <h3>Important Safety Instructions</h3> </div> <div data-bbox="1015 1640 1289 1668"> <p>Carefully read all the safety instructions in this document before using the product.</p> </div> <div data-bbox="1015 1673 1162 1681"> <h4>General safety instructions</h4> </div> <div data-bbox="1015 1685 1289 1830"> <ul style="list-style-type: none"> <li>• Use the product with care and store it in a clean environment that is free from extreme temperature, pressure, and humidity. Make sure that the product is stored in a</li></ul></div>
Earphone LED	Status																
Blinking cyan and white	Both earphones: Powered on Single earphone: Unpaired																
Solid white	Charging																
Off	Paired or fully charged																
Charging case LED	Status																
Color cycle	Case charging																
Solid green	Case fully charged																