







The image is a detailed user manual for the HTC NE37 wireless earbuds, presented in a grid format. The manual includes sections for product overview, assembly, basic operations, and troubleshooting. It features line drawings of the earbuds and their components, as well as screenshots of the smartphone pairing process. The HTC logo is located in the bottom right corner.

 <p>htc Wireless Earphones 37</p>	<p>Product Specifications</p> <p>Model: HTC NE37</p> <p>Bluetooth Range: ≈ 10 m Version: 6.0</p> <p>Speaker Diameter: 13 mm Impedance: 29Ω</p> <p>Earphone power Input: 5 V::30 mA Battery capacity: 30 mAh Battery life: ≈ 4 hrs Charging time: ≈ 1 hrs</p> <p>Charging case power Input: 5 V::300 mA Output: 5 V::60 mA Battery capacity: 300 mAh Charging time: ≈ 2 hrs Earphone recharges: 3 charges (when case is fully charged)</p>	<p>What's in the box</p>  <p>Charging case 2 Earphones Quick Start Guide USB-C cable Lanyard</p>	<p>Components</p>  <p>Touchpad Earphone LED Earphone speaker Charging contacts Charging case power display USB Type-C port</p>	<p>Take out and pair the earphones</p>  <p>If you're using the earphones for the first time, remove both from the charging case. The LED on one earphone will blink white and cyan alternately, indicating that they are in pairing mode.</p> <p>Note: • If the earphones have not been paired with each other, they will automatically enter pairing mode when turned on. You'll hear two beeps when pairing is successful; • If the earphones have been paired before, they will automatically reconnect to each other when turned on. You'll hear a beep when they connect.</p>	<p>How to put on the earphones</p>  <p>1 2 3 4</p>	 <p>Power on Taking the earphones out of the charging case will automatically turn them on. To manually turn on each earphone, press and hold the touchpad for three seconds.</p> <p>Power off Placing the earphones in the charging case will automatically turn them off. To manually turn off each earphone, press and hold the touchpad for five seconds.</p> <p>Note: If the earphones are not paired with a Bluetooth device within three minutes after powering on, they will automatically power off. They will also power off after three minutes if the paired Bluetooth device moves out of the effective connection range and has not reconnected.</p>	<p>Connect to Bluetooth device</p>  <p>On your device, turn on Bluetooth and choose to connect to "HTC NE37".</p>										
<p>Basic operations</p>  <p>Power on/off Phone mode Music mode Indicator LEDs Reset earphones</p>	<p>Key functions</p> <ul style="list-style-type: none"> Play/Pause: Tap either earphone once. Volume up: Tap the right earphone twice. Volume down: Tap the left earphone twice. Play previous track: Tap the left earphone three times. Play next track: Tap the right earphone three times. Answer/End call: Tap either earphone once. Reject call: Press and hold either earphone for two seconds. Activate voice assistant: Press and hold the left earphone for two seconds. Note: When using a single earphone only, press and hold the active earphone for two seconds. Switch between Game and Music modes: Music mode is the default mode. Press and hold the right earphone for two seconds to switch between modes. (The louder notification sound indicates Game mode.) Note: Mode switching is disabled when you're using a single earphone only. <p>Indicator LEDs</p> <table border="1"> <thead> <tr> <th>Earphone LED</th> <th>Status</th> </tr> </thead> <tbody> <tr> <td>Blinking white and cyan</td> <td>Both earphones: Powered on Single earphone: Unpaired</td> </tr> <tr> <td>Solid white</td> <td>Charging</td> </tr> <tr> <td>Off</td> <td>Paired or fully charged</td> </tr> <tr> <th>Charging case display</th> <th>Status</th> </tr> <tr> <td>Right: Flashing number</td> <td>Case charging</td> </tr> </tbody> </table>	Earphone LED	Status	Blinking white and cyan	Both earphones: Powered on Single earphone: Unpaired	Solid white	Charging	Off	Paired or fully charged	Charging case display	Status	Right: Flashing number	Case charging	<p>How to reset the earphones</p> <p>If the earphones fail to pair or reconnect to each other, reset them by tapping both earphones five times simultaneously.</p> <p>Note: Resetting the earphones will clear the Bluetooth pairing history.</p> 	<p>Important Safety Instructions</p> <p>Carefully read all the safety instructions in this document before using the product.</p> <p>General safety instructions</p> <ul style="list-style-type: none"> Use the product with care and store it in a clean environment that is free from extreme temperature, pressure, and humidity. Make sure that the product is stored in a location where it cannot be bent or squeezed. Only store the product in environments with ambient temperatures of 0°C to 35°C (32°F to 95°F). Do not use or store the product in dust-prone, smoke-prone, high-temperature, high-pressure, or highly humid environments. Keep the product dry and away from liquids or moisture. Only use an FCC or CCC-certified charger with an output voltage of 5 V/1 A DC. Do not use the product while charging. Do not leave the product charging for longer than eight hours. Dispose of the product responsibly according to your local waste management guidelines. <p>Personal safety instructions</p> <ul style="list-style-type: none"> Do not use the product if it is obviously defective or exhibits abnormalities such as bulging or excessive heating. Do not use the product when performing high-risk tasks that require your full attention. For your hearing protection, do not listen at high volume for long periods. Keep the product and its packaging out of reach of children and pets to prevent accidents such as swallowing and choking. 	<p>Battery safety instructions</p> <p>The product has a built-in rechargeable battery. Read the following instructions to ensure safe use and disposal.</p> <ul style="list-style-type: none"> Keep the product away from prolonged exposure to heat sources such as open fires or direct sunlight. Only store the product in environments with ambient temperatures of 0°C to 35°C (32°F to 95°F). Do not use or store the product in dust-prone, smoke-prone, high-temperature, high-pressure, or highly humid environments. Keep the product dry and away from liquids or moisture. Only use an FCC or CCC-certified charger with an output voltage of 5 V/1 A DC. Do not use the product while charging. Do not leave the product charging for longer than eight hours. Dispose of the product responsibly according to your local waste management guidelines. <p>FCC ID: 2BHJR-NE37</p> <p>FCC Caution: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>US REP</p> <p>Company name: MIRAMONT SOLUTIONS LLC Company address: 34218 HOURGLASS ST, TEMECULA, CA 92592 United States FRN: 0036313369 Agent name: Wenyi Wang Title: CEO Email: wenyiwang@miramontsolutions.com Phone: 951 401 3633</p>	<p>Customer Service Email: service@yhemt.net</p> <p>Legal notice Trademarks and permissions: HTC and the HTC logo are trademarks of HTC Corporation and used under license by Shenzhen Brands World Technology Co., Ltd. Copyright © 2025 Shenzhen Brands World Technology Co., Ltd. All rights reserved.</p> <p>HTC</p>
Earphone LED	Status																
Blinking white and cyan	Both earphones: Powered on Single earphone: Unpaired																
Solid white	Charging																
Off	Paired or fully charged																
Charging case display	Status																
Right: Flashing number	Case charging																