



# PUCK LIGHT INSTRUCTION MANUAL



## Product Feature:

- 1 Battery powered under cabinet lights with remote controls
- 2 Two control modes: Tap control or remote control. You can turn lights on/off individually by pressing on the lamp lens or using remote control. When using the remote control, please aim the LED signal light of the remote control at the puck light you need to operate.
- 3 Dimmable function: Press the button on remote(10%, 40%, 80%, 100%), or long press lamp lens to increase/ decrease brightness(10%-100%). You can freely adjust according to your lighting needs.
- 4 Timing function: You can set different timing(10min, 30min, 60min, 120min) with the remote control, in case of forgetting turn off the lights. To save battery power, the lamp will turn off automatically within 30min without any operation.
- 5 Easy to install: Each light is powered by 3\* AAA batteries(Not included). Coming with adhesive tape, You just need to stick lights on the wall with stick tape instead of installing troublesome electrical wires.
- 6 Multi-purpose: Mini portable light can be placed anywhere you want, such as kitchen cabinet, stair, cupboard, locker, wardrobe, showcase, any dark corner or decoration.

## Product Information:

Brightness: 80 LM  
Light color: Natural white(4000K)  
Power source: AAA battery  
Power: 0.7- 0.8 W  
Working voltage: 2.5 - 4.5 V  
Working current: 60 - 120 mAh  
Working time: Related to the battery you used (Reference time: 40H)  
Remote control distance: 0 - 2 M  
Remote control power: Equipped with a CR2025 button battery

## How to install the light/ replace batteries?

- 1 Rotate the battery back cover counterclockwise and install 3\* AAA batteries (not included)



- 2 Paste double-side adhesive tape (included) on the back cover of lights. Tear off the tape backing and stick the lamp where needed



- 3 Rotate light counterclockwise to separate it from back cover, leaving the cover on the wall, replace the battery, and then re-install it



## Package Included:

6 x LED Puck Light;  
2 x Remote Control;  
6 x Adhesive Tape

## Tips:

- 1 Each light is powered by 3\* AAA batteries. The batteries are not included and need to be purchased separately.
- 2 Before using the remote, please unplug the plastic insulation sheet from the remote.
- 3 In order to save battery power, the light won't be set to stay on. It will automatically turn off in 30min without any operation.
- 4 Please use it on smooth and flat surface. Before installing, please wipe the surface to make sure it is clean, dry, free from dust and oil.
- 5 Since the tape is very sticky, if you need to remove the tape from the wall, please wipe it with alcohol first.

## Warranty:

Please do not directly return used and unsaleable products back to avoid reselling them to other customers, we will provide refund and return guarantee if you encounter any product problems.

## **Warning Statement**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.