


**PF54A0-rb480-85**

**PF54A0-mb480-85**

## **INSTRUCTION MANUAL**



**NEC Platforms, Ltd.**

---

© 2023 by NEC Platforms, Ltd.

All rights reserved. No part of this document may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, including mechanical, photographic, or magnetic, without the prior written permission of the publisher.

**O-RU**  
**GENERAL CONTENTS**

This manual contains the following descriptions of the equipment.

Ref #	CONTENTS	DOCUMENTATION #
<b>■ O-RU Descriptions</b>		
1	<a href="#">Safety Information</a>	<a href="#">GGS-001383-001</a>
2	<a href="#">Installation</a>	<a href="#">GGS-001385-001</a>
3	<a href="#">Specifications</a>	<a href="#">GGS-001388-001</a>
<b>■ Annex</b>		
A1	<a href="#">Radio Frequency Plans</a>	<a href="#">GGS-001390-001</a>

## **DOCUMENTATION OVERVIEW**

---

### **◆Safety Information**

This manual provides precautions and instructions for safely installing, operating, and maintaining the equipment.

### **◆Installation**

This manual provides the description of O-RU hardware and how to install O-RU. This manual also provides how to assemble cables.

### **◆Specifications**

This manual provides system specifications.

## **ANNEX**

### **◆Radio Frequency Plans**

This manual provides the list of frequencies that O-RU supports.