




User Manual

SVITOO P-pad
(Android)

Android User Manual Setup Guide

This setup guide will help you get started, select system language, time zone, connect to Wi-Fi, set up your username, and device name.



Button Functions

● Power button:



◎ When the device is off, long press power button for 3 secs to turn on the device.

◎ When the device is on, short press power button to turn on/off screen.

◎ When the device is on, long press power button for 3 secs to access the shutdown interface, long press for 10 secs to force shut down the device.

● Volume+ button: Press to increase the volume.



● Volume- button: Press to decrease the volume.



Virtual Button Bar

	HOME button	click to return to home screen
	Back button	click to return to the previous screen
	Recent button	click to view, switch and close recent apps
	Menu button	click to open menu
	Screenshot button	click to screenshot the current screen
	Volume +	increase volume
	Volume -	decrease volume

Control Center

	User	click to switch local user accounts
	Settings	click to access to system settings
	Battery	click to access battery settings
	Wi-Fi	click to turn on/off Wi-Fi
	Bluetooth	click to turn on/off Bluetooth
	Volume	click to quickly adjust volume
	Flight mode	click to turn on/off airplane mode
	Auto-rotation	click to turn on/off auto-rotation
	GPS	click to turn on/off GPS
	Miracast	click to turn on/off Miracast

Wi-Fi Connection

1. Open Settings and go to Network & Internet setting.
2. Turn on Wi-Fi, choose a wireless network, and enter the network password to connect.

Cellular Connection

1. power on the system.
 2. Open Settings and go to Network & Internet setting.
 3. Turn on cellular data toggle.
- *Applicable to supported devices only.

Bluetooth Connection

1. Open Settings and go to Connected Device setting.
 2. Turn on Bluetooth and system will automatically search for Bluetooth devices nearby.
 3. Click on the connectable Bluetooth device then select Pair in the pop-up menu.
 4. Wait for the Bluetooth device to confirm pairing.
- *Applicable to supported devices only.

Display

Open Settings and go to Display setting.

1. Brightness: Slide the bar to adjust screen brightness.
2. Wallpaper: Set the wallpaper.
3. Sleep: Set screen time-out.
4. Font size: Set the size of system fonts.
5. Auto-rotation: Lock current screen orientation or automatically rotate the screen based on device orientation.

Sound

Open Settings and go to the Sound setting.

1.Volume: Slide the bar to adjust the volume of media, alarm, and ringtone.

2.Notification: Set notification sound.

3.Ringtone: Set incoming call ringtone.

4.Other Sounds: Set lock screen and touch sound effects

Battery Status

Open Settings and go to Battery setting to view battery usage.

Battery Indicator: Toggle the switch to display battery percentage.

Connect to PC

Device can be connected to a PC using a USB cable to copy or delete data on the device.

1.Operating systems including Windows 7 and above will automatically install MTP drivers when the device is connected to a PC.

2.For Windows XP, Windows Media Player 11 must be installed before the device can be connected.

Application Management

Open Settings and go to Application setting to uninstall apps, clean cache & data, and force close apps.

- 1.Third-party applications: can be uninstalled.
- 2.System applications: cannot be uninstalled.

Users

Open Settings and go to User setting.

- 1.System supports multi-user login.
- 2.Each user can set their personal applications and content.

Location

Open Settings and go to Location setting.

- 1.Toggle Use Location switch to turn on/off location services.
- 2.View recent location requests and configure location permission on a per-app basis.

Security

Open Settings and go to Security setting.

- 1.Screen lock modes: choose between swipe, pattern, pin, and password modes.
2. Unknown source: allow/deny app installation from unknown sources

Language and Input

Open Settings and go to Language and Input setting.

- 1.Language: select system language.
- 2.Input: select the default system input method and its respective settings

Accounts Management

Open Settings and go to Accounts setting.

- 1.Add accounts for installed applications.
- 2.Manage data syncing for existing accounts.

Factory Reset

1.Open Settings and go to System Setting, Advanced, Reset Options to perform a factory reset.

2.Factory reset will erase all personal data, please backup your data before resetting.

Date and Time

Open Settings and go to Date and Time setting.

1.Automatic date & time: turn on to automatically sync to local time when connected to the internet. You can manually adjust the date and time by turning off this function.

2.Automatic time zone: turn on to automatically sync to local time zone when connected to the internet. You can manually adjust the time zone by turning off this function.

3.24-hour format: choose between AM/PM and 24-hour display formats.

USB OTG function


This device supports USB OTG function to exchange data with other portable devices (flash drive, mobile hard disk, mouse, and keyboard).

1.Devices need to be connected to this device via an OTG cable.

2.Please keep battery above 50% while using OTG function. A separate power supply is needed for high-power consumption devices.

Android ユーザーマニュアル セットアップガイド

このセットアップガイドは、タブレットの開始、システム言語、タイムゾーンの選択、Wi-Fi の接続、ユーザー名およびデバイス名の設定などを説明します。



ボタン機能

● 電源ボタン:



◎本機の電源が切れている状態で、電源ボタンを3秒間長押しすると、電源が入ります。

◎本機の電源が入っている状態で、電源ボタンを短押しすると、画面がオン/オフになります。

◎本機の電源が入っている状態で、電源ボタンを3秒間長押しすると、シャットダウンのインターフェイスにアクセスし、10秒間長押しすると、強制的にシャットダウンすることができます。

● 音量プラスボタン: 押すと音量が上がります。



● 音量マイナスボタン: 押すと音量が下がります。



バーチャルボタンバー

	ホームボタン	クリックするとホーム画面に戻ります
	戻るボタン	クリックすると前の画面に戻ります
	タスクボタン	クリックしてアプリを表示・切り替え・終了します
	メニューボタン	クリックするとメニューが表示されます
	スクリーンショットボタン	クリックして現在の画面をスクリーンショットします
	音量プラスボタン	押すと音量が上がります
	音量マイナスボタン	押すと音量が下がります

コントロールセンター

	ユーザー	クリックしてローカルユーザーアカウントを切り替えます
	設定	クリックしてシステム設定にアクセスします
	バッテリー	クリックしてバッテリー設定にアクセスします
	Wi-Fi	クリックして Wi-Fi がオン/オフになります
	Bluetooth	クリックして Bluetooth がオン/オフになります
	シーンモード	クリックして素早く音量を調整します
	機内モード	クリックして機内モードがオン/オフになります
	自動回転	クリックして自動回転がオン/オフになります
	GPS	クリックして GPS がオン/オフになります
	Miracast	クリックして Miracast がオン/オフになります

Wi-Fi 接続

1. 「設定」を選択して、「ネットワークとインターネット設定」を選択します。
2. Wi-Fiをオンにして、アクセスポイントを選択して、パスワードを入力し、接続します。

モバイルネットワーク

1. SIMカードを挿入して、電源が入っています。
 2. 「設定」を選択して、「ネットワークとインターネット設定」を選択します。
 3. 「モバイルネットワーク」をオンにします。
- *対応機器のみに適用します。

Bluetooth 接続

1. 「設定」を選択して、「デバイス接続設定」を選択します。
 2. Bluetoothをオンにすると、システムが自動的に近くのBluetoothデバイスを検索します。
 3. 接続可能なBluetoothデバイスをクリックし、接続確認画面の「ペア」を選択します。
 4. 相手のBluetoothデバイスが確認して、接続完了します。
- *対応機器のみに適用されます。

ディスプレイ

- 「設定」を選択して、「ディスプレイ接続設定」を選択します。
1. 明るさのレベル: バーをスライドさせて画面の明るさを調整します。
 2. 壁紙: 壁紙を設定します。
 3. スリープ: 画面のタイムアウトを設定します。
 4. フォントサイズ: システムフォントのサイズを設定します。
 5. 自動回転: 画面の向きを固定したり、デバイスの向きに応じて自動的に画面を回転させることができます。

音

「設定」を選択して、「音設定」を選択します。

- 1.音量: バーをスライドさせてメディア、アラーム音や着信音の音量を調整します。
- 2.通知: 通知音を設定します。
- 3.着信音: 着信音を設定します。
- 4.他の音: 画面ロック音やタッチ操作音の効果を設定します。

バッテリーの状態

「設定」を選択して、「バッテリー設定」を選択し、バッテリーの使用状況を確認します。

バッテリーインジケーター: スイッチを切り替えると、バッテリー残量はパーセントで表示されます。

パソコンとの接続

USBケーブルでPCと接続し、デバイスのデータをコピーまたは削除することができます。

- 1.Windows 7以上のOSでは、デバイスをPCに接続するとMTPドライバーが自動的にインストールされます。
- 2.Windows XPの場合は、デバイスを接続する前にWindows Media Player 11をインストールする必要があります。

アプリケーション管理

「設定」を選択して、「アプリケーション設定」を選択し、アプリのアンインストール、キャッシュやデータの削除、アプリの強制終了ことができます。

- 1.サードパーティ製アプリケーション: アンインストール可能です。
- 2.システムアプリケーション: アンインストール不可です。

ユーザー

「設定」を選択して、「ユーザー設定」を選択します。

1. 複数ユーザーのログインも可能です。
2. 各ユーザーが自分のアプリケーションやコンテンツを設定することができます。

位置情報

「設定」を選択して、「位置情報設定」を選択します。

1. スイッチで位置情報サービスをオン/オフにします。
2. 位置情報要求が表示されたり、アプリごとに位置情報の許可を設定したりすることができます。

セキュリティ

「設定」を選択して、「セキュリティ設定」を選択します。

1. スクリーンロック: スワイプ、パターン、pinコード、パスワードのロック解除方法が選択可能です。
2. 提供元不明のアプリ: 提供元不明のアプリのインストールを許可または拒否します。

言語と入力

「設定」を選択して、「言語と入力設定」を選択します。

1. 言語: システム言語を選択します。
2. 入力: デフォルトのシステム入力を選択または設定します。

アカウント管理

「設定」を選択して、「アカウント設定」を選択します。

1. インストールされたアプリケーションのアカウントを追加します。
2. 既存のアカウントのデータの同期管理をします。

工場出荷時のリセット

- 1.「設定」を選択して、「システム設定」、「アドバンスド」、「リセット」を選択し、リセットします。
- 2.ファクトリーリセットをすると、すべての個人データが削除されます。リセットする前に、データをバックアップしてください。

日付と時刻

- 「設定」を選択して、「日付と時刻設定」を選択します。
- 1.日付・時刻自動調整：オンにすると、インターネットに接続したときに自動的にローカルタイムに同期します。この機能をオフにすると、手動で日付と時刻を調整することができます。
 - 2.タイムゾーン自動調整：オンにすると、インターネットに接続したときに自動的にローカルのタイムゾーンに同期します。この機能をオフにすると、手動でタイムゾーンを調整することができます。
 - 3.24時間表示：AM/PMと24時間表示のフォーマットを選択できます。

USB OTG機能

本機はUSB OTG機能に対応できます。他の携帯端末（フラッシュメモリ、モバイルハードディスク、マウス、キーボード）とのデータ交換が可能です。

- 1.デバイスはOTGケーブルで本機と接続する必要があります。
- 2.OTG機能を使用する際は、バッテリー残量を50%以上にしてください。高消費電力のデバイスには独立電源が必要です。

Charger Specifications

©Charger specs should match the input voltage/current shown on the back of the product.

©Please only use chargers that meets the above specification.

©Please do a full recharge every 3 months if the product is going to stay unused for an extended period.

©For first use after storage, the product may require a 30 minute charging session before charging status is indicated.

Shenzhen Chuanzheng Technology CO.,Ltd

Official website : www.svitoopad.com

Technical support: chuanzheng@svitoopad.com

Made in China



SVITOO

Warranty Rules

Dear Customer,

Thank you very much for using our products, Please read the rules carefully .

1. One year warranty

According to the prescription, the period for protecting to fix our company' s tablet is one year. (From the day when you have the invoice) During this period, any belongs to under normal usage circumstance cause because of the product quality's problem of breakdown, our company will be responsible for giving free maintain.

2. Free maintain won' t be given under the following circumstance :

- ⊙ Without Protection to fix warrantees.
- ⊙ The device is out of the warranty period.
- ⊙ The damage caused by customer inappropriate preservation, maintain, or the usage.
- ⊙ The serial number on the back cover is too dim to recognize if it is Svitoo products.
- ⊙ The breakdown caused by the manipulation that hasn' t follow the requests of the manual.
- ⊙ The breakdown, row harm or damaged because of the move or drop.
- ⊙ The breakdown and the damage caused by the force majeure.
- ⊙ The breakdown caused careless protection on the way to service center
- ⊙ The damage caused by the dismantle movement of a non-our-company authorized maintainer.

3. Customer responsibility

3.1 Users should take the responsibility of the data safety

3.2 Please back up all your important data before send your tablet to our service center.

3.3 Svitoo will not take the responsibility of the data missing .

3.4 Screen is easy-broken accessories, please avoid the damage from drop or crash. otherwise you should pay the extro fixing fee.

3.5 Please carefully check the screen before purchase the tablet .

3.6 Svitoo reserves all the right for the final explanation.

Warranty Card

Model No.: _____

Serial No.: _____

Reseller Name : _____

Phone: _____

User' s Name: _____

Phone: _____

Address: _____

E-Mail: _____





Model No.: _____

Serial No.: _____

Please contact with your sellers or local distributors for after sales service.



FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.