








Remote Control Products User Manual




Product name: RC CAR
Item number: 9989

Customer Support:
wecare@lifewarranty2.com


<PRODUCT CONTENTS>

					
Product	Remote Control	Module Battery	USB Type-C cable	Screwdriver	Instruction of Use
x1	x1	x2	x1	x1	x1

<PRODUCT DETAILS>




<REMOTE CONTROL FUNCTIONS>



<BATTERY INSTALLATION>

How to Charge the Car Battery

1. Press the latch to remove the module battery and connect it with the charging cable
2. Plug the USB charging cable into a 5V power source with maximum 2A output (e.g. PC USB port, phone charger, power bank).




Do not connect the output or input ports of the module battery with metal objects, as this may damage the battery or be dangerous.

Notice:

1. Do not charge the battery immediately after use. Allow the battery to cool for at least 10 minutes.
2. The module battery indicator light turns red under charging, and turn off when charging is complete. The charging time is about 120 minutes, depending on the remaining battery power.
3. When the battery is low, the car light will be obviously dimmed or the car will slow down. Please replace and recharge the battery in time.

Remote Control Battery



1. Open the battery cover.
2. Install 2x1.5V AA batteries(not included) in the correct positive (+) and negative (-) polarities direction.
3. Close the battery cover.

Notice:


1. If the remote control is not be used for a long time, please take out the batteries.
2. Adult supervision recommended at all times.
3. Please play the car on a clean flat surface.

<OPERATION>


1. Pairing

1. Turn on remote control and the remote indicator light is flashing.
2. Turn on the vehicle. The vehicle will be paired with remote automatically.
3. The remote control indicator light turns solid when they are successfully paired.

2. Forward and Backward




3. Vertical Rotation



4. Horizontal Rotation

Push the left joystick and the right joystick at the same time, the car will do horizontal rotation.



<OPERATION>

5. Auto Demo Mode

Press the auto demo button, and the Product will enter demo mode, press any of other button to exit demo mode.

<SPECIFICATIONS>

Frequency: 2.4GHz
Dimension: 150x150x85mm
Play Time: about 18-20 mins
Control Distance: about 40 meters
Battery type for product: Modular Battery(included)
Battery type for remote control: 1.5V AA batteries(not included)

<TROUBLE SHOOTING>

PROBLEM	SOLUTION
Motor does not run	1. Power switch is off. Please turn it on. 2. Battery out of power. Please charge it. 3. Restart the car and remote and repair them.
Suddenly stopped during operation	1. Check if the battery is out of power. 2. Replace or recharge the battery.
Remote control Power indicator flashing	1. AA batteries are out of power. Replace them. 2. The car is not paired with remote successfully. Restart the car the remote and repair them.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC ID: 2BHS-9989
Manufacturer: WEILONG TOYS FACTORY
Address: CHENGHAI DISTRICT, SHANTOU CITY, GUANGDONG PROVINCE, CHINA 515000

WARRANTY

1. All the Product carries a 100% satisfaction guarantee.
 2. Stay up-to-date on what's new from us.
 3. All the products are covered by unconditional lifetime warranty when you complete the registration process by scanning the code.
- Customer Support: wecare@lifewarranty2.com

