

# Intelligent Music Boxing Target



## USER MANUAL

# Product Introduction:



## Instructions for use:

Keys (from left to right)

Left: Speed gear adjustment/selection of light color

Short press - speed gear cycle adjustment (random mode, practice mode)

Long press and short press - select the color of the light (flowing light)

Middle: Switch/Mode:

Long press - turn on/off

Short press - mode selection

Random Mode - 5 hit points appear randomly

Practice mode - 9 speed gears, manually adjustable in 1-9 gears

Challenge Mode - Practice Mode Upgrade (Challenge), Automatic Upshift, Upshift with Encouragement Sound

Bluetooth mode - Challenge mode Bluetooth version

Right: Volume adjustment/background sound selection

Short press - volume adjustment

Long press and short press - background sound selection

# Installation instructions:

## Installation method one

1. Tear open the fur Velcro (short Velcro) The sticker on the back, Directly attach to the back of the machine. When pasting, pay attention to the parallel direction of the machine.

## Installation Method 2

2. Then apply the hook faced Velcro (long Velcro) Glue together with the machine's rough surface, Find the location of the corresponding wall, Determine the position, tear off the back sticker, and use magic to create a long magic spell Simply fix it to the wall.

## NOTES:

1. Please fix this product on a sturdy and reliable wall, and when striking, please strike within the striking area  
Striking is strictly prohibited in the corner areas to prevent hand injuries or equipment damage.
2. This product is suitable for adult use. Children should be guided to use it under adult supervision.
3. Beginners should not use excessive force to avoid hand injuries. Pay attention to the process of exercise first  
Safe, leg strikes and knee strikes are strictly prohibited.
4. It is strictly prohibited to hit the horn area.
5. The device cannot be turned on or has abnormalities. Please check if the battery is too low and charge it promptly,  
The charging time should not exceed 8 hours, and it is recommended to charge once every 1-2 months when not in use for a long time.
6. This product is not waterproof. When wiping boxing targets, use a dry cloth and do not get wet.
7. Please keep the instruction manual properly for emergency use.

# Troubleshooting:

Number	Fault phenomenon	Fault phenomenon	Exclusion method
1	No light or sound	The product is not turned on	Long press the power button
2	No light or sound	Battery depleted	Please charge
3	Low battery prompt or automatic shutdown	Low battery level	Please charge
4	The switch cannot be turned on	Long term failure to power on results in power shortage of the main chip capacitor	Repeatedly long press the switch/charge

## Certificate of conformity

This product has passed strict testing and is allowed to leave the factory

Product Name: Second Generation Intelligent Music Boxing Target

Inspector: \_\_\_\_\_



Factory date: \_\_\_\_\_

**FCC Warning Statement:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### **FCC Radiation Exposure Statement**

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.