


# **INSTRUCTION MANUAL**



**English P1-P18**

Please read the manual carefully  
before operating projector..

# Contents

Important Safeguards .....	1
Accessories List .....	1
Projector Knowledge .....	2
Specifications .....	4
Multimedia Format Supported .....	4
Remote Control .....	5
Projector Installation .....	6
Standard Setting .....	7
Installation Method .....	7
Turn the Projector Operation On/Off .....	7
Use of the Projector .....	8
Image focusing .....	11
How to Use Projection Settings .....	11
How to Select the Source .....	13
How to Connect Bluetooth .....	15
How to Use iOS Cast .....	16
How to Use Miracast .....	16
How to Play Files in USB Disk .....	18

# Important Safeguards

## Installation

- To get a better watching, please use this projector while drawing the curtain or in a dark room.
- Please use the projector carefully, dropping or crashing may damage parts or result in blurred images and abnormal displaying.

## Power

- Be careful while using the power cord, avoid excessive bending; the damage of power cable may cause electric shock and fire.
- It is better to unplug the power cord after power off.

## Cleaning

- Unplug the power cable firstly.
- Clean the shell regularly with a damp cloth, neutral detergent can be used.
- Please use a glasses cloth or lens paper, not to scratch the lens.
- Please clean projector's vents and speakers regularly by banister brush, or the ventilation will be blocked.

## High Temperature Attention

- While projection or just finishing, the exhaust port nearby will be very hot, if touch it, would get scald.
- While projection, please do not look the lens directly, or may hurt eyes.

## \*Warm Tips

- Do not disassemble the projector, if not, there will be a risk of electric shock, and the disassembling affect the normal warranty.
- Please do not put any liquid or heavy stuff on the projector.
- To ensure the stability of heat dissipation, please open the height bracket in the bottom of the projector before starting.

# Accessories List

Remote Control ×1


Power Cable ×1

User Manual ×1

HDMI Cable ×1

# Projector Knowledge


Projector can input high-definition video signal and composite video signal, and support stereo audio signal input and output. Please refer to the following figure to connect the projector and other audio equipment according to your own needs.



1. Lens
2. IR Receiver
3. Camera  
(Only available in auto focus version)
4. 3.5mm Port for Audio Output
5. USB Port
6. HDMI Port
7. IR Receiver

8. Cooling Window
9. Cooling Window
10. Power Socket
11. Air inlet
12. Speaker
13. Air inlet
14. Speaker

## Projector Knowledge



1. Power Key
2. OK Key
3. Arrow keys
4. Return key
5. Bracket Holes (1/4 inch nut\*1, depth 6mm), Supports Hoisting
6. Bottom Label

## Specifications

Model	Multimedia Projector
Lamp	LED
Image System	LCD
Input Voltage	AC 100-240V 50/60Hz
Weight	1.95 KG
Working Temp	0-35°C
Input Port	HDMI / USB
Output Port	Headphone
Aspect Ratio	16:9 / 4:3
Size	153.5×155.5×231.1mm
Operation Mode	Manual / Remote Control


## Multimedia Format Supported

Image Format	JPG/PNG/JPEG/BMP/GIF
Audio Format	MP3/FLAC/M4A/ WAV/OGG/WMA/APE/MID
Video Format	MP4/MPG/RM/MKV/AVI/TS/VOB/M2TS/3GP/MOV/RMVB /FLV/DAT
File Format	TXT/EXCEL/WORD/PDF



This model does not support any Dolby audio decoding due to the copyright of Dolby patent.

# Remote Control



1. Signal Indicator
2. Power Key
3. Arrow keys
4. Return key
5. Volume+
6. Volume-
7. Source key
8. Confirmation key
9. Menu
10. Home
11. Focus+
12. Focus-
13. Mute key

# Projector Installation

## Standard Setting


Please refer to the following table to adjust your picture size and distance. (from the lens to the screen).

Aspect ratio	16:9
Picture size (inch)	Projection distance (m)
50	1.48
80	2.30
100	2.86
120	3.40

Please allow  $\pm 3\%$  to the image sizes in the table above. If the distance is less than min data and more than max data, the image could be blurry.


## Warning:

Please check the diagram below for the trapezoid adjustment.



Forbidden Installation Method  
(As the right picture)

Portable Bedside Stand (The Risk of Falling)




# Projector Installation

## Installation Method

Depending on your usage environment and needs, you can use a special hanger to hang it forward on the ceiling. (The lifting device should bear 4 times the weight of the product)

It can also be placed on a stable table to project forward to the screen. Of course, you can also use other ways to install and use the projector according to the following illustrations.



## Warning:

1. The projector may be damaged beyond repair if it is incorrectly mounted on a ceiling or on a surface.
2. The projector should only be used in an environment where the temperature does not exceed the range of 5 C-35 C. Projector malfunction may occur if this is not adhered to.
3. Malfunction may occur if the projector is subjected to dusty, wet, moist or smoky conditions.
4. Poor ventilation could cause overheating which could lead to damage to the projector as well as a life threatening situation.

## Turn the Projector Operation On/Off

When the projector is connected to a power source, the projector enters standby and the cover signal indicator turns blue breathing state and it will go out after 3 cycles.

**Operation on:** Press the power key on the body or the power key on the remote control, the indicator will turn blue and enter the working state.

**Operation off:** In the working state, press the power key of the body or the power key on the remote control, the indicator changes to the breathing light state and the projector is turned off.

## Use of the Projector


### Image focusing

When the newly installed projector is used for the first time, the image will be blurred, and it is necessary to focus the picture;

#### Manual Focus

When the picture is blurred, press the focus keys "F+" and "F-" on the remote control to adjust the focal length of the lens. Tap or long press the focus button until the picture is clear. (As shown below)

Or press the menu button on the remote control; select "Settings" → Keystone → Projection Settings → Motor Focusing.




# Use of the Projector

## How to Use Projection Settings

Select the settings icon in the upper right corner of the main interface, and then press the "OK" key on the remote control to enter the settings interface and select "Projection Image Setting".

After entering the interface, select the mode you want in the projection settings.

Projection mode: Front-Desktop / Rear-Desktop / Front-Ceiling / Rear-Ceiling




## ◀ Projection

Projection Mode	◀	Front-Desktop	▶
Keystone Advanced	◀	Manual	▶
Horizon Keystone	◀	0	▶
Vertical Keystone	◀	0	▶


Note: As the product system is updated from time to time, the specific operation content is based on the actual situation.

# Use of the Projector

Manual Keystore (Manually adjust the four corners through the arrow keys until the screen can be corrected )




Motor Focusing (This function is turned on by default, and the screen can be kept square even after the device is displaced. )




Note: As the product system is updated from time to time, the specific operation content is based on the actual situation.

# Use of the Projector

Digital Zoom (Zoom out or enlarge the image )



The picture ratio is best when the center circle is a perfect circle



"◇"Adjustment      "S" Back      "≡"Reset


Note: As the product system is updated from time to time, the specific operation content is based on the actual situation.

# Use of the Projector

## AutoFocus

(※Auto focus and auto keystone are only available on the auto focus version, do not cover the camera during auto focus)


When this function is turned on, the device will automatically focus to keep the picture clear after the distance of the device is displaced.



# Use of the Projector

## How to Select the Source


Select the source channel you want to enter in the list on the left side of the main interface, such as HDMI , then press the "OK" key on the remote control to enter the corresponding source interface.



## How to Connect to WiFi



Select the settings icon in the upper right corner of the main interface, press the "OK" key on the remote control to enter the settings interface, and select "WiFi Setting".

After entering the interface, select the WiFi you want to connect to in the list below, then enter the password and complete the connection. Connected will be displayed behind the successfully connected WiFi.



Note: As the product system is updated from time to time, the specific operation content is based on the actual situation.

# Use of the Projector



Note: As the product system is updated from time to time, the specific operation content is based on the actual situation.


# Use of the Projector

## How to Use iOS Cast

In the main interface, select "iOS Cast", press the "OK" key on the remote control to enter the interface, and then set up in the order in the interface.

Note: The projector needs to be connected to the Internet for using the iOS Cast or upgrading the projector for the first time

1. The iOS device and the projector are connected to the same network
2. Open the control center of the iOS device and select Screen mirroring
3. Choose the corresponding projecton device name.



Make sure that your iOS device is connected to the same network as your Projector.

The diagram illustrates the three steps to enable screen mirroring on an iOS device. Step 1 shows a smartphone's control center with the 'Screen Mirroring' option highlighted. Step 2 shows the list of available devices, with 'BirdCast-XXXX' selected. Step 3 shows the 'BirdCast-XXXX' device selected from the list.

1. On your iOS device, open Control Center and tap screen Mirroring.
2. Looking for devices that can be mirrored on.
3. Select BirdCast-XXXX from the list.


Network error BirdCast-XXXX

# Use of the Projector

## How to Use Miracast


Select "Miracast" in the main interface and press the "OK" key on the remote control to enter the interface, and then set up in the order in the interface.

1. Turn on the WIFI of the Android device. (It is recommended that the projector is connected to the same router or the WIFI of the Android device is not connected to any router).
2. Turn on the "Wireless Display" of the Android device.
3. Select the corresponding projector device name.



## Miracast

To connect Android mobile/Pad with Projector Based on WiFi-Display Technology




1. On your Android device, turn on WLAN (not necessary to connect to any Wi-Fi router)
2. Launch the Multi-screen/ Wireless Display / Screen Mirroring / Smart View function
3. Select Please waiting from the searching result list

# Use of the Projector

## How to Play Files in USB Disk

Select the required category "movie", "music", "photo" or "Office Suite" in the main interface, and press the "OK" key on the remote control to enter the corresponding category.

Then find the file you want to play in that category, start playing by pressing "OK" key. (You cannot enter the required category without connecting a USB disk.)



### FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.