

SECRET WHISPERS IN THE WOODS
INTO THE DREAM LANTERN

INSTRUCTIONS FOR USE

Before use, be sure to read the product




MP-G

Product Parameters

Product Name:secret Whispers in the woodsinto the dream lantern
Product Number: MP-G
Signal-to-noise Ratio: > =95db
Response Frequency: 20hz-20khz
Bluetooth Version: v5.1
Battery Capacity: 800mah
Rated Voltage: 3.7v
Rated Power: 1.6w
Charging Time: ≈2h

Function Description



- ① Diffusing Stone
- ② Charging Port
- ③ Display Light (charging and Bluetooth mode)
- ④ Bluetooth button
- ⑤ Light button
- ⑥ Indicator light (light mode)
- ⑦ Audio speaker

Function Description

Light button Short press once mode ①: night light mode (Left light on)
Short press mode ② again: sleep companion mode (Middle light on)
Short press mode ③ again: night mode (Right light on)
①Night light mode: In the 30min timer mode, the night light gradually turns off. Mode ①, mode ③ double click: switch the lighting mode.
Mode ③ long press: infinite dimming.
[The light is bright-dark stepless adjustment cycle, and the last light brightness will be remembered by default when the light is turned on next time]

Bluetooth button Short press: connect Bluetooth/turn off Bluetooth (corresponding indicator light white lights on/off)

Indicator Lack of power - flashes quickly for 10 times and then cuts off the power; charging - the breathing light flashes and displays; Fully charged - light off (can work while charging)

Bluetooth connection
1. Short press the power button to turn on;
2. Search for the device named "PROLER BORN" on the Bluetooth interface; after the connection is successful, the product A tone will play.

Parts List

MADE IN CHINA
CE FC RoHS

- 1. Diffusing stone
- 2. Comes with essential oil
- 3. Bluetooth audio
- 4. Charging Cable

Product Safety Guidelines and Precautions

Please read this manual carefully before use and operate according to the instructions.

- 1. Please place the speaker in a stable and safe place to avoid falling and causing damage or personal injury.
- 2. Keep enough space around the speaker for optimal sound quality performance
- 3. Do not insert any foreign objects into the speaker grille or jack; do not hit the speaker vigorously or hit the speaker with external force.
- 4. Because essential oils are corrosive, please do not touch places other than the diffuser stone. Remember to wipe dry after cleaning the diffuser stone. Reinstall the product, otherwise the product may be damaged
- 5. Stay away from heat sources and do not get close to open flames, microwave ovens, electric heaters and other electrical appliances that can generate high heat. To ensure safety, only Ability to use included accessories
- 6. If you have any questions, please contact the original manufacturer or agent to consult professional maintenance personnel to solve the problem.

Note: This product is suitable for use by people over 18 years old

产品保修卡
(本卡只适合中国地区)
This card is only suitable for China

产品名称: product name	联系方式: contact information
产品型号: product number	购买地址: purchase address
用户姓名: username	购买时间: purchase time
经销商名称: dealer name	

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement.

This equipment complies with FCC's RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or conjunction with any other antenna or transmitter.