

80.00 mm
64.00 mm

Wi-Fi camera

Manual

Please read the Manual carefully before using the product and keep it properly.

Connection Instructions

Connect the power interface and the power socket with the power cord.

To use Wi-Fi

Voice broadcast instructions

Indicator light	Indicator state
Red light flashes slowly	Waiting for network configuration
Blue light stays on	Network configuration failed
Blue light flashes quickly	Network configuration completed
Red light flashes quickly	Disconnected from the network
Red light stays on	Long press the reset button to reset
Red light stays on	Device connecting
Red light stays on	On the Wi-Fi network
Red light stays on	Charging
Red light goes out	Full charged

Camera reset

When the camera is powered on, press and hold the reset button for 10 seconds and you will see the indicator light turning black. In this case, then release the reset button. When the camera is reset, and the reset is successful.

Connection method—Bluetooth

- Find the device Bluetooth, and click "Connect".
- Click "Add", this page jumps to figure 2-2.

Connection method—Scan the QR code

- Scan the QR code on the camera label.
- Click "Add" to add device.

[illegible]

FCC Warning

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- *Increase the separation between the equipment and receiver.

- *Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- *Consult the dealer or an experienced radio/TV technician for help.

SHENZHEN MOREJOY INNOVATION TECHNOLOGY CO.,LTD

1907A6K, International Culture Building, No. 3039, Shennan Middle Road, Funan Community, Futian Street, Futian District, Shenzhen