

说 明 书

ZLE010



首次使用请先为产品充电

怎样使用APP



- 1.扫描右方二维码，然后下载和安装APP。
- 2.首次登录时，点击“+”扫描产品标识二维码或手动输入产品标识，设备成功。
- 3.启动产品开关，打开手机的蓝牙，点击“我的设备”图标播放产品。



Android



- 1.扫描Apage上的二维码，注册成为“爱之伴侣”的会员
- 2.第一次登录，点击“+”扫描产品识别二维码或手动输入产品识别码，设备登录成功。
- 3.启动产品开关，打开手机的蓝牙，点击“我的设备”图标来播放产品。



Product
Identification
Code
(8314)

交互模式

点击交互方式或刷APP的操作界面进入交互方式，或点击APP首页的交互按钮进入交互方式并添加好友。

1.点击“好友”按钮在互动界面会出现“好友搜索”框您可以按性别和年龄搜索相应的注册用户。

2.单击要进行交互的朋友图标，系统将发起交互邀请，单击确定，如果对方接受您的邀请，则交互连接成功。

3.交互式连接成功后，默认禁用视频。您必须邀请对方打开视频，对方同意启用视频功能，然后才能打开双方的视频。

操作说明

- 1.开/关/主体伸缩震动键
- 2.嘴唇震动/包蛋震动键
- 3.嘴唇震动
- 4.包蛋震动
- 5.主体伸缩震动
- 6.磁吸充电接口



1、开/关/主体伸缩震动键：

长按1.5秒 “①” 开/关键，电源键灯光常亮，进入待机状态，再次单击“①”启动主体伸缩震动功能，再次单击切换频率，1-9频伸缩震动循环转换，长按电源键1.5秒产品关机。

2、嘴唇震动/包蛋震动键

待机状态下，单击“②”，启动嘴唇/包蛋双震动功能，再次“②”单击切换频率，1-9频循环转换，长按1.5秒功能暂停。

3、遥控器

长按1.5S “③” 开/关键灯光闪烁一下进入待机状态，再次点按启动主体伸缩震动功能 1~9频循环转换，长按“③”1.5秒关机；待机状态下点按“④”启动嘴唇/包蛋双振动功能 1~9频循环转换。

规 格 参 数

产品名称:嘴唇锁精伸缩震动肛塞
产品尺寸:221*40*157MM
产品材质:硅胶+ABS
功能模式:9*9频
噪音等级:≤45dB
额定电压:3.7V

输入电流:5V/1A
防水性能:IPX6级防水
充电方式:磁吸充电
充电时间:2小时左右
使用时长:1小时左右
适合人群:十八岁以上人群使用

包 装 清 单

嘴唇锁精伸缩震动肛塞*1、产品说明书*1、USB充电线*1。

使 用 说 明

- 1.使用前请详细阅读本说明书,按照说明书提示规范使用。
- 2.第一次使用请先为产品充电。
- 3.使用后请保持产品清洁,请勿使用带腐蚀性清洁剂清洗。
- 4.本产品禁止18岁以下未成年人使用。

注意 事 项

- 1.请使用标配的USB充电线充电。
- 2.产品充电时禁止使用产品。
- 3.本产品内置聚合物锂电池，不可自行拆卸,以免对产品造成毁坏。
- 4.本产品使用后，应放置在干燥通风处,避免阳光直射。

INSTRUCTIONS

ZLE010



Please charge the product before using it for the first time

HOW TO USE THE APP

IOS

1. Scan the QR code on the right, then download and install the app.
2. For the first login, click "+" to scan the product identification QR code or manually enter the product identification, and the device is successful.
3. Start the product switch, turn on the Bluetooth of the mobile phone, and click the "My Device" icon to play the product.



Love Spouse QR

Android

1. Register as a member of "love spouse" by scanning the QR code on the APP.
2. For the first login, click "+" to scan the product identification QR code or manually enter the product identification, and the device is successful.
3. Start the product switch, turn on the Bluetooth of the mobile phone, and click the "My Device" icon to play the product.



Product Identification Code

(8314)


Interactive Mode

Click the interactive mode or swipe the operation interface of the APP to enter the interactive mode, or click the interactive button on the home page of the APP to enter the interactive mode and add friends.

1. Click the "Friends" button in the interactive interface will appear the "friends search" box, you can search the corresponding registered user by gender and age.
2. Click the friend icon you want to interact with, the system will initiate an interaction invitation, click OK. If the other party accepts your invitation, the interactive connection is successful.
3. After the interactive connection is successful, the video is disabled by default. You must invite the video of the other party and the other party agrees to enable the video function before opening the video of both parties.

Operating instructions

1. On/Off/Main body telescopic vibration key
2. Lips vibration/Egg wrapping vibration key
3. Lips vibration
4. Egg packaging vibration
5. Main body expansion and contraction vibration
6. Magnetic charging interface



1. On/Off/Main body telescopic vibration key:

Press and hold the "①" button for 1.5 seconds to turn on/off the power button. The power button light will remain on and enter standby mode. Click "①" again to activate the main body's telescopic vibration function. Click "switch frequency" again to cycle between 1-9 frequency telescopic vibration. Press and hold the power button for 1.5 seconds to turn off the product.

2. Lips vibration/Egg wrapping vibration key

In standby mode, click "②" to activate the lip/egg double vibration function, click "②" again to switch frequencies, and cycle between 1-9 frequencies. Press and hold for 1.5 seconds to pause the function.

3. remote control

Long press "③" for 1.5 seconds to turn on/the key light flashes once to enter standby mode. Press and hold again to activate the main body's telescopic vibration function for 1-9 frequency cycle conversion. Long press "③" for 1.5 seconds to turn off the device; Press "④" in standby mode to activate the lip/egg double vibration function with 1-9 frequency cycling conversion.

Specification parameters

Product Name: Vibration Swing Massager

Input current 5V/1A

Product size: 221*40*157MM

Waterproof performance: IPX6 waterproof rating

Product Material: Silicone+ABS

Charging method: Magnetic charging

Function mode: 9 * 9 frequency

Charging time: about 2 hours

Voice level: ≤ 45dB

Usage duration: about 1.5 hours

Rated voltage: 3.7V

Suitable for people aged 18 and above

Packing list

Telescopic vibrating anal plug * 1, product manual * 1, USB charging cable * 1.

Instructions

1. Please read this manual carefully before use and use it according to the instructions provided.
2. Please charge the product before using it for the first time.
3. Please keep the product clean after use and do not use corrosive cleaning agents for cleaning.
4. This product is prohibited for minors under the age of 18 to use

Precautions

1. Please use the standard USB charging cable for charging.
2. It is prohibited to use the product while charging.
3. This product is equipped with a built-in polymer lithium battery, which cannot be disassembled by oneself to avoid damage to the product.
4. After use, this product should be placed in a dry and ventilated place, avoiding direct sunlight.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The devices has been evaluated to meet general RF exposure requirement, the device can be used in portable exposure condition without restriction