



首次使用请先为产品充电

# 说明书

## 操作说明

伸缩键

开关机键

吮吸键



### ○ 开关机键:

- 1.待机:长按此键1.5S产品开机,马达震动0.2S进入待机状态,此按键处的LED灯常亮,进入待机模式:待机状态下,30分钟无操作自动关机。
- 2.关机:长按1.5S关机

### ○ 伸缩键:

- 1.开机状态下,点按此键,LED灯闪亮一下同时切换变频,马达1-9频加档,加频到第9频后再点按此键,频率循环9-1、2、3、4--继续变频,马达在任意伸缩震动频率状态下,长按1.5S,马达会进入待机状态。

### ○ 吮吸键:

- 1.开机状态下,点按此键,LED灯闪亮一下同时切换变频,马达从1-9频加档,加频到第9频后再点按此键,频率循环9-1、2、3、4--继续变频,马达在任意吮吸频率状态下,长按1.5S,马达会进入待机状态。

**●充电方式:** 磁吸充电, 使用前请先充电, 充电状态指示灯为白灯闪烁状态, 充满常亮;

**●充电时间:** 一般约2h充满;

**●使用时间:** 大于60分钟。

## APP控制



扫描二维码下载APP  
IOS系统也可以在苹果商店搜索“暮瑟”。



扫描二维码或  
输入3084绑定设备

- 下载并安装“暮瑟”,注册并登录
- 使用APP控制前,请将设备开机
- 点击“+”扫描绑定设备。
- 请允许APP访问蓝牙

### 【我的设备】

- 经典模式:9种经典振动模式可供选择。
- 音乐模式:APP会自动搜索手机中的音乐播放器。如果您单击音乐播放器播放音乐,设备会随着节奏的变化而振动。
- 画一些东西:点击+在屏幕上随意画一条线,保存并命名。点击名称上的三角符号,进入自由笔画保存模式。
- 摇晃:设备会根据您手机的震动节奏和幅度振动。
- 互动:好友搜索可以通过身份证号、手机号、邮箱进行搜索。

### 【相互作用】

点击要互动的好友图标,系统会发起互动邀请,点击确认。如果对方接受你的邀请,则交互连接成功。交互连接成功后默认不开启视频。您必须先邀请对方的视频并且对方同意打开视频功能,然后才能打开双方。

### 【信息】

本APP支持发送文字、图片、语音、震动模式。

### 【我的】

账户信息、操作指南和设置。

## 产品说明

产品名称	伸缩+吮吸按摩棒	产品型号	ZLV301
产品材质	ABS+硅胶		
产品尺寸	220*36*92mm		
充电时长	约 2 小时	工作时长	约1小时
输入电流	5V/1A	充电模式	磁吸充电
工作模式	9频震动 /APP 9频		

### 包装清单:


按摩棒\*1、产品说明书\*1、USB充电线\*1、

### 使用须知:

- 1.使用前请阅读本说明书,按照说明书提示规范使用;
- 2.第一次使用请先为产品充电;
- 3.使用后请保持产品清洁,请勿使用带腐蚀性清洁剂清洗;
- 4.本产品禁止18岁以下未成年人使用

### 注意事项:

- 注意:充电过程中,产品电路处于保护状态,不能启动。
- 由于电池保护,产品在使用中充电,产品无法开机正常使用。
- 不要将本产品长时间浸泡在水中。
- 请将本产品置于通风干燥处,避免阳光直射。
- 建议使用前先充饱电。



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The devices has been evaluated to meet general RF exposure requirement , the device can be used in portable exposure condition without restriction