ABS-2661 USER MANUAL

FCC Statement
Changes or modifications not expressly approved by the party responsible for compliance could
void the user's authority to operate the equipment.
This equipment has been tested and found to comply with the limits for a Class B digital device,
pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection
against harmful interference in a residential installation. This equipment generates uses and can
radiate radio frequency energy and, if not installed and used in accordance with the instructions,
may cause harmful interference to radio communications. However, there is no guarantee that
interference will not occur in a particular installation. If this equipment does cause harmful
interference to radio or television reception, which can be determined by turning the equipment off
and on, the user is encouraged to try to correct the interference by one or more of the following
measures:

- and or, in each is devolvaged or by your owner. The interference by one or into the interference measures:

 Reportent or relocate the receiving antenna.

 Increase the separation between the equipment and receiver.

 Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

connected.

- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

Function Operation and Features:

1. CC Short press for switching among BT,TF CARD, USB, LINE IN, 🖄

2. — Play the previous music under BT.TF card and USB mode, Play previous radio station under 無 mode. Long press to reduce the volume

3. ► Short press for music play/pause

Short press for music platypause
Long press for music platypause
Long press for mode station automatic searching under file mode.
Long press for addo station automatic searching under file mode.
Long press salves speaker's PIP button to disconnect to both salves speaker and mode phone
TWS open two bluetooth speakers at the same time,
double stack PII (any of them) to build the connection
between them, then search the model No.by phone
bluetooth and connected.

Play next radio station under to mode. Long press to Increase the volume

5.DC 5V

Charge Jack for built in battery. When DC 5V cable plugs in, The LED lights up

6.OFF/ON

Speaker power off / Speaker power on

Support USB and can play MP3 and WAV format music in U disk

8. TF card Port

Support TF CARD and can play MP3 and WAV format music in CARD

Tap to switch the light

10.AUX AUX IN can connect to PC, mp3, Phone, or CD walkman

- Power on the product or press MODE button to enter into BT mode.

Open mobile devices(Cell phones,computers.etc.) in BT mode, search for BT devices ,when it appears the item pairing name (ABS-2661).

After the device has been paired successfully for the first time, it will connect automatically around 10 seconds to the devices which connected before when next time use (Note: Each product could connect to one BT device only.)