


ROHS CE FCC

**Product Description:**

Use scenarios:
Home, Office, Hotel, Car 4S shop, Beauty Salon, Movie Theater, Brand
Clothing Store, Airport and other Commercial places.

1. Do not use overloaded power supply; sockets, as well as damaged power cords and plugs, if used, may endanger your safety and may cause a fire.
2. Please do not open the inside of the product to avoid damage to the product. If there is abnormality in the use of the product, please read the product instruction manual carefully to check whether it is operated according to the normal procedure or consult sales and after-sales service.
3. When the device is working, please do not disassemble the device or shake the device vigorously, as this will cause the device to work abnormally.
4. Do not place the product or the power adapter in water or drench it. Do not use the drenched power adapter.
5. When the product has been filled with liquid (essential oil), do not turn the product upside down, tilt or rotate to avoid liquid spillage and damage to the product.
6. When encountering thunder, do not operate the equipment or touch the power cord to avoid the risk of electric shock.



It can work normally when it is powered on (12V),
long press the power button to turn on or off

After connecting to the power supply, single press the setting button to enter the clock setting;
Click once to set the "hour" time,
Click again to set the "minute" time,
Click again to set the "week" time
Click again to exit.

3. A segment can only control the time of one day, if it exceeds the range of the day, the setting will switch to the previous setting. In this case, it can be set in two sections (the time of day is 00:01-23:59). For example, if the working time is from 22:00 to 2:00, it needs to be controlled in two o periods; the setting method is that the first period is 22:00-23:59; the s second period is 00:01-2:00, the set working time cannot be repeated, or otherwise the system will not be able to recognize it.

1. Press and hold the SET button + power button for 5s to restore the factory settings; and the buzzer will sound 5 times after success;
2. Screen lock function: Double-click the switch key and "+", at this time any key press will not work;
3. Unlock function: Double-click the switch key and "-", the machine can be operated normally after unlocking;
4. Short press the fan button to control on and off. When the fan is on, the start and stop of the fan are synchronized with the pump;
5. Motor work setting time is 5~300s (5s increment);
6. The machine stop setting time is 10~900s (5s increment);

Size	L150×W110×H320mm
voltage	DC12V
power	8W
Coverage	500CBM
Capacity	280ml
Noise	<35db
Color	White
Technology	Two fluid atomization
Supply	plug in
Oil Consumption	1 ML/h+5%

1. Pull out the essential oil bottle with a slight force upwards	2. Take out the essential oilbottle and pour in pure essential oil	3. Buckle the bottle touch to set the time and working frequency
4. Take out the back sticker, stick to the wall or fix it with screws	5. Align the holes on the back of the machine and fasten the machine	6. Insert the power cord into the power port, then it can be powered on

Maintenance once every six months, or when you need to replace with a new fragrance, and when you find that the fragrance has faded.

1. Open the cover of the equipment and take out the used essential oil bottle;
2. Every time the essential oil is replaced, it needs to be filtered with special cleaning essential oil;
3. Pour an appropriate amount of alcohol into the essential oil bottle and clean it;
4. Pour a small amount of alcohol into the essential oil bottle, install it on the device, and turn on the device for 5 minutes; or use a rag dipped in alcohol to wipe the two small holes of the atomizing core,

Malfunction	Solution
device not working	Check whether the wrong power supply is used Check whether the power supply is powered on Check the machine setting time
no atomization	Check whether the pump is working; whether the atomizing core is blocked whether the sealing ring of the outlet pipe is damaged or falls off whether the oil suction pipe is blocked or falls off
small atomization	Check whether the sealing ring of the air outlet pipe is damaged Check whether the atomizing nozzle is blocked Check whether the atomizing core and the atomizing head are loose
oil spill	Whether the atomizing head gasket is damaged Is it damaged and needs to be replaced? Whether the essential oil bottle and atomizing head are tightened
abnormal noise	The air pump is loose, fix the air pump again The air pump is damaged, replace it with a new one Check if the fan is fixed

Power supply	Back sticker	Manual	screw

The equipment is guaranteed within ten years from the date of sale, but the casing, wires and external pipes and other vulnerable parts, man-made or accidental damage a re not covered by the warranty, and paid repairs will be carried out beyond the free war ranty period.

[illegible]

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluatec to meel general RF exposure requirement. The device can be used in portable exposure condition without restriction.